

Continuum DVP™

Model D9010 Decoder

Installation and Operation Guide

Please read this entire guide

Veillez lire entièrement ce guide

Bitte das gesamte Handbuch durchlesen

Sírvase leer completamente la presente guía

Si prega di leggere completamente questa guida

Important

Please read this entire guide before you install or operate this product. Give particular attention to all safety statements.

Important

Veillez lire entièrement ce guide avant d'installer ou d'utiliser ce produit. Prêtez une attention particulière à toutes les règles de sécurité.

Zu beachten

Bitte lesen Sie vor Aufstellen oder Inbetriebnahme des Gerätes dieses Handbuch in seiner Gesamtheit durch. Achten Sie dabei besonders auf die Sicherheitshinweise.

Importante

Sírvase leer la presente guía antes de instalar o emplear este producto. Preste especial atención a todos los avisos de seguridad.

Importante

Prima di installare o usare questo prodotto si prega di leggere completamente questa guida, facendo particolare attenzione a tutte le dichiarazioni di sicurezza.

NOTICES

Trademark Acknowledgments

Scientific-Atlanta and the Scientific-Atlanta logo are registered trademarks of Scientific-Atlanta, Inc.

Continuum DVP is a trademark of Scientific-Atlanta, Inc.

Dolby Digital is a trademark of Dolby Laboratories, Inc.

The DVB logo is a trademark of the DVB Digital Video Broadcasting Project.

Imitext is a trademark of Screen Subtitling Systems Limited.

All other trademarks shown are trademarks of their respective owners.

Publication Disclaimer

Scientific-Atlanta, Inc., assumes no responsibility for errors or omissions that may appear in this publication. Scientific-Atlanta reserves the right to change this publication at any time without notice. This document is not to be construed as conferring by implication, estoppel, or otherwise any license or right under any copyright or patent, whether or not the use of any information in this document employs an invention claimed in any existing or later issued patent.

Copyright

© 2003 Scientific-Atlanta, Inc. All rights reserved. Printed in USA.





Information in this publication is subject to change without notice. No part of this publication may be reproduced or transmitted in any form, by photocopy, microfilm, xerography, or any other means, or incorporated into any information retrieval system, electronic or mechanical, for any purpose, without the express permission of Scientific-Atlanta, Inc.

Safety Precautions

Protect yourself from electric shock and your system from damage!

- This product complies with international safety and design standards. Observe all safety procedures that appear throughout this guide, and the safety symbols that are affixed to this product.
- If circumstances impair the safe operation of this product, stop operation and secure this product against further operation.

Avoid personal injury and product damage! Do not proceed beyond any symbol until you fully understand the indicated conditions!

	You will find this symbol in the literature that accompanies this product. It indicates important operating or maintenance instructions.
	You may find this symbol in the literature that accompanies this product. It indicates a live terminal; the symbol pointing to the terminal device.
	You may find this symbol in the literature that accompanies this product. It indicates a protective earth terminal.
	You may find this symbol in the literature that accompanies this product. It indicates excessive or dangerous heat.

Power

Important! This product is Protection Class II.

This product plugs into a socket-outlet. The socket-outlet must be near this product, and must be easily accessible. Connect this product only to the power source that is indicated on the back panel of this product. This product does not have a mains power switch, the power cord serves this purpose.

Enclosure

Do not allow moisture to enter this product. Do not open the enclosure of this product unless otherwise specified. Do not push objects through openings in the enclosure of this product.

Cables

Always pull on the plug or the connector to disconnect a cable. Never pull on the cable itself. Do not walk on or place stress on cables or plugs.

Factory service





Refer service only to service personnel who are authorized by the factory.

Règles de sécurité

Protégez-vous des risques d'électrocution et protégez votre système contre les endommagements éventuels.

- Ce produit respecte les standards internationaux de sécurité et de conception. Veuillez observer toutes les procédures de sécurité qui apparaissent dans ce guide, ainsi que les symboles de sécurité qui figurent sur le produit.
- Si, du fait des circonstances, ce produit cesse de fonctionner normalement, cessez de l'utiliser et empêchez-en l'utilisation future.

Évitez le risque de blessures et de dommages aux produits! Ne procédez à aucune tâche tant que vous n'aurez pas entièrement assimilé les conditions indiquées par un symbole!

	Ce symbole figure dans la documentation accompagnant ce produit. Il indique d'importantes instructions de fonctionnement ou d'entretien.
	Ce symbole peut être attaché à ce produit. Il indique une borne sous tension; la direction indique la borne.
	Ce symbole peut être attaché à ce produit. Il indique une borne de terre de protection.
	Ce symbole peut être attaché à ce produit. Il indique une température excessive ou dangereuse.

Alimentation

Important! Ce produit fait partie de la classe II.

Ce produit se branche dans une prise murale. Cette dernière doit être placée à proximité du produit et doit être facilement accessible.

Ne branchez ce produit qu'à la source d'alimentation indiquée sur son panneau arrière.

Si ce produit n'a pas d'interrupteur d'alimentation générale, le cordon d'alimentation remplit ce rôle.

Enceinte

Ne laissez pas l'humidité pénétrer dans ce produit.

N'ouvrez pas l'enceinte de ce produit, sauf instructions contraires.

Ne forcez pas d'objets dans les ouvertures du boîtier.

Câbles

Tirez toujours sur la prise ou le connecteur pour débrancher un câble, Ne tirez jamais directement sur le câble.

Ne marchez pas sur les câbles ou les prises et n'y exercez aucune pression.

Réparations effectuées à l'usine





Ne confiez les travaux de réparations qu'au personnel autorisé par l'usine.

Sicherheitsvorkehrungen

Schützen Sie sich gegen elektrischen Schlag, und Ihr Gerät gegen Beschädigung!

- Dieses Gerät entspricht internationalen Sicherheits- und Ausführungsnormen. Beachten Sie alle in diesem Handbuch enthaltenen Sicherheitshinweise sowie die am Gerät angebrachten Warnzeichen.
- Sollten örtliche Umstände den sicheren Betrieb dieses Gerätes beeinträchtigen, schalten Sie es ab und sichern es gegen weitere Benutzung.

Vermeiden Sie Verletzungen sowie Beschädigung des Gerätes! Wenn Sie zu einem der folgenden Warnzeichen gelangen, nicht weiterarbeiten, bis Sie seine Bedeutung voll verstanden haben!

	Dieses Symbol erscheint auf dem Gerät und/oder in der ihm beiliegenden Literatur. Es bedeutet wichtige, zu beachtende Betriebs- oder Wartungsanweisungen.
	Wenn dieses Zeichen am Gerät angebracht ist, warnt es vor einer spannungsführenden Stelle.
	Dieses Symbol kennzeichnet auf dem Gerät die Anschlußstelle der Sicherheitserde.
	Wenn dieses Zeichen am Gerät angebracht ist, warnt es vor heißen Stellen, die zu Verbrennungen führen können.

Netzspannung

Wichtig! Dieses Gerät ist Schutzklasse II.

Das Gerät ist an einer Steckdose anzuschließen. Diese muß sich leicht zugänglich in unmittelbarer Nähe des Gerätes befinden.

Die Netzversorgung muß den auf der Rückwand des Gerätes angegebenen Werten entsprechen.

Falls sich kein Hauptschalter am Gerät befindet, dient das Netzkabel diesem Zweck.

Gehäuse

Das Innere des Gerätes ist vor Feuchtigkeit zu schützen.

Das Gehäuse ist nicht zu öffnen.

Niemals einen Gegenstand durch die Gehäuseöffnungen einführen!

Kabel

Hierzu grundsätzlich am Stecker oder Verbindungsstück und niemals am Kabel selber ziehen.

Nicht auf die Kabel oder Stecker treten oder diese einer Zugbelastung aussetzen.

Hersteller-Wartung





Wartungsarbeiten sind nur durch vom Hersteller autorisierte Techniker vorzunehmen.

Precauciones de seguridad

¡Protéjase contra la electrocución y proteja su sistema contra los daños!

- Este producto cumple con los criterios internacionales de seguridad y diseño. Observe todas los procedimientos de seguridad que aparecen en esta guía, y los símbolos de seguridad adheridos a este producto.
- Si las circunstancias impiden la operación segura de este producto, suspenda la operación y asegure este producto para que no siga funcionando.

¡Evite lastimarse y evite dañar el producto! No avance más allá de cualquier símbolo hasta comprender completamente las condiciones indicadas!

	Encontrará este símbolo en el impreso que acompaña a este producto. Este símbolo indica instrucciones importantes de funcionamiento o mantenimiento.
	Es posible que este símbolo esté pegado al producto. Este símbolo indica un terminal vivo, la flecha apunta hacia el aparato terminal
	Podría encontrar este símbolo pegado al producto. Este símbolo indica un terminal de protección de tierra.
	Podría encontrar este símbolo pegado al producto. Este símbolo indica calor excesivo o peligroso.

Alimentación

Importante! Este producto de Clase II.

Este producto se conecta a un enchufe. El enchufe necesita estar cerca del producto y ser fácilmente accesible.

Conecte este producto únicamente a la fuente de suministro eléctrico indicada en el panel posterior del producto.

Si el producto no tiene interruptor para la línea principal, utilice el cordón toma de corriente para este propósito.

Cubierta

No permita que la humedad penetre en este producto.

No abra la cubierta del producto a menos que se indique lo contrario.

No introduzca objetos a través de las aberturas de la cubierta del producto.

Cables

Tire siempre del enchufe o del conector para desconectar un cable. Nunca tire del cable mismo.

No camine ni aplique presión sobre los cables o enchufes

Revisión y reparación de fábrica





Solo personal aprobado por la fábrica puede darle servicio al producto.

Precauzioni di sicurezza

Protegetevi da scosse elettriche e proteggete il vostro sistema da possibili danni!

- Questo prodotto soddisfa le norme internazionali per la sicurezza ed il design. Seguite tutte le procedure di sicurezza contenute in questa guida e i simboli di sicurezza applicati al prodotto.
- Se circostanze avverse compromettono la sicurezza d'uso di questo prodotto, interrompete l'uso e assicuratevi che il prodotto non venga più utilizzato.

Evitare infortuni alla persona e danni al prodotto! Non procedere oltre a qualunque simbolo fino a quando non si siano comprese pienamente le condizioni indicate!

	Questo simbolo, che appare nella letteratura di accompagnamento del prodotto, indica importanti istruzioni d'uso e di manutenzione.
	Sul prodotto potete vedere questo simbolo che indica un dispositivo terminale sotto tensione; la freccia punta verso il dispositivo.
	Potrete trovare il presente simbolo applicato a questo prodotto. Questo simbolo indica un terminale protettivo di messa a terra.
	Potrete trovare il presente simbolo attaccato a questo prodotto. Questo simbolo indica un calore eccessivo o pericoloso.

Alimentazione

Importante! Questo prodotto è protezione Classe II.

Questo prodotto si inserisce in una presa di corrente. La presa di corrente deve essere in prossimità del prodotto, e deve essere facilmente accessibile.

Collegare questo prodotto solamente alla fonte di alimentazione indicata sul pannello posteriore di questo prodotto.

Se questo prodotto non è dotato di un interruttore principale, il cavo di alimentazione funge a questo scopo.

Chiusura

Proteggete da umidità questo prodotto.

Non aprire la chiusura di questo prodotto a meno che non sia specificato diversamente. Non inserire oggetti attraverso le fessure della chiusura.


Cavi

Per scollegare un cavo tirate la spina o il connettore, non tirare mai il cavo stesso.

Non calpestare o sottoporre a sollecitazioni i cavi o le prese.

Riparazioni di fabbrica

Per le riparazioni contattate solamente personale tecnico autoizzato dalla fabbrica.



IMPORTANT SAFEGUARDS

1. **Read Instructions:** All the safety and operating instructions should be read before this product is operated.
2. **Retain Instructions:** The safety and operating instructions should be retained for future reference.
3. **Heed Warnings:** All warnings on the product and in the operating instructions should be adhered to.
4. **Follow Instructions:** All operating and use instructions should be followed.
5. **Cleaning:** Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
6. **Attachments:** Do not use attachments not recommended by Scientific-Atlanta as they may cause hazards.
7. **Water and Moisture:** Do not use this product near water - for example, near a bath tub, wash bowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool, and the like.

8. **Accessories:** Do not place this product on an unstable cart, stand, bracket, or table. The product may fall causing serious injury to a child or adult, and serious damage to the product. Use only with a cart, stand, bracket, or table recommended by Scientific-Atlanta. Any mounting of the product should follow the instructions, and should use a mounting accessory recommended by Scientific-Atlanta. An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.

PORTABLE CART WARNING



9. **Ventilation:** Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product, and to protect it from overheating. These openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the instructions have been adhered to.
10. **Heat:** This product should be located away from heat sources such as radiators, heat registers, stoves or other products (including amplifiers) that radiate heat.
11. **Power Sources:** This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply in your home or business, consult your appliance dealer or local power company. For products intended to operate from battery power, or other sources, refer to the operating instructions supplied with the product. For applications other than in North America, a suitable attachment plug adapter should be used for connection to the power source. For determining the appropriate attachment adapter type, refer to qualified technical personnel.
12. **Polarization:** This product may be equipped with a polarized alternating current line plug (i.e., a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.
13. **Power Cord Protection:** Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the appliance.
14. **Lightning:** For added protection for this product during a lightning storm or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power-line surges.
15. **Power Lines:** An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.

16. **Overloading:** Do not overload wall outlets, extension cords or integral convenience receptacles, as this can result in a risk of fire or electric shock.
17. **Object and Liquid Entry:** Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.
18. **Servicing:** Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.
19. **Damage Requiring Service:** Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:
 - a) When the power-supply cord or plug is damaged.
 - b) If liquid has been spilled, or objects have fallen into the product.
 - c) If the product has been exposed to rain or water.
 - d) If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation.
 - e) If the product has been dropped or damaged in any way.
 - f) The product exhibits a distinct change in performance.
20. **Replacement Parts:** When replacement parts are required, be sure the service technician uses replacement parts specified by Scientific-Atlanta, or parts having the same operating characteristics as the original parts. Unauthorized part substitutions made may result in fire, electric shock or other hazards.
21. **Safety Check:** Upon completion of any service or repairs made to this product, ask the service technician to perform safety checks to determine that the product is in safe operating condition.
22. **Outdoor Antenna Grounding:** If an outside antenna or cable system is connected to this product, ensure that the antenna or cable system is properly grounded to provide protection against voltage surges and built-up static charges. Appropriate sections of the National Electrical Code (NFPA 1990) provide information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, connection to grounding electrodes, and requirements for the grounding electrode.




Figure 1. Outdoor antenna grounding

Important Notice for Customers in the United Kingdom


Class II Apparatus Using a Two-Wire Power Cord

Important! The wires in this mains lead are coloured in accordance with the following code:

Colour	Mains lead wire
Blue	Neutral
Brown	Live

As the colour of the wires in the mains lead of this apparatus may not correspond with coloured markings identifying the terminal in your apparatus, proceed as follows:

IF wire colour is	Connect it to...
Blue	Neutral terminal. Note: The Neutral terminal is typically marked N or coloured black.
Brown	Live terminal. Note: The Live terminal is typically marked L or coloured red.

	<p>WARNING! Do not connect the blue or brown wires to the earth terminal of a three-pin plug.</p> <p>Note: The earth terminal is distinguished by its colour (green, or green-yellow), or by being marked with the letter E, or marked with the safety earth symbol (⏏).</p>
---	--

Warranty and Disclaimer

Statement

Scientific-Atlanta warrants good title to any hardware furnished by it. For software, we warrant that we have the right to grant any software license granted. We warrant during the Warranty Period as defined below that services will be performed in a good and workmanlike manner. We also warrant that during the Warranty Period, each item we deliver (other than separately licensed software and services) (an "Item") will be free from material defects in workmanship and materials and under ordinary use, conform in all material respects to its published specifications current at the time the Item was shipped. Items may include refurbished goods, subassemblies or components which we warrant as provided in this section.

Warranty Period

The Warranty Period begins on the date the Item is delivered and extends for 12 months for hardware and 90 days for software, parts and services. We will repair or replace, at our option, any product returned to us by the purchaser of such Item at the purchaser's expense during the Warranty Period, which fails to satisfy this Warranty, unless the failure was the result of shipping; improper installation, maintenance or use; abnormal conditions of operation; attempted modification or repair by the purchaser; or an act of God. We will reperform any services which do not conform to this Warranty provided we have received notice of non-conformance within the Warranty Period.

Disclaimer

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS, IMPLIED OR STATUTORY, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NONINFRINGEMENT. PURCHASER'S SOLE REMEDY FOR ANY BREACH OF WARRANTY IS THE REPAIR OR REPLACEMENT, AT SCIENTIFIC-ATLANTA'S OPTION, OF THE FAILED ITEM. SCIENTIFIC-ATLANTA SPECIFICALLY DISCLAIMS ANY AND ALL WARRANTIES, EXPRESS OR IMPLIED, TO CUSTOMERS OF THE PURCHASER.

Purchaser's Responsibility

The purchaser must pay packing, crating, and transportation costs to and from the factory. At the purchaser's request, we will make reasonable efforts to provide warranty service at the purchaser's premises, provided the purchaser pays our then current rates for field services and the associated travel and living expenses.

Claims Under This Warranty

In case of a claim under this warranty, the purchaser should do the following:

1. Notify us by giving the Item model number, serial number and details of the difficulty.
2. On receipt of this information, the purchaser will be given service data or shipping instructions.
3. On receipt of shipping instructions, forward the Item prepaid.
4. If the Item or fault is not covered by warranty, an estimate of charges will be furnished before work begins.

Limitation of Liability

EXCEPT FOR CLAIMS FOR PERSONAL INJURY CAUSED BY ITEMS FURNISHED BY SCIENTIFIC-ATLANTA, SCIENTIFIC-ATLANTA SHALL NOT BE LIABLE TO THE PURCHASER OR ANY OTHER PERSON OR ENTITY FOR INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, PUNITIVE, OR EXEMPLARY DAMAGES ARISING OUT OF OR IN CONNECTION WITH THE TRANSACTION IN WHICH THE ITEMS OR SERVICES WERE FURNISHED OR ANY ACTS OR OMISSIONS ASSOCIATED THEREWITH OR RELATING TO THE SALE OR USE OF ANY ITEMS OR SERVICES FURNISHED, WHETHER SUCH CLAIM IS BASED ON BREACH OF WARRANTY, CONTRACT, TORT OR OTHER LEGAL THEORY AND REGARDLESS OF THE CAUSES OF SUCH LOSS OR DAMAGES OR WHETHER ANY OTHER REMEDY PROVIDED HEREIN FAILS. IN NO EVENT SHALL SCIENTIFIC-ATLANTA'S TOTAL LIABILITY UNDER A CONTRACT EXCEED AN AMOUNT EQUAL TO THE TOTAL AMOUNT PAID FOR ITEMS PURCHASED UNDER SUCH CONTRACT.

Table of Contents

Class II Apparatus Using a Two-Wire Power Cord	ix
Warranty and Disclaimer	x
Introducing the Decoder	1
Welcome	1
Keypad Conventions	3
Installing the Decoder	7
Unpacking and Inspection	7
Rear Panel Connections	8
Installing the Unit	9
Operating the Decoder	11
Front Panel	11
General Operation	12
Menu Structure Overview	13
Main Menu	13
Status Menu	14
Presets Menu	16
Setup Menus	16
About Menu	34
Diagnostics Menu	38
SNMP Control	38
Web Browser Control	38
Customer Support Information	41
Hotlines	41
Technical Specifications	45
Operating Characteristics	45
Lock Levels	49
Overview	49
Alarms and Warnings	53
Overview	53
Compliance Information	55

Introducing the Decoder

Welcome

Welcome to Scientific-Atlanta's Continuum DVP™ Decoder Model D9010. This decoder is designed for Headend applications requiring the recovery of a program back to analog baseband format from a compressed digital format. The DVB-ASI input allows multi program transport streams to be connected to the decoder. The decoder offers the capability to select and decode one of the programs from the incoming DVB-ASI (MPEG-2) transport stream, and output baseband video, audio, cue tones, utility data and VBI.

The Continuum DVP™ Decoder offers a cost and space efficient way to recover programs from an MPEG-2 transport stream at remote Hubs for the analog tier.

Instead of receiving and decoding satellite delivered programs for the analog tier at each Hub, programs can be received at the Master Headend site and transported in MPEG-2 compressed format to the Hub locations.

The Decoder offers DTMF cue tone and eight open collector cue trigger outputs for analog ad-insertion at the Hub locations.

An active DVB-ASI output offers the ability to filter out a specific program from the incoming transport stream, or pass the complete transport stream for daisy chaining multiple decoders together.

Note: The Continuum DVP Model D9010 Decoder shares its control and application software with the PowerVu Model D9850 Program Receiver. As such there are references in this manual to satellite decoder parameters which are not applicable the D9010 decoder. These parameters should be ignored by the operator.

Key Features

- DVB-ASI input
- 4:2:0 NTSC/PAL video decoding
- Aspect Ratio conversion (4:3, 16:9 and 14:9)
- MPEG & Dolby® Digital (AC-3) audio decoding
- 2 stereo pairs of balanced audio outputs
- Utility data via RS-232
- Line 21 Closed Caption & V-chip support
- PowerVu format VBI support/DVB VBI (WST, WSS and VPS)
- DVB or Imtext™ subtitling
- DTMF cue tone & cue trigger outputs for ad-insertion
- Field-upgradeable software via ASI input
- Fingerprint trigger
- Front Panel LCD for control & monitoring
- IP data at 10 Mbps
- SNMP control
- Web browser access

Keypad Conventions

Throughout this guide, there are references to parts of a keypad on the front of the decoder. This is the Navigation/Selection keypad (see diagram at right), which changes its function, depending on the current state of the menu. For clarity, the following table shows which parts of this integral interface are being referenced by which term:














When you see this...	It means...	
LEFT Arrow button	Press the button on the left side of the Navigation/Selection Keypad.	
RIGHT Arrow button	Press the button on the right side of the Navigation/Selection Keypad.	
UP Arrow button	Press the button on the top of the Navigation/Selection Keypad. Move to next item in a list.	
DOWN Arrow button	Press the button on the bottom of the Navigation/Selection Keypad. Move to previous item in a list.	
SELECT button	Press the button in the center of the Navigation/Selection Keypad.	
INFO button	Press the button on the lower left of the numeric keypad for context-sensitive help messages*.	
MENU button	Press the button on the lower right of the numeric keypad*. This button functions as the <i>Escape</i> key, backing the user out of menus and data entry fields.	
Alphanumeric Entry	Pressing the numeric buttons 2-9 once will enter the respective digit into a data entry field. Pressing these buttons again will enter the first of the letters displayed beside the number. Repeatedly pressing the button will toggle through all of that key's possible choices. When entering text, the 1 button can be used to insert spaces (press twice).	

*Numeric keypad buttons are uniform. MENU and INFO have been enlarged here for effect.

LCD Symbol Legend

Various symbols will periodically appear in the LCD panel, indicating which user actions are currently acceptable. For instance, if an **S** appears on the right-hand side of the LCD, then the **Select** key is active and has a function for the menu's current state. The following table describes what symbols you may see and what they mean:

Description	Character	Explanation
Cursor		When this symbol appears to the left of a menu item, the action you take will apply to that item.
LEFT		When this symbol appears on the right-hand side of the LCD screen, the left arrow key is active; e.g., pressing the left arrow key will have an affect, such as moving the cursor to the left.
RIGHT		When this symbol appears on the right-hand side of the LCD screen, the right arrow key is active; meaning pressing the right arrow key will have an affect, such as moving the cursor to the right.
Info Spot		When this symbol appears on the right-hand side of the LCD screen, the INFO key is active. In most cases, this will display contextual information on the LCD screen.
Select		When this symbol appears on the right-hand side of the LCD screen, the SELECT key is active.
Active		The displayed preset is actively used for reception of signal.
UP*		When this symbol appears on the right-hand side of the LCD screen, the UP arrow key is active.
DOWN*		When this symbol appears on the right-hand side of the LCD screen, the DOWN arrow key is active.
Download In Progress (DL)		This symbol, when displayed, indicates that the decoder is currently downloading a software update and storing it into memory in the background. Note that service interruption occurs during a reboot, which is always required when the decoder's software is updated.
Download PID Present		This symbol, when displayed, indicates that a software download PID either for other IRD types or for a version of software already in memory, has been detected.

Download Trigger present (DT)		<p>This symbol, when displayed, indicates new software is ready for download, but a download trigger by the decoder is required before it will be downloaded.</p> <p>Note that service interruption occurs during a reboot, which is always required when the decoder's software is updated.</p>
-------------------------------	---	---

* Be aware that when a list of options are available to be *scrolled* through with the UP and DOWN arrow keys, the sequence of the items goes from bottom to top; meaning, the next item in a list is always accessed by pressing the UP arrow

Installing the Decoder

Unpacking and Inspection

When removing the Decoder protective packaging, inspect the shipping carton for damage. If any signs of damage are evident, notify the carrier immediately before accepting the consignment. Contact your local Scientific-Atlanta representative if any signs of damage or defects are discovered.

Retain the packaging in the event of return, or for equipment storage. Scientific-Atlanta will not be held liable for equipment damage plus any shipping and/or repair charges resulting from inadequate packing, or use of packing materials that do not meet Scientific-Atlanta's specifications.




WARNING!

The Decoder is designed for rack-mount applications. Install the product in a dry, well ventilated location to allow adequate air circulation. Ensure that sufficient clearance is maintained at the chassis rear panel for connecting input/output and AC power cables.

Do not obstruct the chassis ventilation holes. Prolonged operation with reduced ventilation may result in equipment damage.

Rear Panel Connections



Continuum DVP™ Decoder Model D9010

	Control/Connector	Type	Function/Description
1	Cue Trigger	Open Collector Outputs	Pins 1-8 -Interface for External Ad-Insertion equipment or device control. Pin 9 - Ground Pins 10 & 11 - Low-speed data (RS-232). Pin 10 carries data and pin 11 is the ground.
2	Video (2 ports)	BNC	These ports provide the video output. Typically, one is for connection to a cable headend and the other is for connection to a local monitor.
3	Program Relay	Terminal Blocks	Program Relay provides programmed responses to Alarms or cue trigger pin states.
4	Cue Tone	Terminal Blocks	Cue Tone provides DTMF output for connection to external ad-insertion equipment.
5	Balanced Audio 1 & 2	Terminal Blocks	Balanced Audio 1&2 provides two stereo pairs or four mono channels.
6	ASI OUT	BNC	Asynchronous Serial Interface Output
7	ASI IN	BNC	Asynchronous Serial Interface Input
8	Ethernet	RJ-45	Ethernet IP data and control monitoring.
9	AC IN	NEMA 5-15p	Voltage input 100-240 VAC, 50/60 Hz, 50W max.
10	Ground	Screw	Grounding point for the decoder.

Installing the Unit

Installation of the decoder requires mounting the unit into a rack assembly and connecting signal and power cables to the rear panel.

Installing the Rack Assembly

The decoder is one standard rack unit (1RU) high and should be mounted in a standard 19-inch wide by 24-inch deep rack space.

Connecting the Signal Cables

1. **Connect the ASI signal cable** to the ASI IN on the rear of the unit.
2. **Connect the Video output signal (2) to your cable system** using a 75 ohm coaxial cable. This can be a connection to a cable headend device or a monitor, or both.
3. **Connect the BALANCED AUDIO output** to a modulator or switcher equipment. Use a multi-conductor, pluggable cable from the decoder's BALANCED AUDIO 1 and 2 (Left and Right) terminals to your equipment. This output can also be connected to a PowerVu Video Encoder for re-encoding, or to a monitor/local audio amplifier.
4. **If desired, connect the CUE TRIGGER port** to either a serial control device or a device to control ad-insertion.
5. **If desired, connect the Cue Tone 3-pin terminal** to a device to facilitate ad-insertion using DTMF Analog Cue Tones.
6. **If desired, connect the ASI IN port** to an asynchronous serial interface device for uplink monitoring or telco applications.
7. **If desired, connect the ASI OUT port** to an asynchronous serial interface device for digital pass-through applications.



CAUTION!

Scientific-Atlanta recommends using a double-shielded coaxial cable to connect to the ASI OUT and/or the ASI IN port.

Connecting Ethernet Cables

If desired, the appropriate RJ-45 mating connector may be used for remote monitoring and control either via SNMP or the built-in Web browser. IP data is also available via the Ethernet port.

Connecting Power Cables

Connect the power cord (supplied with the unit) between the rear panel power receptacle and a 100V to 240V, 50/60 Hz ac power outlet.

**CAUTION!**

This Product must be Equipotentially Earthed for Equipment Protection and EMC. Use Earth Connection Indicated by Item 10 on the Rear Panel Drawing.

Power Cord

The power cord (consisting of appliance coupler, flexible cord, and plug) supplied with this product meets the requirements for use in the country for which this product was purchased. In general, the power cord must be approved by an acceptable, accredited agency responsible for evaluation in the country where the product will be used.

The power cord must be rated 10A, 125VAC, or 10A, 250VAC in accordance with the power distribution system in the country where the device will be used.

The appliance coupler must comply with IEC60320 Sheet C17, for proper mating with the power inlet used in this product.

**CAUTION!**

The power cord provides no grounding feature. To properly ground the device, use the grounding screw at the top-right of the decoder's rear panel (.

Maintenance of EMC Compliance

Shielded cables should be used to interconnect this unit with any peripheral equipment (e.g., data sources, terminals, monitors, etc.) to ensure compliance with Class B limits.

Operating the Decoder


This chapter shows how to use the function menus accessed on the front panel of the decoder and the impact of such operations.

Front Panel

Front Panel Controls and Indicators

The Decoder is operated using controls and indicators on the front panel. These include the numeric keypad, the Navigation/Selection keypad, the LCD, the ALARM and SIGNAL indicators, as well as the Card Reader. These are shown in the following illustration:

Receiver Front Panel Controls and Indicators



Numeric Keypad

The numeric keypad is used to enter alphanumeric values. The **MENU** key functions as an “escape” key moving you up the menu tree, and the **INFO** key displays contextual help, when available.

LCD

The LCD provides information on the selections available at any menu level, current settings for parameters, and certain status and alarm indications. This

backlit LCD display can display two 40-character lines. Typically, the top line may be status data or identifier information. It can also display optional functions available for tuning operations. The bottom line will show selections or parameter values available using the navigation/selection keypad. The items are selected by pressing the **SELECT** button (center button) on the navigation/selection keypad.

When an alarm exists, the bottom line of the display periodically displays the alarm condition.

Navigation/Selection Keypad

The navigation buttons (LEFT, RIGHT, UP and DOWN) and the SELECT button on this keypad are the primary controllers. Each navigation button performs various functions, depending on the current state of the menu system (i.e. sometimes the left navigation button backspaces over an entry and sometimes moves the cursor to a different menu item). Once the cursor is over the desired function, pressing the SELECT button selects the current item (this may go to a different menu or change an option).

Alarm LED

The Alarm LED flashes red whenever an alarm condition exists in the decoder. The LED flashes for five seconds whenever a warning condition exists in the decoder.

Signal LED


The Signal LED solidly illuminates green whenever a signal lock occurs. When this LED is flashing, the signal is locked, but not authorized. Alternatively, the LED is off when an active signal is not present at any of the selected inputs, either RF IN or ASI IN.

General Operation

Operation of the Decoder is accomplished through the various menu levels illustrated in the diagrams on the following pages. Each level and/or function can be accessed via the navigation/selection keypad. Data can be modified with the numeric keypad or the navigation/selection keypad. Selections and data input are saved immediately. The software will not allow any entry outside the valid parameters. If such input is attempted or incorrect data is entered, the actual value will be reset to the closest acceptable value. (i.e., if the range of acceptable values is 1 to 31 and you enter 99, the value will be reset to 31; or if you enter 0, the value will be reset to 1.)


The method of operation is explained below. The explanation describes each menu level, the selections available at each level, and how to make the desired selection.

Menu Structure Overview



Main Menu


Operation of the Decoder begins at the **Main** menu. On power up and initialization, the channel display is shown. To view the Main menu, press the **MENU** button.



Select the desired function by moving the cursor left or right by pressing the LEFT or RIGHT button on the navigation/selection keypad. Once a selection is made by pressing the SELECT button, the LCD presents the second menu level for the selected function. Secondary and succeeding levels for each function are described on the following pages.

Status Menu

This menu is used to see the status of various elements of the decoder. These fields are display only.



Prog – Shows the program channel number.

Status – Shows the authorization status for the current program (i.e., authorized or not authorized).

Type & PID – Shows the associated service PID and type carried in the current program. By selecting this option, the user can scroll through all of the PIDs associated with this channel. (i.e., PCR, VID, AUD1-4, VBI, LSD, MPE1-5, STT, CDT, Pass1-24 or ECM)

- L-Band** – Shows the current L-Band frequency (MHz).
- Freq** – Shows the current downlink frequency (GHz).
- Lock** – Shows the current signal lock status.
- Lvl** – Shows the current signal level.
- AFC** – Shows the current Automatic Frequency Control count.
- SymRate** – Shows the Symbol Rate.
- FEC** – Shows the Forward Error Correction.
- NetID** – Shows the Network ID.
- TxID** – Shows the Transport ID.
- Polar** – Shows the actual LNB voltage for RF1 (0, 13 or 18). If no NIT has been received, the polarization in the active preset will be displayed.
- Preset** – Shows the currently used active preset.
- CEC** – Shows the current Corrected Error Count.
- UEC** – Shows the current Uncorrected Error Count.
- BER** – Shows the current Bit Error Rate.
- Authorized** – Shows whether the signal is authorized or not.
- Encrypted** – Shows whether the signal is encrypted or not.
- Scrambled** – Shows whether the signal is scrambled or not.
- Mode** – Shows detected scrambled signal (i.e., DVB, DES or Unknown).
- Vid Bitrate** – Shows the current Video Bit Rate.
- Video Res** – Shows the current Video Resolution.
- 3:2 Pulldn** – Shows whether 3:2 pulldown mode is detected (i.e., Yes or No).
- Fps** – Shows the video frame rate in frames per second.
- ADP Enc & ADP Non-Enc** – Shows the current Encrypted and Non-Encrypted Addressed Data Packet Counts. These counts indicate the amount of transmitted ADP information which is being accurately received and processed. Ideally, these two numbers should be identical. To help the user make accurate analyses of the decoder's functionality, these numbers can be cleared by pressing **Select** on this menu. These values are also reset whenever the decoder is turned on or restarted/reset.

Alarms and Warnings Menus

These menus allow you to see all of the current alarms and warnings.

System Alarms Menu – This menu shows all Alarm messages since the last time they were cleared or the decoder was power cycled. The user can scroll through the messages by pressing **Select** and then using the **UP** and **DOWN** arrow keys. If there are no current alarm messages, then the menu displays *No System Alarms to Report*.

System Warnings Menu – This menu shows all Warning messages since the last time they were cleared or the decoder was power cycled. The user can scroll through the messages by pressing **Select** and then using the **UP** and **DOWN** arrow keys. If there are no current warning messages, then the menu displays *No System Warnings to Report*.

Clear Alarms – Selecting this option clears any existing Alarms (flashing Alarm LED). The function is instantaneous, but you can tell when it is successful because the Alarm light will go out (assuming there's no existing Warnings).

Clear Warnings – Selecting this option clears any existing Warnings (solid Alarm LED). The function is instantaneous, but you can tell when it is successful because the Alarm light will go out (assuming there's no existing Alarms).

Note: Since Alarms are more serious than Warnings, when both Alarms and Warnings exist, the Alarm LED will flash (i.e., not solidly illuminated).


Presets Menu

This menu does not apply to the D9010 decoder as it is not applicable to the ASI input. The signal "Input" port will always be **ASI 0**.

All other options on this menu only apply to decoders with RF input ports.


Setup Menu

The Setup Menus are the starting point for all decoder configurations. Use the **LEFT** and **RIGHT** arrow keys to select the area of the decoder's operation you would like to setup/configure, and then press **SELECT**.



Admin Menus

These menus are used to control the administrator user-configurable options.



Lock Level – This is the lock level setting for the decoder in the range from 0 – 4.

Password – This is where you can change the password used to control the Lock Levels. To change the password, press **Select** and then enter the old password. Next, enter the new password (four digits in the range from 0000 to 9999) and re-enter the new password for confirmation when prompted. To change the password, the decoder must be in Lock Level 0.

Note: The default password when shipped is **1234**.

Changing the Lock Level

To change the lock level, the user enters the **Admin Setup** menu and presses **Select** with the cursor on the **Lock Level** option. The option name will change to **Enter Lock Level** and the cursor will move down into the data entry area. The user can now use the up/down arrows to toggle through the possible lock levels. When the desired lock level is displayed, press **Select** and the user is prompted for the **lock level password**. Enter the four-digit password. The new lock level will only be applied when the password has been accepted.

For information on changing the lock level password, see the **Password** option above.

For general information on lock levels, see “Lock Levels” on page 15.

For functions which are locked out, the message *Permission denied for <function>* will display. The user will not be able to execute locked-out functions.

For variables or options which are locked out, the message *Permission denied for <item> in <table>* will display. The user will not be able to change or select locked-out variables or options.

LCD Contrast – This setting adjusts the contrast of the LCD menu panel. You can enter a number in the range of from 0 to 30, with 30 being the highest contrast. You can also scroll through the available values using the Up and Down arrow keys.

Validate OrbPos - This option allows you to check the position of your satellite in the event you switch to another RF input (i.e., change your Preset). The decoder will check to see if all the frequencies in the network table can be tuned to.

Factory Reset – This option allows you to perform a reset of decoder settings back to the way they were when the unit left the factory. A warning message allows you to confirm that you really want to do this.

DL Mode – This option allows you to select the desired Download Mode. Possible options are **Always**, **Once** and **Never**. **Always** will accept an unforced download and save it in memory. **Once** will accept an unforced download, reboot the decoder and change the DL Mode to Never. **Never** will not accept unforced downloads.

Note: Forced downloads (initiated by the uplink) are always accepted and always result in a reboot of the decoder. *Service interruption will occur!*

CDT# – This is the Code Download Table in the file being downloaded that is currently being received. Although a single file is being downloaded, it is made up of many of these tables. As a table is received, the **CDT#** increases incrementally. All of the counters are cleared when the download has completed, is aborted or when the decoder is power-cycled.

Recv – This is the number of CDTs received since the last completed or aborted download, or power-cycle.

Reject – This is the rejected table count. Tables are rejected whenever validation fails due to things like CRC failure or incorrect code or decoder type.

Abort – Selecting this option stops a download that is currently being received.

Restart – Selecting this option restarts a previously aborted download. Note that the download does not resume from where it was aborted, but restarts from the beginning.

Application Select – If more than one application/version is stored in the decoder, this selects which to use.


Reboot – Selecting this option will reboot the decoder. After you press **Select**, you are prompted on whether you really want to reboot. Select **Continue** to reboot the decoder.

Erase – When selected, this option removes the selected application code from memory, and resets it to the factory configured application code setting.

A/V Menus

These menus allow you to configure the decoder's audio and video settings.

Video Format – Select video format for the video output. Possible options are **NTSC**, **PAL-B/G/I/D**, **PAL-M**, **PAL-N (AR)** or **AUTO**. Use NTSC for 525-line systems and PAL-B/G/I/D for 625-line systems.



Stream – This is the format of the incoming stream. This value is read-only.

Output Format – This is the signal format output from the decoder. This value is determined by the Video Format setting and the actual format of the incoming stream. This value is read-only.

Changing the Aspect Ratio

Changing the aspect ratio allows you to control how the incoming signal/program is displayed at the video output. This feature allows the decoder to match the display format of the MPEG video to the TV system, either 4:3

(standard) or 16:9 (wide screen). 16:9 encoded streams require conversion to feed 4:3 systems, and vice versa.

Aspect ratio is set using two parameters: **TV A/R** and **Convert**. **TV A/R** is used to set the aspect ratio of the TV the program is to be displayed on. **Convert** is used to set the type of conversion required by the decoder to display in either 4:3 or 16:9 format.



TV A/R (Aspect Ratio) - This is the aspect ratio of your TV. The default is 4:3. Set it to the corresponding value. Possible options are **4:3** or **16:9** (wide aspect ratio).






Convert - This is the conversion the decoder will perform on the incoming signal for the picture to be displayed correctly (i.e., to correspond to the aspect ratio of your TV) on your TV, based on your selection. Possible options are **Auto**, **None**, **16:9 F/W** (full width), **4:3 F/H** (full height), **14:9**, **4:3 P/B** (pillar box), and **4:3 L/B** (letter box). The default is set to **Auto**.





Stream - This indicates the aspect ratio of the incoming signal. This is read-only information.

Act Conv - This is the type of (aspect ratio) conversion the decoder will perform based on what you have selected. This is read-only information.

Refer to the following table for the conversions performed by the decoder based on your selection, and the affect on the picture displayed by the decoder in each case.

Stream (read only)	TV Aspect Ratio	Conversion	Act Conv (read only)	Description	Image
4:3	4:3	None	None	Normal Picture	 4:3
4:3	4:3	Auto	None	No conversion	
4:3	4:3	4:3 L/B	None	Conversion is not possible. Normal picture.	
4:3	4:3	4:3 F/H	None	Conversion is not possible. Normal picture.	
4:3	4:3	4:3 P/B	None	Conversion is not possible. Normal picture.	
4:3	4:3	14:9	None	Conversion is not possible. Normal picture.	
4:3	4:3	16:9 F/W	None	Conversion is not possible. Normal picture.	
4:3	16:9	None	None	Picture is short & fat.	 4:3 Stretch

Stream (read only)	TV Aspect Ratio	Conversion	Act Conv (read only)	Description	Image
4:3	16:9	Auto	4:3 P/B	Uses 4:3 P/B.	
4:3	16:9	4:3 L/B	None	Conversion is not possible. Picture appears short and fat.	
4:3	16:9	4:3 F/H	None	Conversion is not possible. Picture appears short and fat.	
4:3	16:9	4:3 P/B	4:3 P/B	4:3 picture is centered in a pillar-style box.	
4:3	16:9	14:9	14:9	Compromises some up-sampling. Some black bars and cropping are visible.	
4:3	16:9	16:9 F/W	16:9 F/W	Vertically up-samples the centre of the 4:3 picture and crops the top and bottom of the screen.	
16:9	16:9	None	None	Normal	
16:9	16:9	Auto	None	No conversion. Normal picture.	
16:9	16:9	4:3 L/B	None	Conversion is not possible. Normal picture.	
16:9	16:9	4:3 F/H	None	Conversion is not possible. Normal picture.	
16:9	16:9	4:3 P/B	None	Conversion is not possible. Normal picture.	
16:9	16:9	14:9	None	Conversion is not possible. Normal picture.	
16:9	16:9	16:9 F/W	None	Conversion is not possible. Normal picture.	


Stream (read only)	TV Aspect Ratio	Conversion	Act Conv (read only)	Description	Image
16:9	4:3	None	None	Picture appears tall and thin.	 16:9 Compressed
16:9	4:3	4:3 L/B	4:3 L/B	Vertically down-samples the picture and applies black bars at the top & bottom of the screen.	 4:3 LB
16:9	4:3	4:3 F/H	4:3 Crop	Horizontally up-samples the centre portion of the picture to fill the 720.	 4:3 Crop
16:9	4:3	4:3 P/B	None	Conversion is not possible. Picture appears tall and thin.	
16:9	4:3	14:9	14:9	Compromises some up-sampling. Some black bars and some cropping are visible.	 14:9
16:9	4:3	16:9 F/W	None	Conversion is not possible. Picture appears tall and thin.	

Caption Mode - This is the mode of closed-captioning to use, if any. Possible options are **Auto**, **SA Custom**, **EIA 708**, **DVS 053**, **Type 3**, **DVS 053 Type 4 SA**, **DVS 053 Type 4 ATSC**, **Reserved** or **DVS 157**. The default is **Auto**.

Note that mode 1 (S-A Custom) is not supported when telecine video coding is enabled.

Aud# - This is the audio output number to which all settings on the two audio menus will apply. Possible options are **Aud1** or **Aud2**. When you change this option on one of the Audio Menus, it changes on the other as well.

The two audio (Aud#) menus allow you to configure the two Balanced Audio outputs on the rear panel, known in the decoder as **Aud1** and **Aud2**., respectively.



AC3 Compression – (Applicable only if the received signal is Dolby Digital (AC-3)) This specifies the AC3 Compression range of the received audio. Possible options are **Line Mode**, **Custom 1**, **Custom 0** or **RF Mode**. (RF Mode is recommended for analog cable modulators.)

Left – This is the volume adjustment for the Left audio channel, in the range of **-6.0 dB** to **+6.0 dB**. Any value can be entered with the numeric keypad (in the appropriate range), but the **UP** and **DOWN** arrows will make increments/decrements at 0.5 dB steps.

Right – This is the volume adjustment for the Right audio channel, in the range of **-6.0 dB** to **+6.0 dB**. Any value can be entered with the numeric keypad (in the appropriate range), but the **UP** and **DOWN** arrows will make increments/decrements at 0.5 dB steps.

Stereo/Mono – This setting configures how audio received on the audio input is handled. Possible options are **STEREO** (Left and Right are passed directly through to Left and Right), **R-MONO** (Right is passed to both the Left and Right), **L-MONO** (Left is passed to both the Left and Right), and **MIXED** (Left is passed to both the Left and Right, and Right is passed to both the Left and Right).

Audio Decoder - This setting is used to select the audio channel within the stream when the signal contains more than two audio pairs. The defaults are **AUD1** for audio channel Aud1 and **AUD2** for audio channel Aud2. Possible options for the two stereo audio channels are **AUD1** to **AUD4**.

Note: These settings may be changed/overridden by the uplink.

TxOut Menu

The TxOut Menu allows you to configure filtering for the MPEG Transport (ASI) output signal.

◆Filter Mode i 5
No Output ◀ ▶

◆ASI Out Rate User Rate Actual Rate 5
Automatic 68.5 0.0 ◀ ▶

Filter Mode – This is the type of filtering, if any, which occurs on the transport output. Possible options are **No Output** (nothing is transported), **Passthrough** (the raw signal is output), **Service Channel Scrambled** (the current scrambled channel is output), **Service Channel Descrambled** (the current channel is descrambled and output) and **Passthru w/ Svc Ch Descrambled** (the current channel is descrambled and output along with other channels). Custom PID is reserved for future use.

ASI Out Rate - This sets the ASI output bit rate (in Mbps) when the unit has an RF input signal. Possible options are **Automatic**, **Minimum** and **User Selected**. The table below describes the affect each of the settings has on the ASI output bit rate.

ASI Out Rate Selection	Description
Automatic	The output rate follows that set by the uplink. This means the output bit rate is determined automatically based on the input source symbol rate and FEC value.
Minimum	The output rate is set at the minimum allowed by the decoder. (The decoder does not output null packets) This can be useful in applications where you want to daisy-chaining multiple receivers, and ensure that the ASI input source bit rate does not exceed that expected by each of the other receivers in the chain. In this mode, the Actual ASI output bit rate is not displayed (appears as 0.0).
User Selected	The output rate is determined by the user setting regardless of the input source.

User Rate - When the ASI Output Rate is set as **User Selected**, enter the required output rate using the numeric keypad. This setting is used when the signal source is the RF or ASI input. Note that output data may be lost when the **User Selected** bit rate is set to a value that is less than the actual signal bit rate. This allows you to set the output bit rate to a value expected by equipment connected to the ASI output.


Actual Rate - This is the actual ASI output bit rate of the decoder. This will be either the automatically calculated value or the user selected value. The Actual Rate may be different than the **Automatic** or **User Selected** value depending on the **Filter Mode** setting, e.g., when set to **No Output** or **Passthrough**. The following table shows the affect different Filter Mode settings in combination with ASI Out Rate selections have on the ASI output bit rate, which will depend on your application.

Filter Mode	ASI Out Rate Setting	Input Source	
		RF	ASI
		Actual ASI Output Bitrate	Actual ASI Output Bitrate
No Output	Automatic	Zero	Zero
Passthrough		Same as input source	Same as input source
Service Channel Scrambled		Calculated based on modulation settings	User Rate
Service Channel Descrambled		Calculated based on modulation settings	User Rate
Passthru w/ Svc Ch Descrambled		Calculated based on modulation settings	User Rate
No Output	Minimum	Zero	Zero
Passthrough		Same as input source	Same as input source
Service Channel Scrambled		Only PIDs referenced in the PMT, plus PSI	Only PIDs referenced in the PMT, plus PSI
Service Channel Descrambled		Only PIDs referenced in the PMT, plus PSI	Only PIDs referenced in the PMT, plus PSI
Passthru w/ Svc Ch Descrambled		All PIDs except 8191	All PIDs except 8191
No Output	User Selected	User Rate	Zero
Passthrough		Same as input source	Same as input source
Service Channel Scrambled		User Rate	User Rate
Service Channel Descrambled		User Rate	User Rate
Passthru w/ Svc Ch Descrambled		User Rate	User Rate

3

Cueing Menu

This menu allows you to control the decoder's cue tone/trigger features. Cueing is used to automate the insertion and synchronization of localized commercial messages into video programming.



Note: You cannot select Cue tone and Cue trigger concurrently.

Cue tones are standard Dual-Tone-Multi-Frequency (DTMF) tones. The tones are generated at the Cue Tone output on the rear panel of the decoder.

Cue trigger refers to open collector pins which can be generated at the **Cue Trigger** output on the rear panel of the decoder.

Cueing Mode – This setting determines if the cueing mode is **Cue Trigger** or **Cue Tone**.

Trigger Polarity – This setting determines if the Trigger Polarity is **Active High** or **Active Low**. When **Active High**, an **Active** signal sent by the Uplink results in a **Floating** or **open collector**. An **Inactive** signal results in a **GND** signal. When **Active Low**, the reverse of Active High is true.

Repeat – This parameter specifies how many consecutive tone sequences are generated. Possible options are **1**, **2**, and **3**. The default is **1**. The other values are provided when a scenario demands repetition to ensure the ad insertion equipment receives the signal.

Tone (ms) – This is the duration of the tone in milliseconds. The default is **40**, and the acceptable range of possible values is from **0** to **80**.

Silence (ms) – This is the silence duration between the tones in milliseconds. The default is **40**, and the acceptable range of possible values is from **0** to **80**.

Seq# – This is the tone sequence to use. The decoder supports up to 16 tone sequences. Press **Select** and then use the up/down arrows to move through all 16 available sequences, pressing **Select** again to choose the one you want. Now any edits you make to **State**, **Tones**, **Mode** and **Delay** will be applied to that **Seq#**.

State – This sets the state to either **enabled** or **disabled**. When disabled, no cue tone is output.

Tones – These are the cue tone digits used in your network.

Mode – This option specifies what to send in the sequence. Options are ***** for **Start Tone**, **#** for **End Tone**, and ***/#** for sending the **Start Tone** and then the **End Tone** after waiting the specified **delay** time in the option below.

Delay (sec) – This is the delay, in seconds, that is sent when ***/#** is used in the **Mode** option above. The default is **30**, and the acceptable range of possible values is from **1** to **255**.

Relay Mode – This relay can be programmed to respond to an Alarm state, or the state of one of the eight cue trigger pins. The response is generated at the PGM RLY output on the rear panel of the decoder.

The following table shows what the possible field settings are and their relationship to the decoder output:


Relay Mode	Condition	Relay Contact	
		NC - C	C - NO
Alarm	Unit Power Off	Open	Close
	Alarm State	Open	Close
	No Alarm	Close	Open
Cue Trigger*	Active (selected in PNC)	Close	Open
	Inactive	Open	Close

* select one of the eight **Cue Trigger Bits**, corresponding to Cue Trigger port pins.

3

IP Setup

This menu is used to configure the IP options of the decoder.



IP Address/Mask – This is the IP Address and Subnet Mask you would like to assign to the device for its participation in a Network environment.

Gateway Address – This is the Network Gateway Address on the Network, used to expose the unit to a WAN.

The IP Address/Mask and Gateway Address should be changed together, i.e., as a group.

The following table shows the most commonly used Subnet mask values to enter for a chosen IP address mask, which will depend on the size of your network.

Mask	Subnet Mask
8	255.0.0.0
16	255.255.0.0
24	255.255.255.0

MAC Address – This is the MAC address of the decoder. This is a read-only value.

Multicast Filter – Possible options are **None** (no multicast IP data is forwarded), **Filter List** (packets matching the specified multicast address are forwarded), and **Forward All** (all received multicast IP data is forwarded without filtering).

IGMP Mode – This is the Internet Gateway Multicast Protocol. It can be toggled on or off. When on, the decoder accepts dynamic multicast requests from other network devices to join multicast groups with the specified multicast addresses.

Fixed Multicast IP Address – This is where you enter the Multicast IP Addresses you want the decoder to monitor and forward. Select **Add** and enter any new addresses you require. (Select *Filter List* in **Multicast Filter** above.)


Dynamic Multicast IP Address – This is a list of the IP addresses requested by the other network devices when IGMP mode is on. This is a read-only value.

RIPv2 Mode – This option specifies whether RIPv2 Routing Information Protocol is used or not. Possible options are **On** and **Off**. When *On*, other network devices can request specific Unicast IP Addresses to be filtered.

Unicast Network/Mask – This is where you enter the specified ranges of the Unicast IP Addresses in conjunction with subnet masks. These unicast IP addresses are forwarded to the specified gateway addresses. Select **Add** and enter any new addresses you require.

Decode Menu

This menu lists all of the software decoder types and allows you to enable/disable them individually.




Decoder – This is the decoder that any change to the enabled setting will affect. Possible options are **DATA**, **MPE1-5**, **SUBTITLE**, **VIDEO**, **AUDIO1-4** and **VBI**.

Enabled – When viewing, this is the state of the currently displayed Decoder (Select the Decoder option and use the UP/DOWN arrow keys to scroll through them). When selected, this option allows you to change the state of the currently displayed decoder. Possible options are **Yes** and **No**.

PSI Menus

This menu allows you to configure how the decoder processes the PSI (Program Specific Information) tables and gathers its channel lists. The parameters on this menu are the most important with regard to your type of network application and the settings determine which search parameters are used to find the signal you want install the decoder to receive.



Stream Tuning Mode – This determines the mode to use to build channel lists from allowed service lists. Possible values are **Auto**, **Basic**, **Fixed Pid**, and **CUSTOM**. The default is **Basic**.

CA - The type of CA (Conditional Access) will determine which programs can be viewed via the decoder. Either **STD** (standard) for PowerVu signal or **Open** conditional access for free-to-air (i.e., in-the-clear signals) can be selected.

Input Sel - This sets the parameters the decoder uses for signal switching. You can select either **RF Map** or **Preset**. **RF Map** uses the orbital positioning settings to find and lock onto a signal, while it can be ignored for **Preset**.

Refer to the table below and select your settings based of your application.

Menu	Parameter	Free-to-airSettings
PSI	Stream Tuning Mode	Auto
PSI	CA	Open
PSI	Input Select	Preset

Services List Mode – All of the options on this menu allow you to select which tables to use to obtain tuning and channel lists. The values set on this menu **ONLY** apply when the **Stream Tuning Mode** is set to *Custom*. Possible options for this mode are **Allow Deg'd Install** or **Rigorous Install**. **Rigorous Install** means all the default settings must be present in the received signal. **Allow Deg'd Install** means only the table parameters present in the received signal will be used to install the decoder. The default is **Rigorous Install**.

The following table shows some possible configurations for the allowed service lists:

Allowed Service Lists	Auto	Basic	Custom	Fixed PID
BAT	N	N	N	N
NIT	N	N	N	
SDT	N	N	N	
PAT	Y	Y	Y	N
Frequency Tuning	NIT	NIT	Preset	Preset

Edit Menu

This menu is where you setup your fixed PID properties (when Stream Tuning Mode is Fixed PID). Select the channel to setup and then Select **Edit**.

Ch – This is the channel number, in the range from 0-15. Use the up and down arrow keys to select the channel to edit/view. Any changes made will be applied to the displayed channel only.

PID – While viewing, this is one of the PID numbers currently assigned to this channel, in the range of from **0000** to **8191**. While editing, this is the PID number to Add/Edit/Del.

Type – This is the type of PID (aud1, data, etc.) being set up.

Note: The PCR PID must be the first one setup.


Map – This is the PID type the actual PID type is mapped to.

Add – Select this option to Add a PID to a channel.

Del – Select this option to Delete the currently displayed PID.

Subtitles Menus

This menu allows you to configure what type of subtitling (i.e., DVB or Imitext) is displayed by the decoder, and how the decoder displays subtitling on the TV system.



Op Mode – This determines the mode to use to display the program subtitles. Possible options are **Off**, **On**, **DVB**, and **Imitext**. The following table describes each of the available options.

Op Mode Selection	Description
Off	No subtitles are displayed.
On	Functions as an “Auto” setting. DVB subtitles are displayed when only DVB subtitles are transmitted on the channel, and likewise, Imitext subtitles are displayed when only Imitext subtitles are transmitted on the channel. When both DVB and Imitext subtitles are available on the same channel, only DVB subtitles will be displayed.
DVB	Displays only DVB titles. For example, if DVB is selected, but both DVB and Imitext titles are being transmitted on the same channel, only DVB subtitles will be displayed.
Imitext	Displays only Imitext subtitles. For example, if Imitext is selected, but both DVB and Imitext titles are being transmitted on the same channel, only Imitext subtitles will be displayed.

Select Language By - This is used to select the language type to display the subtitles. Possible options are **Language List**, **Language Entry**, and **PMT Order**. The default setting is **Language List**. **Language Entry** and **Language PMT Order** are more applicable for advanced applications. The following table describes each of the available options and how to set them.

Select Language By Option	Description
Language List	Each subtitling PID can contain multiple languages. Use this setting to select the language from the Language List by toggling through the available selections. If Language List is selected, PMT Order and Entry fields are not used.
Language Entry	Use this setting with Entry to directly enter the language code when the language you want is not in the list. In this case enter the three-character code provided by your uplink service provider under Entry using the numeric keypad (e.g., eng for English).
Language PMT Order	Use this setting to select one of up to eight languages as assigned in the PMT for the tuned channel on the decoder. Toggle through the PMT Order to select the correct language within the order (i.e., First to Eighth), available from your uplink service provider.

Select Type Field - for future use.

ForeGnd - This is used to set the colour of Imitext subtitles only. The available options are **Auto**, **Yellow** and **White**. **Auto** displays text in the colour transmitted by the subtitling equipment. **Yellow** and **White** override the colour set by the uplink, and display text in the selected colour.

BackGnd - This option sets the background on which Imitext subtitles are displayed. Possible options are **Auto**, **Shadow**, **Opaque**, **Semi** and **None**. The following table identifies the affect each setting has on the displayed subtitle text.

BackGnd Option	Description
Auto	Follows (i.e., same as) the uplink subtitling equipment setting.
Shadow	Applies an outline to the right side of each text character. No background box is applied to subtitles, i.e., text is visible directly on top of video.
Opaque	Applies a black box to each text character.
Semi	Applies a semi-transparent box to subtitle text.
None	No shadow or outline is applied to subtitle text.

About Menu

The User Address (UA) is required in order to request program authorization from the uplink. This menu shows basic software version and hardware information useful when requesting customer support from Scientific-Atlanta.

◆Product ID: D9010 Tracking ID: 250102000147		◆
◆Boot App 1.01	Safe App 1.04	Current App 1.04
		0 ◀▶
◆IRD User Address 000-401-3476-5	ISE Version 2.50(2)	
		◆
◆OSE User Address Not Installed	OSE Version 0.00(0)	
		◆
◆H/W Info: Board: PRM RevC FPGA: Spartan2 XC2S50E 1.02		
◆		
◆H/W Info: CPLD: 1.00 PIC Version: 1.04		
◆		
◆Number of RF Inputs: 0 ASI In: Yes Number of Audios: 2 ASI Out: Yes		
◆		
◆Ethernet: Yes SDI: No Enhanced Ethernet: No		
◆		

Boot App – Receiver Boot Application version number.

Safe App – Factory loaded application version number.

Current App – Currently running application version number.

IRD User Address – The current User Address (UA).

ISE Version – This is the Internal Security Element (ISE) version number. The ISE software controls the operation of all internal data security functions.

OSE User Address – Smart Card User Address (UA).

OSE Version – This is the Outside Security Element (OSE) version number. The OSE software is associated with the Smart Card security device.

Board – This is the Board type and revision.


FPGA – This is the Field Programmable Gate Array (FPGA) type and version number.

CPLD – This is the Complex Programmable Logic Device (CPLD) version number.

PIC Version – This is the Programmable Interrupt Controller (PIC) version number.


Diagnostics Menu

This menu allows the user to perform various diagnostic functions and set the Alarm and Warning conditions monitor on the decoder. This is primarily for use by Scientific-Atlanta personnel during servicing



Alarms/Warnings Menu

The first two menus in this branch display the current Alarms and Warnings, respectively. You can scroll through multiple Alarms/Warnings by pressing select and using the UP and DOWN arrow keys.



The remainder of this menu allows you to set which alarms and warnings trigger notices in your decoder. You can also clear alarms and warnings here.

Clear System Alarms – Selecting this option clears any existing Alarms (flashing Alarm LED). The function is instantaneous, but you can tell when it is successful because the Alarm light will go out (assuming that there's no existing Warnings).

Clear System Warnings – Selecting this option clears any existing Warnings (solid Alarm LED). The function is instantaneous, but you can tell when it is successful because the Alarm light will go out (assuming there's no existing Alarms).

System Alarms Menu – This menu allows the user to set the alarm conditions to monitor.

System Warnings Menu – This menu allows the user to set the warning conditions to monitor.

Note: Since Alarms are more serious than Warnings, when both Alarms and Warnings exist, the Alarm LED will be flashing.

History Menu

This menu allows you to view system event messages. Press select to view the messages using the UP/DOWN arrow keys.

Logs Menu

This menu allows you to view system log messages. Press select to view the messages using the UP/DOWN arrow keys.

PSI Menu

FreqPlan Sub-Menu

The Frequency Plan sub-menu does not apply to the D9010 decoder.

Channels Sub-Menu

This is the Virtual Channel sub-menu. You cannot make any changes here, but you can view the available channels and their settings. The following is a list of the expanded abbreviations:

VC – Virtual Channel

TxID – Transport ID*

ONID – Original Network ID

PMT – Program Map Table

ECM – Entitlement Control Message

PCR – Program Clock Reference

Tables Sub-Menu

This is the Tables Received sub-menu. You cannot make any changes here, but you can view the PSI tables received and their settings. The following is a list of the expanded abbreviations:

Type – Table Type (i.e., NIT, PMT, etc.)

Tbl-ID – MPEG/DVB Table ID

ID – Identification Number

Version – Table Version number

Status – Reception status

Disaster Recovery Menu

The Disaster Recovery Menu does not apply to the D9010 decoder. It is only applicable to decoders with RF input ports.

SNMP Control

The decoder can be controlled via a PC using the Ethernet port. You can either purchase a ROSA Network Management System and interface drivers, or obtain a MIB (Management Information Base) specification to create a PowerVu D9850 program decoder control system. The MIB specification can be obtained from your closest Scientific-Atlanta customer support center detailing the features and operating parameters that can be controlled remotely.

It should be noted that when the decoder is controlled via the Ethernet port, either SNMP or Web browser, that the front panel keypad cannot be used to control the unit simultaneously.


Web Browser Control

The decoder provides a web page generation facility, allowing easy control and monitoring via a Ethernet connection and Web Browser, such as Microsoft's Internet Browser. When the decoder is connected to a network, users may access and control the decoder from any location which has access to the network.


It should be noted that when the decoder is controlled via the Ethernet port, either SNMP or Web browser, that the front panel menu keys cannot be used to control the unit simultaneously.

Follow the steps below to set the IP address of the decoder for network communication.


1. Obtain an IP address from your IT department that does not conflict with any other communications devices in your network.
2. Enter the new IP address in the IP Address, (Subnet) Mask and Gateway field on the IP submenu using the decoder front panel keypad. Enter and save the value in each field.
3. Go to the **Admin** Menu and "Reboot" the decoder to activate the new network setting. After you press **Select**, you are prompted on whether you really want to reboot. Select **Continue** to reboot the decoder.
4. Start up your web browser and enter the decoder IP address similar to that shown on the screen below.




5. On the Network Password screen, enter the User Name and Password as follows:
 User Name - user (all lowercase letters)
 Password - USER (all uppercase letters)
 Select OK



6. The following web page (main menu) displays if the decoder is online.





To view/change the decoder's configuration, click on one of the menus on the left of the web page to display the available submenus. Most of the options and configurable features accessible from the decoder's front LCD panel are available through this interface, though the grouping and individual menu names may vary.