

PowerVu *Plus*<sup>™</sup> *Professional Receiver*  
*Model D9224*

**Please read this entire guide**  
**Veillez lire entièrement ce guide**  
**Bitte das gesamte Handbuch durchlesen**  
**Sírvase leer completamente la presente guía**  
**Si prega di leggere completamente questa guida**

---

**Important**

Please read this entire guide before you install or operate this product. Give particular attention to all safety statements.

**Important**

Veillez lire entièrement ce guide avant d'installer ou d'utiliser ce produit. Prêtez une attention particulière à toutes les règles de sécurité.

**Zu beachten**

Bitte lesen Sie vor Aufstellen oder Inbetriebnahme des Gerätes dieses Handbuch in seiner Gesamtheit durch. Achten Sie dabei besonders auf die Sicherheitshinweise.

**Importante**

Sírvase leer la presente guía antes de instalar o emplear este producto. Preste especial atención a todos los avisos de seguridad.

**Importante**

Prima di installare o usare questo prodotto si prega di leggere completamente questa guida, facendo particolare attenzione a tutte le dichiarazioni di sicurezza.

---

**PowerVu *Plus*<sup>™</sup> Professional Receiver**  
**Model D9224**  
**Installation and Operation Guide**

---

## Notices

### Trademark Acknowledgments

Scientific-Atlanta, the Scientific-Atlanta Logo, and PowerVu *Plus* are trademarks of Scientific-Atlanta, Inc.

*All other brand and product names are trademarks or registered trademarks of their respective owners.*

### Disclaimer

Scientific-Atlanta, Inc. assumes no responsibility for errors or omissions that may appear in this publication. Scientific-Atlanta reserves the right to change this publication at any time without notice.

### Copyright

©1999-2000 Scientific-Atlanta, Inc. All rights reserved. Printed in Canada.

Information in this publication is subject to change without notice. No part of this publication may be reproduced or transmitted in any form, by photocopy, microfilm, xerography, or any other means, or incorporated into any information retrieval system, electronic or mechanical, for any purpose, without the express permission of Scientific-Atlanta, Inc.

---

## Safety precautions

---

### Protect yourself from electric shock and your system from damage!

- This product complies with international safety and design standards. Observe all safety procedures that appear throughout this guide, and the safety symbols that are affixed to this product.
  - If circumstances impair the safe operation of this product, stop operation and secure this product against further operation.
- 

### Avoid personal injury and product damage! Do not proceed beyond any symbol until you fully understand the indicated conditions!



You will find this symbol in the literature that accompanies this product. It indicates important operating or maintenance instructions.



You may find this symbol in the literature that accompanies this product. It indicates a live terminal; the symbol pointing to the terminal device.



You may find this symbol in the literature that accompanies this product. It indicates a protective earth terminal.



You may find this symbol in the literature that accompanies this product. It indicates excessive or dangerous heat.

---

## Power

- Important! If this product is a Class I product, you must earth this product.
  - This product plugs into a socket-outlet. The socket-outlet must be near this product, and must be easily accessible.
  - Connect this product only to the power source that is indicated on the back panel of this product.
  - If this product does not have a mains power switch, the power cord serves this purpose.
- 

*continued on next page*

## Safety precautions (continued)

---

### Enclosure

- Do not allow moisture to enter this product.
- Do not open the enclosure of this product unless otherwise specified.
- Do not push objects through openings in the enclosure of this product.

---

### Cables

- Always disconnect all power cables before you service this product.
- Always pull on the plug or the connector to disconnect a cable. Never pull on the cable itself.
- Do not walk on or place stress on cables or plugs.

---

### Fuse

- Always use a fuse that has the correct type and rating. The correct type and rating is indicated on this product.
- Always disconnect all power cables before you change a fuse.

---

### Factory service

- Refer service only to service personnel who are authorized by the factory.

## Règles de sécurité

---

**Protégez-vous des risques d'électrocution et protégez votre système contre les endommagements éventuels.**

- Ce produit respecte les standards internationaux de sécurité et de conception. Veuillez observer toutes les procédures de sécurité qui apparaissent dans ce guide, ainsi que les symboles de sécurité qui figurent sur le produit.
- Si, du fait des circonstances, ce produit cesse de fonctionner normalement, cessez de l'utiliser et empêchez-en l'utilisation future.

---

**Évitez le risque de blessures et de dommages aux produits! Ne procédez à aucune tâche tant que vous n'aurez pas entièrement assimilé les conditions indiquées par un symbole!**



Ce symbole figure dans la documentation accompagnant ce produit. Il indique d'importantes instructions de fonctionnement ou d'entretien.



Ce symbole peut être attaché à ce produit. Il indique une borne sous tension; la direction indique la borne.



Ce symbole peut être attaché à ce produit. Il indique une borne de terre de protection.



Ce symbole peut être attaché à ce produit. Il indique une température excessive ou dangereuse.

---

### Alimentation

- Important! Si ce produit fait partie de la classe I, vous devez le mettre à la terre.
- Ce produit se branche dans une prise murale. Cette dernière doit être placée à proximité du produit et doit être facilement accessible.
- Ne branchez ce produit qu'à la source d'alimentation indiquée sur son panneau arrière.
- Si ce produit n'a pas d'interrupteur d'alimentation générale, le cordon d'alimentation remplit ce rôle.

---

*suite page suivant*

## Règles de sécurité (suite)

---

### Enceinte

- Ne laissez pas l'humidité pénétrer dans ce produit.
- N'ouvrez pas l'enceinte de ce produit, sauf instructions contraires.
- Ne forcez pas d'objets dans les ouvertures du boîtier.

---

### Câbles

- Débranchez toujours tous les cordons d'alimentation avant de réparer ce produit.
- Tirez toujours sur la prise ou le connecteur pour débrancher un câble, Ne tirez jamais directement sur le câble.
- Ne marchez pas sur les câbles ou les prises et n'y exercez aucune pression.

---

### Fusibles

- Utilisez toujours un fusible de type et de valeur corrects, indiqués sur le produit.
- Débranchez toujours tous les cordons d'alimentation avant de changer un fusible.

---

### Réparations effectuées à l'usine

- Ne confiez les travaux de réparations qu'au personnel autorisé par l'usine.



## Sicherheitsvorkehrungen

---

### Schützen Sie sich gegen elektrischen Schlag, und Ihr Gerät gegen Beschädigung!

- Dieses Gerät entspricht internationalen Sicherheits- und Ausführungsnormen. Beachten Sie alle in diesem Handbuch enthaltenen Sicherheitshinweise sowie die am Gerät angebrachten Warnzeichen.
- Sollten örtliche Umstände den sicheren Betrieb dieses Gerätes beeinträchtigen, schalten Sie es ab und sichern es gegen weitere Benutzung.

---

**Vermeiden Sie Verletzungen sowie Beschädigung des Gerätes! Wenn Sie zu einem der folgenden Warnzeichen gelangen, nicht weiterarbeiten, bis Sie seine Bedeutung voll verstanden haben!**



Dieses Symbol erscheint auf dem Gerät und/oder in der ihm beiliegenden Literatur. Es bedeutet wichtige, zu beachtende Betriebs- oder Wartungsanweisungen.



Wenn dieses Zeichen am Gerät angebracht ist, warnt es vor einer spannungsführenden Stelle.



Dieses Symbol erscheint auf dem Gerät und/oder in der ihm beiliegenden Literatur. Es bedeutet wichtige, zu beachtende Betriebs- oder Wartungsanweisungen.



Wenn dieses Zeichen am Gerät angebracht ist, warnt es vor heißen Stellen, die zu Verbrennungen führen können.

---

### Netzspannung

- Wichtig! Wenn dieses Gerät ein Produkt der Schutzklasse I ist, muß es geerdet werden
- Das Gerät ist an einer Steckdose anzuschließen. Diese muß sich leicht zugänglich in unmittelbarer Nähe des Gerätes befinden.
- Die Netzversorgung muß den auf der Rückwand des Gerätes angegebenen Werten entsprechen.
- Falls sich kein Hauptschalter am Gerät befindet, dient das Netzkabel diesem Zweck.

---

*Fortsetzung nächste Seite*

## **Sicherheitsvorkehrungen (fortsetzung)**

---

### **Gehäuse**

- Das Innere des Gerätes ist vor Feuchtigkeit zu schützen.
- Das Gehäuse ist nicht zu öffnen.
- Niemals einen Gegenstand durch die Gehäuseöffnungen einführen!

---

### **Kabel**

- Vor jeglicher Wartung des Gerätes sind alle Kabel zu entfernen.
- Hierzu grundsätzlich am Stecker oder Verbindungsstück und niemals am Kabel selber ziehen.
- Nicht auf die Kabel oder Stecker treten oder diese einer Zugbelastung aussetzen.

---

### **Sicherung**

- Grundsätzlich eine Sicherung der richtigen Ausführung und Leistung verwenden. Diese sind am Gerät angegeben.
- Vor Auswechseln der Sicherung stets alle Netzkabel entfernen.

---

### **Hersteller-Wartung**

- Wartungsarbeiten sind nur durch vom Hersteller autorisierte Techniker vorzunehmen.

## Precauciones de seguridad

---

### ¡Protéjase contra la electrocución y proteja su sistema contra los daños!

- Este producto cumple con los criterios internacionales de seguridad y diseño. Observe todas los procedimientos de seguridad que aparecen en esta guía, y los símbolos de seguridad adheridos a este producto.
  - Si las circunstancias impiden la operación segura de este producto, suspenda la operación y asegure este producto para que no siga funcionando.
- 

### ¡Evite lastimarse y evite dañar el producto! No avance más allá de cualquier símbolo hasta comprender completamente las condiciones indicadas!



Encontrará este símbolo en el impreso que acompaña a este producto. Este símbolo indica instrucciones importantes de funcionamiento o mantenimiento.



Es posible que este símbolo esté pegado al producto. Este símbolo indica un terminal vivo, la flecha apunta hacia el aparato terminal



Podría encontrar este símbolo pegado al producto. Este símbolo indica un terminal de protección de tierra.



Podría encontrar este símbolo pegado al producto. Este símbolo indica calor excesivo o peligroso.

---

## Power

- Importante! Es necesario poner el producto a tierra si es un producto de Clase I.
  - Este producto se conecta a un enchufe. El enchufe necesita estar cerca del producto y ser fácilmente accesible.
  - Conecte este producto únicamente a la fuente de suministro eléctrico indicada en el panel posterior del producto.
  - Si el producto no tiene interruptor para la línea principal, utilice el cordón toma de corriente para este propósito.
- 

*Sigue en la próxima página*

## Precauciones de seguridad (continuación)

---

### Cubierta

- No permita que la humedad penetre en este producto.
- No abra la cubierta del producto a menos que se indique lo contrario.
- No introduzca objetos a través de las aberturas de la cubierta del producto.

---

### Cables

- Desconecte siempre todos los cables eléctricos antes de revisar o reparar el producto.
- Tire siempre del enchufe o del conector para desconectar un cable. Nunca tire del cable mismo.
- No camine ni aplique presión sobre los cables o enchufes

---

### Fusible

- Use siempre un fusible del tipo y clasificación correctos. El tipo y la clasificación correctos están indicados en el producto.
- Desconecte siempre todos los cables eléctricos antes de cambiar un fusible.

---

### Revisión y reparación de fábrica

- Solo personal aprobado por la fábrica puede darle servicio al producto.

## Precauzioni di sicurezza

---

### **Protegetevi da scosse elettriche e proteggete il vostro sistema da possibili danni!**

- Questo prodotto soddisfa le norme internazionali per la sicurezza ed il design. Seguite tutte le procedure di sicurezza contenute in questa guida e i simboli di sicurezza applicati al prodotto.
  - Se circostanze avverse compromettono la sicurezza d'uso di questo prodotto, interrompetene l'uso e assicuratevi che il prodotto non venga più utilizzato.
- 

### **Evitare infortuni alla persona e danni al prodotto! Non procedere oltre a qualunque simbolo fino a quando non si siano comprese pienamente le condizioni indicate!**



Questo simbolo, che appare nella letteratura di accompagnamento del prodotto, indica importanti istruzioni d'uso e di manutenzione.



Sul prodotto potete vedere questo simbolo che indica un dispositivo terminale sotto tensione; la freccia punta verso il dispositivo.



Potrete trovare il presente simbolo applicato a questo prodotto. Questo simbolo indica un terminale protettivo di messa a terra.



Potrete trovare il presente simbolo attaccato a questo prodotto. Questo simbolo indica un calore eccessivo o pericoloso.

---

## Alimentazione

- Importante! Se questo prodotto è di Classe I, va messo a terra.
  - Questo prodotto si inserisce in una presa di corrente. La presa di corrente deve essere in prossimità del prodotto, e deve essere facilmente accessibile.
  - Collegare questo prodotto solamente alla fonte di alimentazione indicata sul pannello posteriore di questo prodotto.
  - Se questo prodotto non è dotato di un interruttore principale, il cavo di alimentazione funge a questo scopo.
- 

*Continua alla pagina seguente*

## Precauzioni di sicurezza (continua)

---

### Chiusura

- Proteggete da umidità questo prodotto.
- Non aprire la chiusura di questo prodotto a meno che non sia specificato diversamente.
- Non inserire oggetti attraverso le fessure della chiusura.

---

### Cavi

- Staccare sempre tutti i cavi di alimentazione prima di svolgere l'assistenza tecnica al prodotto.
- Per scollegare un cavo tirate la spina o il connettore, non tirare mai il cavo stesso.
- Non calpestare o sottoporre a sollecitazioni i cavi o le prese.

---


### Fusibile

- Utilizzare sempre un fusibile che sia di tipo e potenza nominale corretta. Il tipo e la potenza nominale corretta sono indicati su questo prodotto.
- Staccare sempre tutti i cavi di alimentazione prima di sostituire un fusibile.

---

### Riparazioni di fabbrica

- Per le riparazioni contattate solamente personale tecnico autorizzato dalla fabbrica.



## IMPORTANT SAFEGUARDS

1. **Read Instructions:** All the safety and operating instructions should be read before this product is operated.
2. **Retain Instructions:** The safety and operating instructions should be retained for future reference.
3. **Heed Warnings:** All warnings on the product and in the operating instructions should be adhered to.
4. **Follow Instructions:** All operating and use instructions should be followed.
5. **Cleaning:** Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
6. **Attachments:** Do not use attachments not recommended by Scientific-Atlanta as they may cause hazards.
7. **Water and Moisture:** Do not use this product near water - for example, near a bath tub, wash bowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool, and the like.

PORTABLE CART WARNING




8. **Accessories:** Do not place this product on an unstable cart, stand, bracket, or table. The product may fall causing serious injury to a child or adult, and serious damage to the product. Use only with a cart, stand, bracket, or table recommended by Scientific-Atlanta. Any mounting of the product should follow the instructions, and should use a mounting accessory recommended by Scientific-Atlanta. An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.
9. **Ventilation:** Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product, and to protect it from overheating. These openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the instructions have been adhered to.
10. **Heat:** This product should be located away from heat sources such as radiators, heat registers, stoves or other products (including amplifiers) that radiate heat.
11. **Power Sources:** This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply in your home or business, consult your appliance dealer or local power company. For products intended to operate from battery power, or other sources, refer to the operating instructions supplied with the product.  
For applications other than in North America, a suitable attachment plug adapter should be used for connection to the power source. For determining the appropriate attachment adapter type, refer to qualified technical personnel.
12. **Polarization:** This product may be equipped with a polarized alternating current line plug (i.e., a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.
13. **Power Cord Protection:** Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the appliance.
14. **Lightning:** For added protection for this product during a lightning storm or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power-line surges.



15. **Power Lines:** An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.
16. **Overloading:** Do not overload wall outlets, extension cords or integral convenience receptacles, as this can result in a risk of fire or electric shock.
17. **Object and Liquid Entry:** Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.
18. **Servicing:** Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.
19. **Damage Requiring Service:** Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:
  - (a) When the power-supply cord or plug is damaged.
  - (b) If liquid has been spilled, or objects have fallen into the product.
  - (c) If the product has been exposed to rain or water.
  - (d) If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation.
  - (e) If the product has been dropped or damaged in any way.
  - (f) The product exhibits a distinct change in performance.
20. **Replacement Parts:** When replacement parts are required, be sure the service technician uses replacement parts specified by Scientific-Atlanta, or parts having the same operating characteristics as the original parts. Unauthorized part substitutions made may result in fire, electric shock or other hazards.
21. **Safety Check:** Upon completion of any service or repairs made to this product, ask the service technician to perform safety checks to determine that the product is in safe operating condition.

22. Outdoor Antenna Grounding: If an outside antenna or cable system is connected to this product, ensure that the antenna or cable system is properly grounded to provide protection against voltage surges and built-up static charges. Appropriate sections of the National Electrical Code (NFPA 1990) provide information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, connection to grounding electrodes, and requirements for the grounding electrode (see Figure 1).



TO CATV SYSTEM INSTALLER

This reminder is provided to call the CATV system installer's attention to Article 820-40 of the National Electrical Code (NEC) that provides guidelines for proper grounding, and in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of entry as practical.

**Figure 1. Outdoor antenna grounding**

## Important notice for Class I apparatus

---

### Important

This notice is applicable only if this apparatus has a three-pin power plug.

---

### Warning

This apparatus must be earthed.

---

### Mains lead colours

The following is applicable to Class I apparatus supplied with a flexible cord having cores coloured green-and-yellow, brown, and blue.

**Important!** The wires in this mains lead are coloured in accordance with the following code.

Colour	Mains lead wire
Green and yellow	Earth
Blue	Neutral
Brown	Live

---

### Connecting the mains lead

As the colours of the wires in the mains lead of this apparatus may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows.

IF the wire is coloured...	THEN connect it to...
Blue	...the Neutral terminal Note: The Neutral terminal is typically marked N or coloured black.
Brown	...the Live terminal Note: The Live terminal is typically marked L or coloured red.
Green and yellow	...the Earth terminal Note: The Earth terminal is typically marked E (or marked with the safety earth symbol, or coloured green and yellow).

---

## Warranty terms and conditions

All products manufactured by Scientific-Atlanta Canada Inc., hereinafter called S-A, are warranted to be free from defects in material and workmanship, and to conform to currently published specifications.

Scientific-Atlanta Canada extends warranty coverage to the original purchaser only. Products must be purchased from a recognized Scientific-Atlanta dealer or distributor.

### Duration of warranty

Scientific-Atlanta Canada will repair, replace or correct any product or part thereof that is defective by reason of faulty material and/or improper workmanship, or by any non-conformance to published product specifications for a period of one (1) year.

Written notice of any defects must be received by Scientific-Atlanta within the warranty period. No extension of warranty will be granted by Scientific-Atlanta without the existence of a valid service contract between the customer and an authorized Scientific-Atlanta repair center.

### Limits of liability

Scientific-Atlanta's liability is limited to servicing, adjusting or correcting any product returned to the factory under warranty, including the replacement of defective components.

Equipment repairs are billed at normal rates for any fault caused by improper installation, maintenance or use, or if the product is subject to abnormal operating conditions.

### Disclaimer

Scientific-Atlanta makes no representations that its PowerVu product line is fully compatible with similarly represented equipment from other vendors due to the wide range of implementation possibilities of the applicable standards.

Scientific-Atlanta disclaims all statutory and implied warranties such as warranties of merchantability and fitness for purpose. In no event shall Scientific-Atlanta be liable for incidental, indirect or consequential damages, regardless of being informed about the possibility of such damages, and in no event shall Scientific-Atlanta's liability exceed the purchase price of the product.



**IMPORTANT!** All PowerVu equipment is shipped from the factory pre-configured. Opening the chassis for diagnostic inspection may only be performed by authorized Scientific-Atlanta technical support personnel.

## Customer responsibility

When returning equipment, the customer is solely responsible for equipment packaging and transportation costs both to and from the factory.

At the customer's request, Scientific-Atlanta will make reasonable efforts to provide warranty service at the customer's premises, provided that the customer pays current field service rates plus direct travel and accommodation expenses.

## In case of a fault

If an equipment fault develops, perform following steps. For complete information regarding product return, see "Appendix A, Customer Support Information".

1.	<p>(a) Notify Scientific-Atlanta of the problem immediately, providing the model number and serial number of the equipment plus details of the problem.</p> <p>(b) On receipt of this information, service information and shipping instructions will be provided.</p>
2.	<p>(a) On receipt of instructions, return the product by prepaid freight.</p> <p>(b) If the product or fault is not covered under warranty, Scientific-Atlanta will provide an estimate of repair charges in advance of any work performed.</p>



---

# Table of Contents

**Chapter 1 Introduction .....1-1**

**Chapter 2 Installation .....2-1**

**Chapter 3 Operation .....3-1**

**Chapter 4 Maintenance.....4-1**

**Appendix A Customer Support Information..... A-1**

**Appendix B Technical Information..... B-1**

**Appendix C Troubleshooting..... C-1**

**Appendix D Serial Remote Control Command Set..... D-1**

**Appendix E Product Identification ..... E-1**

**Appendix F Application Notes .....F-1**

**Appendix G Reference..... G-1**





---

# Chapter 1 Introduction

## About this guide

This guide provides installation and operating instructions, plus user servicing and maintenance procedures for the PowerVu *Plus*™ Model D9224 Professional Receiver. Service problems not identified in this manual should only be performed by qualified service technicians. This is not a complete system operation guide.

## Professional Receiver

Welcome to the world of PowerVu *Plus* direct-broadcast satellite services. Your Professional Receiver provides the ultimate in digital-quality video, audio and data services. Designed using state-of-the-art MPEG-2 digital compression and broadcast satellite technology, your PowerVu *Plus* Model D9224 Professional Receiver is quality-built for trouble-free operation, and comes equipped with many built-in features and capabilities. Depending on the country or jurisdiction where it is used, your Professional Receiver may be slightly different from other models.

## Contents

**Main features ..... 1-2**

## Main features

- ❑ MPEG-2/DVB digital video and audio signals in 525-line or 625-line systems
- ❑ Variable symbol rates from 3.0 to 30.8 Msymbols/s
- ❑ Receives signals for single or multiple-channel-per-carrier operation
- ❑ Smart Card receptacle for field-upgradable security
- ❑ Selectable Viterbi Forward Error Correction rates of  $\frac{1}{2}$ ,  $\frac{2}{3}$ ,  $\frac{3}{4}$ ,  $\frac{5}{6}$  or  $\frac{7}{8}$  (installer-selectable or downloadable over satellite)
- ❑ Two pairs of balanced audio outputs with detachable connectors for easy installation
- ❑ Non-encrypted utility data output at rates up to 38.4 kb/s
- ❑ Separate text and video output, allowing the operator to access diagnostic menus without disrupting the decompressed video signal output
- ❑ Supports VBI reinsertion of NABST, AMOL I AND II (Nielsen), and WST data
- ❑ Supports reinsertion of VBI lines 10 to 22 in NTSC (fields 1 and 2), or PAL lines 7 to 22 (fields 1 and 2)
- ❑ Eight (8) programmable output switches and Form C contact closures for control of external devices such as VCRs and transmitters
- ❑ Downloadable software capability via PowerVu Command Centre providing site upgrade-ability
- ❑ Remote serial interface for receiver monitoring, diagnostics and tuning control
- ❑ DVB-ASI transport output
- ❑ Digital video output and digital audio output serial interface
- ❑ SWIF transport input and output
- ❑ Four L-Band Inputs
- ❑ Basic Interoperable Scrambling System (BISS) Fixed Key descrambling

# Chapter 2 Installation

## About this chapter

This chapter provides installation and preliminary setup instructions for the Power Vu Model D9224 Professional Receiver. Service problems not identified in this manual should only be performed by qualified service technicians. This is not a complete system operation guide.

## Contents

<b>Introduction .....</b>	<b>2-2</b>
<b>Unpacking and inspection .....</b>	<b>2-2</b>
<b>Rear panel connections .....</b>	<b>2-3</b>
<b>Equipment installation and setup.....</b>	<b>2-5</b>
<b>Receiver equipment interconnection.....</b>	<b>2-5</b>
<b>Optional connections .....</b>	<b>2-8</b>
EXPANSION PORT .....	2-8
BALANCED AUDIO output (terminal blocks and controls).....	2-9
AES/EBU digital audio output ports.....	2-9
DIGITAL VIDEO output port.....	2-10
Digital Audio/Video output .....	2-10
AUTH relay terminals .....	2-12
RC8 relay terminals .....	2-12
SWIF Input/Output ports.....	2-12
System interconnections.....	2-16

# Introduction

---

## Unpacking and inspection

When removing the PowerVu *Plus* Model D9224 Professional Receiver protective packaging, inspect the shipping carton for damage. If any signs of damage are evident, notify the carrier immediately before accepting the consignment. Contact your local S-A representative if any signs of damage or defects are discovered.



**WARNING!** The PowerVu *Plus*™ Model D9224 Professional Receiver is designed for rack-mount applications. Install the product in a dry, well-ventilated location to allow adequate air circulation. Ensure that sufficient clearance is maintained at the chassis rear panel for connecting input/output and AC power cables.

Do not obstruct the chassis (top) ventilation holes. Prolonged operation with reduced ventilation may result in equipment damage.

Retain the packaging in the event of return, or for equipment storage. Scientific-Atlanta will not be held liable for equipment damage plus any shipping and/or repair charges resulting from inadequate packing, or use of packing materials that do not meet S-A specifications.

## Rear panel connections

All input and output signal connections are made at the receiver rear panel. The accompanying table summarizes all standard and optional rear panel I/O connections. Figure 2-1 shows the rear panel view of the PowerVu *Plus* Model D9224 Receiver.




Figure 2-1. Rear panel view

Note that some rear panel connections are optional. Not all factory options are available with any single model. For more information about receiver options, see Appendix B. Table 2-1 lists receiver rear panel controls and connectors and their functions.

Table 2-1. Rear panel controls and connectors

Control/Connector	Type	Function/Description
AC IN	NEMA 5-15p	<ul style="list-style-type: none"> <li>Voltage input 100-240 VAC, 47-63 Hz (<math>\pm 10\%</math>)</li> </ul>
RF IN/RF OUT	F	<ul style="list-style-type: none"> <li>Loop cable from four input switch output to tuner input.</li> </ul>
LNB POWER	Slide Switch	<ul style="list-style-type: none"> <li>Provides a +13V or +19V DC signal output at RF IN when set to ON (external LNB power source <i>not</i> used), and no output when set to OFF (external LNB power source <i>used</i>)</li> </ul>
EXPANSION PORT	DB25F	<ul style="list-style-type: none"> <li>Multi-function connector supports asynchronous utility data at rates up to 38,400 baud, eight (8) auxiliary outputs for external Serial Remote Control plus computer diagnostics and remote tuning control</li> </ul>
AGC	RCA	<ul style="list-style-type: none"> <li>Provides an output voltage proportional to the RF input signal level for antenna peaking</li> </ul>
VIDEO	BNC	<ul style="list-style-type: none"> <li>Provides video output for connection to a cable headend or external TV modulator</li> </ul>
MONITOR	BNC	<ul style="list-style-type: none"> <li>Provides video output for connection to a TV monitor</li> </ul>
SWIF OUT	ST (Fiber Optic)	<ul style="list-style-type: none"> <li>SWIF port typically used to output transport data received from a D9130 Digital Multiplexer or other/D9224 receiver (i.e., at SWIF IN)</li> </ul>
BALANCED AUDIO 1 & 2	Euro-Type (Pluggable)	<ul style="list-style-type: none"> <li>Provides two (2) Balanced Audio outputs with adjustable gain controls (see L/R below) for use with an external audio amplifier, cable headend or external modulator</li> </ul>
MO/ST	Slide Switch	<ul style="list-style-type: none"> <li>Provides (Balanced Audio) combined L+R channel monaural output when set to MO, and discrete Left and Right channel stereo output at the terminal strip when set to ST</li> </ul>
L/R (Balanced Audio)	Trim Potentiometer	<ul style="list-style-type: none"> <li>Trimpot adjustment provides balanced audio output levels (left and right audio channels) is factory set to provide 0 dBm out for 0 dBm in</li> </ul>
RELAY OUT	Euro-Type	<ul style="list-style-type: none"> <li>Two separate terminal blocks (i.e., RC8 and AUTH) provide</li> </ul>

Control/Connector	Type	Function/Description
	(Pluggable)	alarm output signals for connecting to alarm/signal detection, VCR or other/broadcast equipment for automatic equipment control (e.g., in the event of a receiver error condition due to signal loss, receiver deauthorization, or non-video service selection), where an alarm output signal connected to alarm detection equipment can switch signal output to a spare or auxiliary (standby) receiver
D1 Digital Video Output	BNC	<ul style="list-style-type: none"> <li>Provides a digital video output signal for connection to a cable headend or external TV modulator</li> </ul>
SWIF IN	ST (Fiber Optic)	<ul style="list-style-type: none"> <li>SWIF port accepts unfiltered transport data from a Model D9130 Digital multiplexer or other/ D9224 receiver (see SWIF OUT) for backhaul or monitoring applications</li> </ul>
AES/EBU Digital Audio Output	XLR-3P	<ul style="list-style-type: none"> <li>Provides digital audio output (AES/EBU format) for connection to cable headend or external audio equipment</li> </ul>
LNB 1, LNB 2, LNB 3, and LNB 4	F	<ul style="list-style-type: none"> <li>Provides four LNB signal inputs, remote LNB power for use when no external LNB power source is available plus automatic 22 kHz tone signaling for dual-band LNB operation. <i>Only the selected input can be active— the others are <b>OFF</b>.</i></li> </ul>
DVB/ASI Output	BNC	<ul style="list-style-type: none"> <li>Provides an MPEG-2 transport output when signals need to be remultiplexed and transmitted over terrestrial or satellite links.</li> </ul>

# Equipment installation and setup

The following instructions provide setup and installation details for the Model D9224 Professional Receiver in a typical commercial application. If a TV monitor connection is used, additional receiver setup is required. The pages that follow provide equipment setup information.

## Receiver equipment interconnection

The following instructions are provided for unpacking and setup of the receiver, to connect external signals and equipment and to activate the receiver.



**IMPORTANT!** Automatic 22 kHz tone signaling (LNB selection) is provided for dual-LNB operation if the receiver setup includes certain settings. The presence or absence of this signal (at the receiver RF IN connector) depends on the frequency settings used. For more information about frequency settings, see Chapter 3.

### Step 1. Unpack and mount the receiver

Remove the receiver from the shipping carton in preparation for installation. Install in a dry, well-ventilated location to allow proper air circulation in and around the unit. Always maintain sufficient clearance at the chassis rear panel for connecting input/output and AC power cables.

### Step 1. Connect the LNB RF signal cable

Connect the LNB RF signal output cable to the receiver rear panel LNB connector.

The RF loopback is securely attached to both RF IN and RF OUT as shown in Figure 2-2. Connect the LNB signal output cables to the receiver rear panel LNB 1, LNB 2, LNB 3 and LNB 4 connectors. Note that if the RF loopback cable is *not* installed, then a single LNB cable can be connected to the RF IN, thereby bypassing the four input switch.




Figure 2-2. Correct position of RF Loopback

**Step 4.** Set the LNB POWER switch

Set the LNB POWER switch to 19V, 13V/19V, or OFF. The default setting for the rear panel LNB POWER switch is OFF. When set to 19V or 13V/19V, a +13 or +19V DC signal is output at the RF IN connector (no external LNB power source available). When set to OFF, there is no DC signal output at this connector (external LNB power source used).

**Step 5.** Connect the VIDEO output signal to your cable system

Connect a RF cable from the receiver VIDEO output connector to your cable modulator VIDEO IN connector. This output signal can also be connected to a PowerVu Model D9110 Digital Video Encoder for rebroadcast, or to a TV monitor.

**Step 5.** Connect the BALANCED AUDIO output to modulator or switcher equipment

Connect a multi-conductor cable from the receiver BALANCED AUDIO 1 and 2 (Left and Right) screw terminal outputs to your cable modulator or audio switcher inputs. This output can also be connected to a PowerVu Model D9110 Digital Video Encoder for signal rebroadcast, or to a TV monitor.

**Step 6.** Connect the MONITOR output to a TV monitor

Connect a cable from the receiver MONITOR output to the input of your TV monitor, if SWIF or RF signal monitoring is required (see Figure 2-6).

**Step 7.** Connect the RELAY OUT (AUTH) output to alarm detection equipment

Connect a multi-conductor cable from the receiver RELAY OUT-AUTH screw terminal outputs to your alarm detection equipment, if required (see “terminals” for additional information).

**Step 8.** Connect the RELAY OUT (RC8) output to remote control equipment

Connect a multi-conductor cable from the receiver RELAY OUT-RC8 screw terminal outputs to your Remote Control equipment, if required (see “terminals” for additional information).

**Step 9.** Connect the EXPANSION PORT I/O cable to remote PC/Workstation or terminal equipment

Connect a multi-conductor cable from the receiver EXPANSION PORT to a remote PC/Workstation or terminal (see Appendix B for additional information).



**IMPORTANT!** Be sure that any cable you attach to the expansion port is fully shielded.

**Step 10.** Connect the receiver to AC power

Connect the socket end of the supplied AC power cable to the receiver AC cable input socket, and connect the other (plug) end of this cable to a proper AC power source.



**Step 11.** Power ON the receiver

Press the STANDBY button on the receiver front panel to activate the receiver. When AC power is first applied (AC power cord connected), the receiver starts up in STANDBY mode. This state is confirmed by the flashing character segment on the front panel alphanumeric display. When in normal operating mode, the current channel is displayed.

**NOTE:** If connecting the receiver to a TV monitor, or to a PC/workstation or terminal, see this chapter for complete setup information.



**IMPORTANT!** Following successful startup, you can change the current/default receiver settings using the front panel buttons in Alt Mode (via the Installer Channel), or using menus. When the receiver is tuned to the installer channel, "0" appears on the front panel display. If channel 0 is not displayed, press 0 to display the Installer Channel. If you are unable to display the Installer Channel, contact your dealer/reseller or local service provider, or your nearest Scientific-Atlanta Customer Service Center for assistance.

## Optional connections

The topics that follow provide details for connecting EXPANSION PORT and SWIF Input/Output port signal cables to external equipment.



**IMPORTANT!** Application-related information provided in this chapter includes setup instructions for operating the receiver using front panel buttons (i.e., Alt Mode). For complete information about how to use the front panel to operate the receiver, see Chapter 3. Additional application and product reference information is provided in Appendix F and Appendix G.

## EXPANSION PORT

The EXPANSION PORT provides support for asynchronous utility data I/O from 300 to 38,400 baud (8 bits, 1 stop bit, no parity) via a 25-pin, D type connector (i.e., 300, 1200, 2400, 4800, 9600, 19200 and 38400 baud). Eight separate remote control ports are available for remote diagnostics and receiver setup, or for controlling external user equipment. For EXPANSION PORT connector pin-out information, see Table 2-2 (see also “Appendix B”).

**Table 2-2. EXPANSION PORT connector pin-out**

Pin	Function	Pin	Function
1	Chassis Ground	15	NO CONNECTION
2	Utility Data Output	16	Remote Control output #8
3-6	NO CONNECTION	17	Remote Control output #7
7	Signal Ground	18	Remote Control output #6
8	NO CONNECTION	19	Remote Control output #5
9	NO CONNECTION	20	+5 VDC control output via 1K $\Omega$ pull-up resistor
10	Not Authorized Flag	21	+5 VDC control output via 47 $\Omega$ pull-up resistor
11	NO CONNECTION	22	Remote Control output #4
12	Serial Remote Control interface Rx data	23	Remote Control output #3
13	Serial Remote Control interface Tx data	24	Remote Control output #2
14	NO CONNECTION	25	Remote Control output #1

All EXPANSION PORT outputs are open-collector type except for Utility Data and Serial Remote Control interface Rx/Tx data I/O (pins 2, 12, and 13, respectively). Pin 2 (Utility Data) can provide Utility Data service only if the receiver is authorized and a signal authorized via PCC Control System software is being received. When this authorized service is present, pin 10 is low (open collector output).



**IMPORTANT!** Ensure that any cable you attach to the expansion port is fully shielded.

## BALANCED AUDIO output (terminal blocks and controls)

The BALANCED AUDIO terminals provide two (or four) balanced, low impedance audio sources that include independent monaural or stereo output and Left/Right channel signal level adjustment for each source. Channel Left, Right and Ground signals are available via pluggable Euro-type terminals. A screwdriver-adjustable potentiometer is available for Left and Right channel output level adjustment of  $\pm 6$  dB (maximum output of +18 dBm into a 600  $\Omega$  load). Signal level output is factory set to unity gain (i.e., 0 dBm out for 0 dBm in) for each channel. The accompanying figure shows the BALANCED AUDIO output terminals, Left/Right channel trim potentiometers and monaural/stereo selector switches. For BALANCED AUDIO terminal pin-out information, see the accompanying table. Note that the pin-out for both BALANCED AUDIO 1 and 2 terminals is identical.

Table 2-3. BALANCED AUDIO terminal pin-out

Pin	Function
1	Left Channel (+)
2	Left Channel (-)
3	Ground
4	Right Channel (+)
5	Right Channel (-)

Figure 2-3 shows the BALANCED AUDIO 1 and 2 terminal block connections plus audio level controls and monaural/stereo selector switches.




Figure 2-3. BALANCED AUDIO channel output and control

## AES/EBU digital audio output ports

Each of the two (2) AES/EBU DIGITAL AUDIO output ports (i.e., CH1 and CH 2) provide a balanced, low impedance (110  $\Omega$ ) digital audio signal. Each port carries a separate AES/EBU bitstream, with each bitstream containing two separate (i.e., Left and Right) digital audio data channels.

Figure 2-4 shows the XLR-3P (Female) output connector with pin numbers and corresponding signals. Table 2-4 provides AES/EBU connector pin-out information for connecting external digital audio interface cables between the DIGITAL AUDIO output ports and customer digital audio equipment.

Table 2-4. AES/EBU DIGITAL AUDIO output port pin-out information

Pin	Polarity
1	Ground (GND)
2	Positive (+)
3	Negative (-)




Figure 2-4. AES/EBU DIGITAL AUDIO output (XLR-3P) connector

## DIGITAL VIDEO output port

The DIGITAL VIDEO output port provides D1 (75  $\Omega$ ) video output at 525-line or 625-line rates, depending on the factory-installed option. The DIGITAL VIDEO D1 output signal can be connected to video/signal processing, distribution or other broadcast equipment having D1 signal inputs. For DIGITAL VIDEO and D1 signal specifications, see Appendix B Technical Information.

## Digital Audio/Video output

AES/EBU digital audio and D1 digital video signals originating from the Model D9224 Professional Receiver can be connected directly to customer equipment. Typically, these digital output signals can be used for the following application (see Figure 2-5).

- **Application #1:** Connecting AES/EBU digital audio and D1 digital video outputs to external VTR customer equipment

For example, AES/EBU/D1 cable connections made between the Model D9224 Professional Receiver and external customer VTR equipment are shown in the accompanying figure. To connect AES/EBU/D1 output signals for VTR recording, perform the following actions. All other cable connections required for normal receiver operation are assumed.

- Step 1.** Connect separate cables from the receiver CH1/CH2 DIGITAL AUDIO output connectors to the VTR CH1/CH2 digital audio inputs, as required. Depending on your equipment configuration, only one DIGITAL AUDIO cable connection may be necessary.
- Step 2.** Connect a cable from the receiver DIGITAL VIDEO output connector to the VTR D1 digital video input, as required.

Figure 2-5 shows a typical equipment configuration that can be used for connecting AES/EBU digital audio and D1 digital video output signals to external VTR recording equipment. The AES/EBU and D1 outputs can also be used for interfacing with the PowerVu Model D9110 Digital Video Encoder and/or with other digital signal switching equipment.




Figure 2-5. VTR connections for digital signal recording

## AUTH relay terminals

AUTH relay terminal contacts are controlled by the operating state of the receiver. Under normal operating conditions (i.e., receiver is authorized), the AUTH NC (Normally Closed) relay contact is open. If an alarm condition occurs (i.e., if AC power is disconnected or interrupted, or if loss of signal authorization takes place), the AUTH NC relay contact is closed, and the AUTH NO relay contact is opened. This NO terminal signal which indicates a change of operating state for the receiver can be used to activate remote alarm detection equipment connected between the NO and C terminals. When connecting external equipment to RELAY OUT, use the Normally Open (NO) and Common (C) terminals. For typical alarm relay connections between the receiver and other equipment, see Figure 2-8.



**IMPORTANT!** The alarm signal available at the AUTH NO relay terminal is present when AC power is disconnected or interrupted, or if loss of signal authorization occurs. This signal is identical to that found on pin 10 of the EXPANSION PORT connector.

## RC8 relay terminals

RC8 relay terminal contacts are controlled via uplink (PCC Control System software), and can also be controlled via Serial Remote Control commands when the receiver is connected to a PC/workstation or terminal. The RC8 NO (Normally Open) relay contact is controlled via the receiver front panel using the PRLY (i.e., Remote Control Port Relay) setting. The Remote Control RC8 relay provides an output signal that tracks the current Remote Control ports setting (i.e., 1 through 8 or OFF). Each Remote Control port when selected can be used to control remote broadcast or other equipment connected to the receiver EXPANSION PORT (see “EXPANSION PORT”). When connecting external equipment to RELAY OUT, use the Normally Open (NO) and Common (C) terminals.


## SWIF Input/Output ports

The SWIF signal originates from PowerVu Model D9130 Digital Multiplexer or the PowerVu Model D9110 Digital Video Encoder equipment, and can be connected directly to the Model D9224 Professional Receiver. SWIF input signal selection is controlled via the receiver Installer Menu using the Input Select function (i.e., RF or SWIF). Normally, the receiver decodes transport data information from the RF input signal. If a SWIF input signal is present at the receiver SWIF IN connector and SWIF input is selected, the receiver decodes the transport data from the SWIF input. Typically, the SWIF input signal can be used for the following applications.

□ **Application #1:** Single receiver monitoring of SWIF broadcast signal

Transport data output from a Model D9130 Digital Multiplexer or Model D9110 Digital Video Encoder can be monitored by routing the Multiplexer/Encoder SWIF output signal to the receiver SWIF input (before satellite transmission). In addition, the transport data output signal routed to the receiver RF input can be monitored (after satellite transmission) using a TV monitor.

Figure 2-6 shows a typical equipment configuration that can be used for monitoring RF or SWIF signal input. Note that for monitoring a RF input signal, the SWIF/RF input must be set to OFF.



**Figure 2-6. RF or SWIF signal monitoring**

For example, equipment cable connections required for single receiver monitoring of SWIF broadcast signal (output) from a Model D9130 Digital Multiplexer are shown in Figure 2-6. To monitor receiver SWIF input, perform the following actions.

- Step 1.** Connect a fibre optic cable from the Multiplexer/Encoder SWIF output to the receiver SWIF IN connector.
- Step 2.**
  - (a)** At the receiver rear panel, connect a video cable from the (receiver) TV monitor output connector to the TV monitor input.
  - (b)** If required, connect separate audio cables from the audio outputs for monitoring purposes.
- Step 3.** At the receiver front panel, press the **ALT** button once to change from normal operation to Alt 1 Mode. If you are already operating in Alt 2 Mode, press the ALT button twice (the ALT LED flashes OFF and ON repeatedly to confirm Alt 1 Mode operation).
- Step 4.**
  - (a)** Press **0** to display the current SWIF/RF input setting (ON or OFF). When set to ON, the input signal from the SWIF IN rear panel connector is used. When set to OFF, the input signal from the RF IN rear panel connector is used.
  - (b)** Set the SWIF input setting to ON.
- Step 5.** Press **YES** to save the new setting.  
The front panel display flashes OFF and ON several times to confirm the new setting.
- Step 6.** Press **VIEW** to exit from Alt 1 Mode to video (i.e., return to normal receiver operation).

**Application #2:** Daisy-Chain network monitoring of SWIF broadcast signal

**IMPORTANT!** If any of the daisy-chain networked receivers fails to operate, the SWIF/RF input and output signal routed to all other receivers connected downstream of the failed receiver will not be present.

Transport data output from a Model D9130 Digital Multiplexer or Model D9110 Digital Video Encoder (or other SWIF output) can be monitored by routing the Multiplexer/Encoder SWIF output signal to the receiver SWIF input (before satellite transmission). By connecting the receiver SWIF output to the SWIF input of another receiver (and so on in a daisy-chain network configuration), the SWIF input signal used for the multiple-receiver network can be monitored before (or after) satellite transmission using a TV monitor connected to the TV monitor output.

For example, equipment cable connections required for receiver network monitoring of SWIF signal output are shown in Figure 2-7.

To monitor receiver SWIF/RF input, perform the following actions.

- Step 1.** Connect a fibre optic (or SWIF) cable from the Multiplexer/Encoder SWIF output (or other SWIF output) to the receiver SWIF IN connector.
- Step 2.** (a) Connect a fibre optic (or SWIF) cable from the SWIF OUT connector of the first receiver in the chain to the SWIF IN connector of the second receiver. (b) Connect another SWIF cable from the SWIF OUT connector of the second receiver in the chain to the third receiver SWIF IN connector, and so on, until all receivers are interconnected in this way.
- Step 3.** (Only if downlink RF input used) At the receiver rear panel of the first receiver in the chain, set the LNB power switch to ON or OFF, as required.
- Step 4.** (Optional) (a) At the receiver rear panel of the first receiver in the chain, connect a video cable from the (receiver) TV monitor output connector to the TV monitor video input. (b) Connect separate cables to audio equipment.
- Step 5.** At the receiver front panel, press the **ALT** button once to change from normal receiver operation to Alt 1 Mode. If you are already operating in Alt 2 Mode, press the **ALT** button twice (the ALT LED flashes OFF and ON repeatedly to confirm Alt 1 Mode operation).
- Step 6.** a) Press **0** to display the current SWIF/RF input setting (ON or OFF). When set to ON, the input signal from the SWIF IN rear panel connector is used. When set to OFF, the input signal from the RF IN rear panel connector is used. (b) Set the SWIF input setting to ON.
- Step 7.** **YES** to save the new setting.  
The front panel display flashes OFF and ON several times to confirm the new setting.
- Step 8.** Press **VIEW** to exit from Alt 1 Mode to video (i.e., return to normal receiver operation).






**IMPORTANT!** If filtered MPEG Output is currently set, SWIF signal monitoring is limited to the current virtual channel only. The current receiver MPEG Output setting can only be changed from the Installer Menu (see Chapter 3).

Figure 2-7 shows a typical equipment configuration that can be used for monitoring SWIF signal input using a daisy-chain receiver network.

Figure 2-7. SWIF signal monitoring via daisy-chain receiver network




## System interconnections

For a Single-LNB system, the vertically or horizontally polarized RF input signal from the satellite LNB is routed via RF coaxial cable to the RF IN rear panel connector. Other/optional connections can also be made (see “Receiver equipment interconnection” and “Optional connections”). Figure 2-8 shows a typical single-LNB system interconnection.

Note that it is possible to have one to four cables connected to the input RF switches.

Figure 2-8. Typical single-LNB system interconnection



# Chapter 3 Operation

## About this chapter

This chapter provides complete operating instructions for the PowerVu *Plus* Model D9224 Professional Receiver using menus via the menu interface, and using the front panel via the Alt Mode interface.

## Contents


<b>Chapter 3</b>	<b>Operation .....</b>	<b>3-1</b>
	About this chapter.....	3-1
	Contents.....	3-1
<b>Front panel controls &amp; display.....</b>		<b>3-4</b>
	STANDBY button.....	3-4
	CHAN. ▼ button .....	3-4
	CHAN. ▲ button .....	3-5
	SIGNAL indicator LED .....	3-5
	ALT Mode indicator LED .....	3-6
	Alpha-Numeric display.....	3-6
	Numeric keypad.....	3-6
	Smart Card slot.....	3-6
<b>Setting up the receiver.....</b>		<b>3-7</b>
	...About the Alternate Mode interface.....	3-7
	...About operating the on-screen menus .....	3-7
	...About entering numbers using front panel buttons.....	3-8
	...About saving changes.....	3-9
	...About the current channel .....	3-10
	...About changing the Video Standard .....	3-10
	...About the Network ID.....	3-10
	...About Lock Levels .....	3-11
	...About frequency settings .....	3-12
	...About Signal Searches .....	3-14
	...About the Find option .....	3-14
	Receiver startup.....	3-14
	Default receiver settings.....	3-15
<b>Front panel operation.....</b>		<b>3-17</b>
	...About Alt Modes .....	3-17
	AFC Level.....	3-19
	Alt 1 Mode .....	3-19
	Alt 2 Mode .....	3-20
	Aspect Ratio.....	3-20
	Authorization Relay.....	3-20
	Band Select.....	3-21
	Baud Rate .....	3-21
	Factory Reset.....	3-22
	FEC Rate .....	3-22
	Find .....	3-23
	Frequency .....	3-23

Lock Level .....	3-24
Menu .....	3-24
Next .....	3-25
Remote Control Port Relay.....	3-25
RF/SWIF input .....	3-26
Signal Level.....	3-26
Signal Polarization .....	3-26
Signal Quality (BER) .....	3-27
Signal Search .....	3-27
Store (Save).....	3-28
Symbol Rate .....	3-28
User .....	3-29
Video Standard .....	3-29
Video Bit Rate .....	3-30
View .....	3-30
<b>On-screen menu operation.....</b>	<b>3-31</b>
...About on-screen menu operation.....	3-31
<b>Menus at a glance .....</b>	<b>3-33</b>
<b>R10-Receiver Status menu.....</b>	<b>3-34</b>
...About the ADP count.....	3-35
...About Signal Level and Signal Quality .....	3-35
Decoder Address.....	3-36
Decoder Versions .....	3-36
Smart Card .....	3-36
Smart Card Version.....	3-36
Additional Versions .....	3-36
ADP enc. and ADP non-enc.....	3-36
Bit Error Rate .....	3-36
Signal Level.....	3-37
AFC Level.....	3-37
<b>R20-Services Menu .....</b>	<b>3-38</b>
Program number / Services status .....	3-39
Transport ID.....	3-39
Video status and PID .....	3-39
Audio status and PID .....	3-40
Utility data status and PID.....	3-40
High Speed data status and PID .....	3-40
VBI status and PID.....	3-40
Download DCP/CCP status and PID.....	3-41
PMT PID .....	3-41
PCR PID.....	3-41
<b>R22-Sub-Menu.....</b>	<b>3-42</b>
<b>R23-Tuning Mode Menu .....</b>	<b>3-43</b>
<b>R28-Configuration Menu .....</b>	<b>3-44</b>
CCP Boot Version.....	3-45
DCP Boot Version.....	3-45
Decoder front end .....	3-45
High Speed data .....	3-45
Digital Option .....	3-45
SWIF Option .....	3-46
DVB Common Scrambling.....	3-46

Multiple L-Band .....	3-46
<b>R35-Session Word Menu .....</b>	<b>3-47</b>
<b>R39-Installer Menu .....</b>	<b>3-48</b>
R39-Installer Menu (page 1) .....	3-49
Band Select .....	3-49
Frequency .....	3-50
FEC Rate .....	3-50
Symbol Rate .....	3-51
Signal Polarization .....	3-51
RF/SWIF input .....	3-52
Find .....	3-52
Bit Error Rate (Signal Quality) .....	3-53
Signal Level .....	3-53
AFC Level .....	3-53
R39-Installer Menu (page 2) .....	3-54
Seconds to NO SIGNAL .....	3-54
Network ID .....	3-54
Bouquet ID .....	3-55
Video Standard .....	3-56
...About I-Q signal inversion .....	3-57
MPEG Output .....	3-57
C-Band LO frequency .....	3-58
Ku-Band Low/Single LO frequency .....	3-58
Ku High Band LO frequency .....	3-59
Ku Band Switch LO Crossover frequency .....	3-59
L-Band Input selection .....	3-60
R39-Installer Menu (page 3) .....	3-61
...About other Search Setup options .....	3-61
Signal Search .....	3-61
Search Type .....	3-62
Upper Search Limit .....	3-62
Lower Search Limit .....	3-63

## Front panel controls & display

The front panel of your Model D9224 Professional Receiver provides controls for switching the receiver on and off, switching the receiver to Alt Mode operation, activating and navigating menus, and for interfacing with the Smart Card. A Signal presence LED and an Alternate Mode indicator LED are provided. A four (4)-digit, seven (7)-segment display provides visual identification of current receiver settings, and also provides user feedback when changing the current receiver setup via the front panel. An introduction to each of the front panel buttons and indicators follows.



### STANDBY button

The STANDBY button switches the Professional Receiver on and off (standby).

#### To switch the receiver on or off from the front panel...

Press **STANDBY** .....



When the receiver is switched on, the front panel LED display is ON. When switched off (standby), all indicator and display LEDs are OFF, except for the flashing decimal point on the front panel seven (7)-segment display.

### CHAN.▼ button

While viewing any channel you can use the CHAN.▼ button (front panel) to change channels (lower) one channel at a time.




#### To display the next channel (lower)...

Press CHAN.▼ .....



You can also change channels directly by entering the channel number using the front panel buttons, and then pressing VIEW (see "NUMERIC keypad").

**To change channels directly using front panel buttons...**


Press **0** to **9**.....    
Press **VIEW**..... 

If three buttons (numbers) are pressed for a channel (e.g., 009), the channel change takes place immediately. If only one or two buttons (numbers) are pressed for a channel, the channel change takes place after a short delay (approximately four (4) seconds). If the channel number entered corresponds to a virtual channel outside the frequency plan range, no channel change takes place, and the original channel number is redisplayed.

**CHAN. ▲ button**




While viewing any channel you can use the CHAN. ▲ button (front panel) to change channels (higher) one channel at a time.

**To display the next channel (higher)...**

Press CHAN. ▲..... 

You can also change channels directly by entering the channel number using the front panel buttons, and then pressing VIEW (see “NUMERIC keypad”).

**To change channels directly using front panel buttons...**

Press **0** to **9**.....    
Press **VIEW**..... 

If three buttons (numbers) are pressed for a channel (e.g., 009), the channel change takes place immediately. If only one or two buttons (numbers) are pressed for a channel, the channel change takes place after a short delay (approximately four (4) seconds). If the channel number entered corresponds to a virtual channel outside the frequency plan range, no channel change takes place, and the original channel number is redisplayed.

Other Alt Mode functions are also available via the front panel. For complete information about viewing or changing the current receiver setup using Alt Mode functions, see “Front panel operation”.

**SIGNAL indicator LED**

The Signal indicator LED is ON or OFF in response to the current operating state of your Professional Receiver. When the receiver is synchronized with the incoming digital signal, this LED is ON. If no incoming signal is detected or recognized by the receiver, or if the receiver setup is incorrect, this LED is OFF. If the incoming signal or signal synchronization is temporarily interrupted or lost, this LED may turn OFF and ON intermittently (see Table 3-1). For receiver troubleshooting information, see Appendix C.

Table 3-1. SIGNAL indicator LED operation

Receiver Status	LED State
Authorized	ON
Not Authorized	OFF
No Lock	OFF

## ALT Mode indicator LED

The ALT Mode indicator LED flashes ON and OFF regularly when your Professional Receiver is operating in Alt 1 Mode, and is ON when operating in Alt 2 Mode. When operating the receiver in Alternate Modes, you can use the front panel keypad Alt Mode functions to change the current receiver setup. When the receiver is in normal operating mode, this LED is OFF. For information about using Alt Mode functions to operate your Professional Receiver, see “Setting up the receiver”.

## Alpha-Numeric display

Visual identification of current receiver settings is provided by a four (4)-digit, seven (7)-segment display. The display provides you with immediate feedback when making changes to the current receiver setup via front panel buttons.

When the receiver is switched on, the seven (7)-segment display indicates the current channel.

## Numeric keypad

While viewing any channel you can use the front panel numeric keypad to change the current receiver setup by switching from normal receiver operation to one of two (2) alternate operating modes (i.e., Alt\_Mode-1 and Alt Mode-2). For more information about Alt Modes, see “Setting up the receiver”.

While in normal operating mode (i.e., front panel ALT LED OFF), you can use the front panel numeric keypad to change any channel from 001 to 999 (see also CHAN.▼ button and CHAN.▲ button), or to enter information for R39-Installer Menu options.

### To use the numeric keypad (normal mode operation)...

Press 0 to 9.....

0

9

Alt Mode functions are also available via the front panel. For complete information about viewing or changing the current receiver setup using Alt Mode functions, see “Setting up the receiver”.

## Smart Card slot

The Smart Card slot is provided for future security upgrades to pre-authorized satellite broadcast services.



## Setting up the receiver

This topic provides important operating information regarding the setup and operation of your PowerVu *Plus*™ Professional Receiver and satellite antenna signal source. Before you begin using the receiver, it is important that you read all of the information in this chapter. If you are modifying your receiver or system configuration, you may need to change the current settings to suit your operating requirements. If you are unsure about which settings to use, contact your dealer/reseller, or local service provider.



**IMPORTANT!** Access to your PowerVu *Plus*™ Professional Receiver setup can be controlled via Lock Level. Depending on the current Lock Level setting, you may or may not be prevented from making changes to the current settings.

Using the receiver front panel buttons you can...

- ☐ Activate and navigate the on-screen menus via the menu interface
- ☐ Operate the receiver in Alt 1 or Alt 2 Mode via the Alt Mode interface
- ☐ View or change the current receiver setup
- ☐ Select and view available satellite programs or events

Both the menu interface and the Alt Mode interface can be used interchangeably for performing most receiver setup tasks, since both are operated via receiver operating system software. However, not all menu interface functions are duplicated by the Alt Mode interface. Depending on how you have installed and connected the Professional Receiver, you may or may not be able to use the menu interface. If the receiver is connected to a TV/video display monitor, you can view or change the current receiver setup via on-screen menus. Conversely, if no TV/video display monitor connection is available, only the front panel Alt Mode interface can be used for receiver setup, and you will not need to reference instructions provided for operating the various menus.

### ...About the Alternate Mode interface

While viewing any channel, you can use Alt Mode functions to view the current receiver setup, or you can view or change the current setup from the Installer Channel (see also "...About the current channel"). Alt Mode functions are available via receiver front panel buttons. Alt 1 function labels are printed directly on the keypad bezel above each button. Alt 2 functions are also associated with front panel buttons, except that the function names are not printed on the keypad bezel (see ALT Mode indicator LED"). As with the menu interface, access to Alt Mode functions is controlled by system Lock Levels. More information about Lock Levels is contained in this chapter.

For detailed information about how each of the Alt 1 and Alt 2 functions are used to set up the receiver, see "Front panel operation".

### ...About operating the on-screen menus

While viewing any channel, you can display on-screen menus for viewing or changing the current receiver setup. While in menus, you can change the current receiver settings, and/or display other menus. Some menus contain setup information which is available for viewing only, and cannot be changed. Numbered menu options are used to display other

menus. Access to menus and changeable menu options is controlled by system Lock Levels. For more information about Lock Levels, see "...About Lock Levels".

#### To display on-screen menus and view the current receiver setup...

- Step 1.** Press the **MENU** button on the receiver front panel.  
The R39-Installer Menu is displayed.

You can only change the current receiver setup if you have changed to the Installer Channel (i.e., channel 0) before pressing the MENU button. Otherwise, you will only be able to view the current receiver settings.

- Step 2.** Move to the desired setting by pressing the NEXT button, or follow the on-screen instructions to display other menus.

For complete information about how to operate each of the on-screen menus, see "On-screen menu operation" (see also "...About saving changes").

#### To disable receiver lockout (if Lock Level 3 set)...

If the receiver is locked out (i.e., Lock Level 3 is set), you can display setup information at the front panel only, and menus cannot be displayed.

Perform the following actions to change the receiver Lock Level setting from 3 to 0 to disable lockout. When receiver lockout is disabled, you can display menus and/or make any changes to the current setup using front panel buttons.

- Step 1.** Press **ALT** to change from normal operation to Alt 2 Mode.  
The ALT LED is ON.
- Step 2.** Press **3 (LOCK)** once to display the current Lock Level (i.e., Loc 3). Pressing **3** again displays Loc 0.
- Step 3.** Press **YES** to save (STORE) the setting.  
The front panel display flashes OFF and ON several times to confirm the new setting.

For more information about Lock Levels, see "...About Lock Levels".

### ...About entering numbers using front panel buttons

**Alt Mode interface:** The Alt Mode interface cannot be used for direct numeric entry. To operate the front panel for setting numeric functions while in Alt Mode, perform the following actions.

- Step 1.** Change to Alt 1 or Alt 2 Mode operation by pressing the ALT button on the receiver front panel (see "Front panel operation").
- Step 2.** Press the appropriate Alt Mode button to display/change the currently displayed value higher or lower, as required.
- Step 3.** Press **YES** to STORE (save) the new setting.

Each change made must be saved before exiting (see also “...About saving changes”). Repeat the above action to change the current setting. If a value is out of range or conflicts with another setting, a default value may be substituted.

**Menu interface:** Some menu options let you enter values directly using front panel buttons. To enter numbers directly and to operate numeric functions, perform the following actions.

- Step 1.** Move to the desired menu option by pressing the **NEXT** button.
- Step 2.** Press the **CHAN. ▲** or **CHAN. ▼** button to change the currently displayed value higher or lower, as required, or press the front panel buttons to enter the number directly. Each number entered is displayed on-screen (decimal places may also display automatically). If you make a mistake while entering numbers, repeat the above using the correct buttons.

Any changes made must be saved before exiting the menu (see “...About saving changes”). Repeat the above action to change the current setting. If a value entered is out of range or conflicts with another setting, a default value may be substituted.

## ...About saving changes

**Alt Mode interface:** After making changes to the current setup via any Alt Mode function, you must save or discard the changes. Saved changes are used to update the current receiver settings which are stored in non-volatile memory. Discarding changes restores the previously saved settings. You can also cancel the operation to make further changes. For more information about Alt Modes, see “Front panel operation”.

### After changing the current receiver setup you can...

- ☐ **Save:** Press **YES** to save (STORE) the new setting
- ☐ **Cancel:** Press any other key to discard the change (restore previously saved setting)

**Menu interface:** After making a changes to the current receiver setup, you must save or discard changes (see “...About saving changes”). Saved changes are used to update the current receiver settings which are stored in non-volatile memory. Discarding changes restores the previously saved settings. For more information about menus, see “On-screen menu operation”.

### After changing the current receiver setup you can...

- ☐ **Save:** Press **YES** to save (STORE) the new settings
- ☐ **Cancel:** Do not press **YES** before exiting from menus



**IMPORTANT!** Saved settings are automatically restored when the receiver is restarted after AC power is switched off or interrupted (see also “...About Lock Levels”).

### ...About the current channel

When you change from normal receiver operation to Alt Mode (or navigate to menus from video), the information displayed is associated with the current (virtual) channel. If no changes are made to the current setup, you are automatically returned to the previously-watched channel when you exit to video. If any changes are made which affect the received digital signal, exiting to video after saving changes is preceded by the Installer Channel banner display (i.e., channel 0). The current channel is displayed on-screen when in video, at the front panel when using the Alt Mode interface, and at the R20-Services Menu. For more information about the Installer Channel, see “Front panel operation”.

### ...About changing the Video Standard

The Video Standard used to operate the receiver is preset at the factory to either NTSC (525-line), or PAL (625-line), depending on factory-installed options. Changing the Video Standard is normally required only for operating the receiver in a network or jurisdiction that uses the alternate Video Standard, and/or when new (or different) subscriber services are made available.



**IMPORTANT!** The current Video Standard setting is used by the receiver for correct display of the video (picture) only. The satellite receiver does not convert from one Video Standard to another, such as from NTSC (525-line) to PAL-B (625-line) formats.

Note that *only* NTSC and PAL-B are supported even though PAL-M and PAL-N are shown on the display.

Changing the Video Standard or resetting the receiver to the default factory settings may cause the TV video to display improperly. If the current Video Standard setting is incompatible with subscriber/network services, it must be changed. For information about factory default settings, see “Default receiver settings”.

### ...About the Network ID

Operating the Professional Receiver in a DVB<sup>1</sup> network requires a valid Network ID. This number must be correctly set to match the Network ID associated with the uplink signal. Similarly, if your subscriber/network services require a Bouquet ID<sup>2</sup>, it must also be correctly set to match the uplink signal Bouquet ID. Loss of service will result if the receiver Network ID and/or Bouquet ID does not match the uplink signal Network/Bouquet ID information.

The Network ID used to operate the receiver is preset at the factory (i.e., to 1). The Bouquet ID (if used) is also preset at the factory (i.e., to 1). Changing the Network/Bouquet ID or resetting the receiver to the factory default settings may cause loss of service. If the Network/Bouquet ID required for your uplink service is unknown or is incorrect, it must be correctly identified and set. For more information, see “Default receiver settings”.

---

<sup>1</sup> Digital Video Broadcasting

<sup>2</sup> Subnetwork ID required by some DVB networks

## ...About Lock Levels

Four (4) user-selectable Lock Levels (Loc 0, 1, 2 and 3) are available for protecting your Professional Receiver and the current receiver settings against unauthorized use or modification (see Table 3-2). A Lock Level 0 setting lets you make any changes to the current receiver setup. A Lock Level 1 setting is the same as 0, except that Factory Reset is disabled. A Lock Level 2 setting disables all settings that can compromise the video signal, except Authorization Relay, Baud Rate, Lock Level, and Port Control Relay settings. A Lock Level 3 setting prevents any changes to the current receiver setup by blocking access to menus and disabling all front panel (i.e., Alt Mode) functions, except the Lock Level setting. A Lock Level 4 setting can only be changed via remote terminal (Serial Remote Control commands) or PCC uplink signal, and displays N/A<sup>1</sup> if set. When the receiver configuration is protected via Lock Level 4, front panel operation is locked out or disabled, and menus cannot be displayed (see also Appendix D).



**IMPORTANT!** For Alt Mode operation only: The Lock Level setting can be changed from any channel, including the Installer Channel (i.e., channel 0). To return to the previously-watched (virtual) channel after changing the Lock Level setting to 3 in Alt Mode, be sure that the desired virtual channel is displayed before changing to this Lock Level setting.

If a change made to the current Lock Level setting is not saved, the previously-saved setting is restored (see "...About saving changes").

**Table 3-2. Available Lock Levels**

Lock Level	Description
0	All front panel and menu operation enabled
1	Factory Reset disabled (see Table 3-3)
2	Critical settings disabled (see Table 3-3)
3	Front panel and menu operation disabled, except Lock Level (accessible from front panel only)
4	Front panel and menu operation disabled (accessible via Remote Control Commands and PCC uplink control only)

Table 3-3 summarizes Lock Level settings associated with receiver front panel buttons for both front panel (i.e., Alt Mode) and menu operation.

---

<sup>1</sup> Not Applicable

Table 3-3. Lock Level summary

Label	Function/Description	Press	Lock	Label	Function/Description	Press	Lock
STANDBY	On/Standby	STANDBY	0, 1 & 2	–	–	–	–
CHAN.▲	Channel /Option ↑	CHAN.▲	0 & 1	–	–	–	–
CHAN.▼	Channel /Option ↓	CHAN.▼	0 & 1	–	–	–	–
0-9	Direct (numeric) entry	#0 - 9	0 & 1	–	–	–	–
F. Reset	Factory Reset	ALT 1 <sup>1</sup>	0	–	–	–	–
ALT 1	ALT 1 Mode	ALT (once)	0, 1, 2 & 3	ALT 2	Alt 2 Mode	ALT (twice)	0, 1, 2 & 3
C/Ku	Band Select	ALT 1+1	0 & 1	BAUD	Baud Rate	ALT 2+1	0, 1 & 2
FEC	FEC Rate	ALT 1+2	0 & 1	PRLY	Rem. Ctrl. Port Relay	ALT 2+2	0, 1 & 2
BER	BER (Signal Quality)	ALT 1+3	0, 1, 2 & 3	LOCK	Lock Level	ALT 2+3	0, 1, 2 & 3
FRQ▲	Frequency	ALT 1+4	0 & 1	–	–	ALT 2+4	–
SYM	Symbol Rate	ALT 1+5	0 & 1	ARLY	Authorization Relay	ALT 2+5	0, 1 & 2
SIG	Signal Level	ALT 1+6	0, 1 & 2	WIDE	Aspect Ratio	ALT 2+6	0, 1, 2 & 3
FRQ▼	Frequency	ALT 1+7	0 & 1	VID	Video Standard	ALT 2+7	0 & 1
POL	Signal Polarization	ALT 1+8	0 & 1	–	–	ALT 2+8	–
AFC	Auto Frequency Control	ALT 1+9	0, 1, 2 & 3	VBR	Video Bit Rate	ALT 2+9	0, 1, 2 & 3
SWIF	Input Select	ALT 1+0	0 & 1	–	–	ALT 2+0	–
USER	Next (Installer) menu	USER	0, 1 & 2	SRCH	Signal Search	ALT 2+ USER	0 & 1
MEN U	Receiver Status menu	MEN U	0, 1 & 2	–	–	–	–
NEXT	Next (menu) option	NEXT	0, 1 & 2	NEXT	Find	NEXT	0 & 1
STORE	Saves each change	YES	0, 1, 2 & 3	–	–	–	–
VIEW	Exit to video	VIEW	0, 1 & 2	–	–	–	–

### ...About frequency settings

As you make changes to the current setup, the receiver checks that the various C-Band and Ku-Band LO (Local Oscillator), Ku Band Switch (Crossover) plus operating Band frequency settings are compatible with each other, and with other settings. The settings required depend on the type of LNB system installed and on subscriber/network services available, which may vary. Use only those settings specified by your antenna/LNB manufacturer, dealer/reseller or local service provider.

You can enter a valid frequency using the numbered front panel buttons, and/or you can use the CHAN.▲/CHAN.▼ front panel buttons to display available settings. If the current setting is out of range or is incompatible with other settings, it may be changed automatically. After making changes to the current receiver setup, it must be saved. For information about saving changes, see "...About saving changes".

The relationships between the Downlink, L-Band and Local Oscillator frequencies are shown in Table 3-4 for both C-Band (3.7 GHz to 4.2 GHz) and Ku-Band (10.7 GHz to 15 GHz) operation.

<sup>1</sup> After changing to Alt 1 Mode, press the CHAN.▲ and CHAN.▼ buttons simultaneously

**Table 3-4. C and Ku-Band frequency calculations**

Frequency Band	L-Band (operating) frequency calculation
C-Band	L-Band frequency = $f^1$ (Local Oscillator) - $f$ (Downlink)
Ku-Band	L-Band frequency = $f$ (Downlink) - $f$ (Local Oscillator)

A Ku Band Switch (Crossover) frequency is required only if you are using a dual-band LNB. If used, the Ku High Band LO frequency must be greater than the C-Band LO or the Ku Lo/Single LO (or Ku High Band LO) frequencies.

Automatic 22 kHz tone signaling (LNB selection) is provided for dual-LNB operation if the receiver setup includes certain settings. The presence or absence of this signal (at the receiver RF IN connector) depends on the frequency settings used. The relationship between the various frequency settings and 22 kHz tone signal output are shown in Table 3-5.

**Table 3-5. LO frequency settings vs. 22 kHz tone signal output**

Frequency 'Band' setting	22 kHz Tone
C/L-Band Freq.	OFF
C/Downlink Freq.	OFF
Lo Ku/L-Band Freq.	OFF
High Ku/L-Band Freq.	ON
Single Ku/Downlink Freq.	OFF
Dual Ku/Downlink Freq.	ON or OFF

When using a dual-band (universal) LNB and the Dual Ku/Downlink Freq. setting is used, the receiver compares the current Downlink Freq. setting (value) with the Ku Band Switch (Crossover) frequency setting (value). If the Downlink Freq. setting associated with the Installer Channel (i.e., Channel 0) is lower than the Dual Ku/Downlink Freq. setting, the 22 kHz tone signal is OFF (i.e., not present at the receiver RF IN connector). Consequently, if the Downlink Freq. setting is higher, the 22 kHz tone signal is ON (i.e., present). When the receiver is operated in a multiple-transport network, the Downlink Freq. value associated with other virtual channel services is used by the receiver for comparison, as above (see also "R39-Installer Menu").

The required Band, Frequency and Local Oscillator settings are shown in Table 3-6.

**Table 3-6. Band, Frequency and Local Oscillator settings**

Band	Frequency	Local Oscillator	LO Crossover
C/L-Band Freq.	L-Band	C Band LO	N/A
C/Downlink Freq.	Downlink	C Band LO	N/A
Low Ku/L-Band Freq.	L-Band	Ku Low/Single LO	N/A
High Ku/L-Band Freq.	L-Band	Ku High Band LO	N/A
Single Ku/ Downlink	Downlink	Ku Low/Single LO or Ku High Band LO	N/A
Dual Ku/ Downlink	Downlink	Ku Low/Single LO plus Ku High Band LO	Ku Band Switch

---

<sup>1</sup> Frequency

## ...About Signal Searches

Searching for a signal with the “Search” option is used for restoring normal receiver operation if the received signal is interrupted or lost, or is changed by the local broadcast satellite services provider.

A signal search is enabled by setting the Search option to ON, and is activated automatically only if the carrier signal is interrupted or lost for more than 20 seconds, and only if the receiver is operating in normal mode (i.e., menus are not displayed). If the lost carrier signal is recovered within 20 seconds, the receiver will attempt to synchronize with the last locked channel. If unavailable, the “NO SIGNAL” banner is displayed. If the lost carrier signal is not recovered within this time, a signal search is activated automatically.

Once activated, the receiver begins searching for a signal associated with the current Network ID. When a possible match is found, the search is temporarily interrupted while the receiver attempts to synchronize with the found signal. If synchronization is successful, the “LOCKED” status is displayed on-screen. Settings can be saved, as required, before exiting to video (current channel). If receiver synchronization cannot be achieved, the signal is discarded and the signal search is automatically resumed. If no signal is found, the signal search continues indefinitely, and must be manually terminated. A signal search can also be manually terminated, or interrupted and resumed with different settings. To disable the search, set the Search to OFF. A search is also terminated automatically if the current channel is changed, or if the MENU button is pressed.

Signal Searches are constrained or limited by the current Search Type and the boundary settings for the Lower and Upper Range frequencies. Default Search Type, Lower Range and Upper Range (frequency) criteria used for conducting the Signal Search can only be changed via the menu interface. For information about factory default settings, see “Default receiver settings”.

## ...About the Find option

Searching for a signal with the “Find” option can be used if you are installing the Professional Receiver for the first time, or if you are modifying the current receiver setup. Activating the Find function forces the receiver to search for a signal immediately.

Once activated, the receiver begins searching for a signal associated with any Network ID. When a possible match is found, the search is temporarily interrupted while the receiver attempts to synchronize with the found signal. If synchronization is successful, the “LOCKED” status is displayed on-screen, and the settings can be saved, as required, before exiting to video (current channel). If receiver synchronization cannot be achieved, the signal is discarded and the signal search is automatically resumed. If no signal is found, the signal search continues indefinitely, and must be manually terminated.

## Receiver startup

To activate the receiver, press the STANDBY button on the receiver front panel. When AC power is first applied, the receiver starts up in STANDBY mode. This operating mode is confirmed by the flashing character segment on the front panel display. When in normal operating mode, the current channel is displayed.



## Default receiver settings

When the receiver is first powered on, the default factory receiver settings stored in non-volatile memory are used for receiver operation. Current settings can be displayed via the Alt Mode Interface by pressing the appropriate front panel buttons, or in menus via the Menu Interface.

A Factory Reset (available via the front panel only) is available for resetting the receiver to the factory default settings. When executed, the current receiver settings are replaced by the default settings (see Table 3-7). After the factory defaults are restored, you can make any changes, as required. Current receiver settings can be replaced at any time. For information about how to perform a Factory Reset, see "Front panel operation".

The accompanying table lists each of the Model D9224 Professional Receiver factory default settings by Menu. "YES" indicates front panel operation (see "Front panel operation").

**Table 3-7. Factory default settings**

Option	Menu	Front Panel	Default
Band	R39-Installer Menu 1/3	YES	C-Band
L-Band Freq.	R39-Installer Menu 1/3	YES	950 MHz
FEC Rate	R39-Installer Menu 1/3	YES	7/8
Symbol Rate	R39-Installer Menu 1/3	YES	28.3465 Msymbols/s
Polarization	R39-Installer Menu 1/3	YES	H (Horizontal)
Input Select	R39-Installer Menu 1/3	YES	RF
Find	R39-Installer Menu 1/3	YES	OFF
Bit error Rate (BER)	R39-Installer Menu 1/3	YES	N/A
Signal Level	R39-Installer Menu 1/3	YES	N/A
AFC Level	R39-Installer Menu 1/3	YES	N/A
Seconds to NO SIGNAL	R39-Installer Menu 2/3	NO	5
Network ID	R39-Installer Menu 2/3	NO	1
Bouquet ID	R39-Installer Menu 2/3	NO	1
Video Standard	R39-Installer Menu 2/3	YES	525A: NTSC->PAL/B
I-Q Select	R39-Installer Menu 2/3	YES	Auto Switch
MPEG Output	R39-Installer Menu 2/3	NO	Unfiltered
C Band LO	R39-Installer Menu 2/3	NO	5.150 GHz
Ku Low/Single LO	R39-Installer Menu 2/3	NO	9.750 GHz
Ku High Band LO	R39-Installer Menu 2/3	NO	10.600 GHz
Ku Band Switch	R39-Installer Menu 2/3	NO	11.700 GHz
Search	R39-Installer Menu 3/3	YES	OFF
Search Type	R39-Installer Menu 3/3	NO	Frequency Only
Upper Search Limit	R39-Installer Menu 3/3	NO	1450.00 MHz
Lower Search Limit	R39-Installer Menu 3/3	NO	950.00 MHz
Baud Rate	NO	YES	9600
Remote Control Port Relay	NO	YES	OFF
Authorization Relay	NO	YES	OFF
Aspect Ratio	NO	YES	4-3 (Normal)
VBR (Video Bit Rate)	NO	YES	N/A
Factory Reset	NO	YES	N/A

## Front panel operation

Setting up your Professional Receiver via the Alt Mode interface requires setup of frequency-related and other options. These settings are used by the receiver for locking onto the signal, and for optimizing receiver performance. Most menu interface functions are also available via the Alt Mode interface. For a summary of Alt Mode functions, see Table 3-8.

Alt-1 Mode				Alt-2 Mode			
C/Ku	FEC	BER		BAUD	PRLY	LOCK	
1	2	3	MENU	1	2	3	MENU
FRQ▲	SYM	SIG			ARLY	WDE	FIND
4	5	6	NEXT	4	5	6	NEXT
FRQ▼	POL	AFC	STORE	VIDEO		VBR	STORE
7	8	9	YES	7	8	9	YES
	SWIF	SNR				SRCH	
ALT	0	USER	VIEW	ALT	0	USER	VIEW

### ...About Alt Modes

While viewing any channel, you can use Alt Mode functions to view the current receiver setup, or you can view or change the current setup from the Installer Channel (see also “...About the current channel”). Alt Mode functions are available via receiver front panel buttons. Alt 1 function labels are printed directly on the keypad bezel above each button. Alt 2 functions are also associated with front panel buttons, except that the function names are not printed on the keypad bezel (see “ALT Mode indicator LED”). As with the menu interface, access to Alt Mode functions is controlled by system Lock Levels. More information about Lock Levels is contained in this chapter.

#### To operate the receiver in Alt 1 Mode...

- Step 1.** Press the ALT button on the receiver front panel once. If you are already operating in Alt 2 Mode, press the ALT button twice.  
The ALT LED flashes to confirm Alt 1 Mode operation.

While the receiver is operating in Alt 1 Mode, the ALT LED flashes regularly, and only Alt 1 functions are available via front panel buttons. Pressing ALT twice returns the receiver to normal operation (i.e., the ALT LED is OFF).

#### To operate the receiver in Alt 2 Mode...

- Step 1.** Press the ALT button on the receiver front panel twice. If you are already operating in Alt 1 Mode, press the ALT button once.  
The ALT LED is ON to confirm Alt 2 Mode operation.

While the receiver is operating in Alt 2 Mode, the ALT LED is ON, and only Alt 2 functions are available. Pressing ALT once returns the receiver to normal operation (i.e., the ALT LED is OFF).

## To change a receiver setting...

- Step 1.** Change to the Installer Channel (i.e., channel 0) using front panel buttons.
- Step 2.** Choose the desired Alt Mode function by pressing the appropriate front panel buttons. For some Alt Mode functions, you press the same button repeatedly to display available options. For other functions, you press (a) different button(s). The current setting is displayed on the receiver front panel.
- Step 3.** After displaying the desired option, press YES to save (STORE) the setting.



**IMPORTANT!** Certain (critical) receiver setup options can only be changed from the Installer Channel (i.e., channel 0). Before making changes, verify that channel 0 is the current channel, if required (see also "...About the current channel").

For more information about using front panel buttons, see "Front panel operation".

## After changing the current receiver setup you can...

- ☐ **Save:** Press **YES** to save (STORE) the new setting
- ☐ **Cancel:** Press any other key to discard the change (restore previously saved setting)



**IMPORTANT!** Saved settings are automatically restored when the receiver is restarted after AC power is switched off or interrupted (see also "...About Lock Levels").

## To exit from Alt Mode to video...

- ☐ Press the VIEW button
- Table 3-8 shows available Alt Mode functions.

**Table 3-8. Available Alt Mode functions**

Alt 1	Description	Press	Alt 2	Description	Press
F. Reset	Factory Reset	ALT 1 <sup>1</sup>	–	–	–
ALT	Alt 1 Mode	ALT <sup>2</sup>	ALT	Alt 2 Mode	ALT <sup>3</sup>
C/Ku	Band Select	1	BAUD	Baud Rate	1
FEC	FEC Rate	2	PRLY	Remote Control Port Relay	2
BER	BER (Signal Quality)	3	LOCK	Lock Level	3
FRO▲	Frequency ↑ (L-Band)	4	–	NA	4
SYM	Symbol Rate	5	ARLY	Authorization Relay	5
SIG	Signal Level	6	WIDE	Aspect Ratio	6
FRO▼	Frequency ↓ (L-Band)	7	VID	Video Standard	7

<sup>1</sup> After changing to Alt 1 Mode, press the CHAN.▲ and CHAN.▼ buttons simultaneously

<sup>2</sup> Press ALT (once) to change from normal receiver operation to ALT 1 Mode

<sup>3</sup> Press ALT (twice) to change from normal receiver operation to ALT 2 Mode

Alt 1	Description	Press	Alt 2	Description	Press
POL	Signal Polarization	8	–	NA	8
AFC	Auto Frequency Control	9	VBR	Video Bit Rate	9
SWIF	Input Select	0	–	NA	0
USER	NA <sup>1</sup>	–	SRCH	Signal Search	USER
MEN U	Displays R10-Receiver Status menu	MEN U	MEN U	Displays R10-Receiver Status menu	MEN U
NEXT	NA	NEXT	FIND	Find	NEXT
STORE	Saves each change	YES	STORE	Saves each change	YES
VIEW	Exit to video	VIEW	VIEW	Exit to video	VIEW

## AFC Level

**Display only:** The AFC (Automatic Frequency Control) Level display option is an Alt 1 Mode function. The displayed AFC Level (any number from -50 to +50) is the current relative offset from the set center frequency of the decoded digital signal. The receiver automatically compensates for a  $\pm 2.5$  MHz frequency offset which is equivalent to an AFC Level of approximately  $\pm 12$ .

To display the AFC Level...

**Step 1.** Press **ALT** to change from normal operation to Alt 1 Mode. The ALT LED flashes OFF and ON, continuously. .

**Step 2.** Press **9** (AFC) to display the AFC Level.

The AFC Level can be displayed from any channel. This option is also available at the R39-Installer Menu, and at the R10-Receiver Status menu.

## Alt 1 Mode

To operate the receiver in Alt 1 Mode...

**Step 1.** Press **ALT** on the receiver front panel once. If you are already operating in Alt 2 Mode, press the ALT button twice. The ALT LED flashes to confirm Alt 1 Mode operation.

Repeat the above action to change from normal receiver operation to Alt 1 Mode. The receiver can be operated in Alt 1 Mode from any channel. While operating in Alt 1 Mode, the ALT LED flashes ON and OFF, and only Alt 1 functions are available via front panel buttons. Pressing ALT twice (or pressing VIEW) returns the receiver to normal operation (i.e., the ALT LED is OFF).

---

<sup>1</sup> No Action

## Alt 2 Mode

To operate the receiver in Alt 2 Mode...

- Step 1.** Press **ALT** on the receiver front panel twice . If you are already operating in Alt 1 Mode, press the ALT button once.  
The ALT LED is ON to confirm Alt 2 Mode operation.

Repeat the above action to change from normal receiver operation to Alt 2 Mode. The receiver can be operated in Alt 2 Mode from any channel. While operating in Alt 2 Mode, the ALT LED is ON, and only Alt 2 functions are available via front panel buttons. Pressing ALT once (or pressing VIEW) returns the receiver to normal operation (i.e., the ALT LED is OFF).

## Aspect Ratio

**Display only:** The Aspect Ratio option is an Alt 2 Mode function. The selected Aspect Ratio lets you view programming broadcast in normal (4 X 3) or wide (16 X 9) format on your TV monitor. Wide format is available when wide aspect ratio information is included with the broadcast, and only if enabled at the uplink.

To display the Aspect Ratio...

- Step 1.** Press **ALT** twice to change from normal operation to Alt 2 Mode.  
The ALT LED is ON.
- Step 2.** Press **6** (WIDE) to display the current Aspect Ratio setting. Available settings are (4-3 [4X3 or Normal] or 16-9 [16X9 or Wide]). The default setting is 4X3 (Normal).

The Aspect Ratio can be displayed from any channel. This option is only available at the front panel.

## Authorization Relay

The Authorization Relay option is an Alt 2 Mode function. The selected setting enables or disables the receiver rear panel (AUTH terminals) Authorization Relay output signal. In the event of loss of signal authorization, this output signal can be used for switching in redundant receiver backup or other equipment (see also "Remote Control Port Relay").

To set the Authorization Relay operating state...

- Step 1.** Press **ALT** twice to change from normal operation to Alt 2 Mode.  
The ALT LED is on.
- Step 2.** Press **5** (ARLY) to display the current Authorization Relay operating state setting. Pressing **5** repeatedly displays available settings (ON or OFF). The default setting is OFF.
- Step 3.** When the desired setting is displayed, press YES to save (STORE) the setting.  
The front panel display flashes to confirm the new setting.

Repeat the above action to change the Authorization Relay operating state. The Authorization Relay operating state can be displayed or changed from any channel. This option is only available at the front panel.

## Band Select

The Band Select option is an Alt 1 Mode function. The selected operating (frequency) band is the operating frequency band (C-Band or Ku-Band) used by the receiver for tuning the received digital signal.

To display or change the operating band...

- Step 1.** Press **ALT** once to change from normal operation to Alt 1 Mode. The ALT LED flashes OFF and ON, continuously.
- Step 2.** Press **1** (C/Ku) to display the current operating band (C or U [Ku]). Press **1** again to change the current setting, as required. The default setting is C.
- Step 3.** When the desired setting is displayed, press YES to save (STORE) the setting. The front panel display flashes OFF and ON several times to confirm the new setting.

Repeat the above action to change to another operating Band. This option is also available at the R39-Installer Menu.

## Baud Rate

The Baud Rate option is an Alt 2 Mode function. The selected Baud Rate sets the Baud Rate for the serial Expansion Port (if used).

To display or change the Baud Rate...

- Step 1.** Press **ALT** to change from normal operation to Alt 2 Mode. The ALT LED is ON.
- Step 2.** Press **1** (BAUD) to display the current Baud Rate. Pressing 1 repeatedly displays available settings [150, 300, 600, 1200, 2400, 4800 or 9600 baud] ). The default setting is 9600.
- Step 3.** When the desired setting is displayed, press YES to save (STORE) the setting. The front panel display flashes OFF and ON several times to confirm the new setting.

Repeat the above action to change to another Baud Rate. The Baud Rate can be displayed or changed from any channel. This option is only available at the front panel.

## Factory Reset

The Factory Reset option is an Alt 1 Mode function, and is used to replace the current receiver settings with the factory default settings. For information about factory default receiver settings, see “Default receiver settings” (see also Table 3-7).

To restore the factory default settings...

- Step 1.** Press the ALT once to change from normal receiver operation to Alt 1 Mode. The ALT LED flashes OFF and ON, continuously.
- Step 2.** Press the CHAN. ▲ and CHAN. ▼ buttons simultaneously (front panel). The front panel displays “do?”.
- Step 3.** Press the YES button (front panel) to initiate the Factory Reset (pressing any other key aborts the action).

Repeat the above action to restore the factory default settings (see “Default receiver settings”). Once initiated, a Factory Reset cannot be interrupted or reversed. A Factory Reset can be performed from any channel (see “...About the current channel”). This option is only available at the front panel.

## FEC Rate

The FEC Rate option is an Alt 1 Mode function. The selected FEC Rate must match the FEC Rate associated with the received digital signal.

To display or change the FEC rate...

Perform the first step if you are changing the FEC Rate.

- Step 1.** If required, press 0 to display the Installer Channel.
- Step 2.** Press ALT once to change from normal operation to Alt 1 Mode. The ALT LED flashes OFF and ON, continuously.
- Step 3.** Press 2 (FEC) to display the current FEC Rate. Pressing 2 repeatedly displays available settings (1-2, 2-3, 3-4, 5-6, or 7-8), which correspond to 1/2, 2/3, 3/4, 5/6, or 7/8, respectively. The default setting is 7/8.
- Step 4.** When the desired setting is displayed, press YES to save (STORE) the setting. The front panel display flashes OFF and ON several times to confirm the new setting.

Repeat the above action to change the FEC Rate. The FEC Rate can be displayed from any channel, but can only be changed from the Installer Channel (see “...About the current channel”). This option is also available at the R39-Installer Menu.



## Find

The Find option is an Alt 2 Mode function. The selected setting enables or disables the automatic Find feature used for recovering a digital signal (see "...About the Find option"). See also "...About Signal Searches".

### To display or change the Find setting...

- Step 1.** If required, press **0** to display the Installer Channel.
- Step 2.** Press **ALT** twice to change from normal operation to Alt 2 Mode.  
The ALT LED is ON.
- Step 3.** Press **NEXT** (FIND) to display the current Find setting. Pressing **NEXT** repeatedly displays available settings (FIND or OFF). The default setting is OFF.
- Step 4.** When the desired signal is found (i.e., "LOCKED" status displayed on-screen), press **YES** to save (STORE) the setting.  
The front panel display flashes OFF and ON several times to confirm the new setting.

Repeat the above action to Find another signal. When a signal is found, the Find option is automatically set to OFF. You can also terminate the search manually by setting the Find option to OFF. The Find setting can only be displayed or changed from the Installer Channel (see "...About the current channel"). This option is also available at the R39-Installer Menu.

## Frequency

The Frequency option is an Alt 1 Mode function. The displayed Frequency setting is the current C/Ku (L-Band) frequency used by the receiver for tuning the received digital signal.

### To display or change the operating Frequency...

Perform the first step if you are changing the operating (L-Band) Frequency.

- Step 1.** If required, press **0** and then press **SELECT** to display the Installer Channel.
- Step 2.** Press **ALT** once to change from normal operation to Alt 1 Mode.  
The ALT LED flashes OFF and ON, continuously.
- Step 3.** Press **4** (FRQ ▲) or **7** (FRQ ▼) to display the current frequency setting. Pressing **4** (FRQ ▲) or **7** (FRQ ▼) repeatedly displays higher or lower settings (frequencies are displayed from 950 MHz to 2050 MHz [L-Band] in 1 MHz steps. The default setting depends on the currently selected operating band (see ...About frequency settings).
- Step 4.** When the desired setting is displayed at the front panel, press **SELECT** to save the setting.  
The front panel display flashes OFF and ON several times to confirm the new setting.

Repeat the above action to display or change the operating frequency. The operating frequency can be displayed from any channel, but can only be changed from the Installer Channel (see "...About the current channel"). A valid operating Frequency is always required (see also "Band Select"). Note that only L-Band frequencies can be displayed or changed via Alt Mode. This option is also available at the R39-Installer Menu.

## Lock Level



**IMPORTANT!** (For Alt Mode operation only) The Lock Level setting can be changed from any channel, including the Installer Channel (i.e., channel 0). To return to the previously-watched (virtual) channel after changing the Lock Level setting to 3 in Alt Mode, be sure that the desired virtual channel is displayed before changing the Lock Level setting.

The Lock Level option is an Alt 2 Mode function. The Lock Level setting determines what receiver/interface options are available for viewing and/or modification.

### To display or change the Lock Level...

Performing the first step may or may not be required if you are changing the Lock Level to 3 (see IMPORTANT).

- Step 1.** If required, press **0** to display the Installer Channel.
- Step 2.** Press **ALT** to change from normal operation to Alt 2 Mode.  
The ALT LED is ON.
- Step 3.** Press **3** (LOCK) to display the current Lock Level . Pressing **3** repeatedly displays available settings (Lock Levels are displayed from 0 to 3). The default setting is 0.
- Step 4.** When the desired setting is displayed, press **YES** to save (STORE) the setting.  
The front panel display flashes OFF and ON several times to confirm the new setting.

Repeat the above action to change the Lock Level setting. The Lock Level setting can be displayed or changed from any channel. Note that if Lock Level 4 is set (via uplink only), "Loc 4" is displayed when any front panel button is pressed. For more information about Lock Levels, see "...About Lock Levels". This option is only available at the front panel.

## Menu

The Menu option is a front panel function provided for displaying the R10-Receiver Status menu. The R10-Receiver Status menu displays information about the current receiver setup. Other menus can also be displayed via this menu (see "On-screen menu operation").

### To display the R10-Receiver Status menu...

- ☐ Press **MENU** to display the R10-Receiver Status menu.

Repeat the above action to display menus. Menus can be displayed from any channel. Receiver settings can also be displayed or changed when the MENU button is pressed from any virtual channel, including the Installer Channel.

To exit from the R10-Receiver Status menu...

- Press **VIEW** to exit from the R10-Receiver Status menu to video.
- For information about the VIEW button, see “View”.

## Next

The NEXT option is a menu function, and is provided for moving to the next R39-Installer Menu option (see also “Menu”).

To display the next R39-Installer Menu option...

- Press **NEXT** to move to (or select) the next option. Pressing next repeatedly moves continuously to the changeable menu options. A “>” character appears beside the currently selected option.
- Repeat the above action to move to (or select) the next (changeable) menu option. The NEXT button can only be operated when changeable options are displayed (menus), or when operating the receiver in Alt 2 Mode (see “Find”).

## Remote Control Port Relay

The Remote Control Port Relay option is an Alt 2 Mode function. The selected setting enables or disables the receiver rear panel (RC8 terminals) Remote Control Port Relay output signal in response to the current operating state of Remote Control port pins. When a Remote Control Port is selected (receiver rear panel EXPANSION PORT), the Remote Control Port Relay output signal can be used to provide ON/OFF control of remote equipment (see also “Appendix D Serial Remote Control Command Set”).

To display or change the Remote Control Port Relay operating state...

- Step 1.** Press **ALT** to change from normal operation to Alt 2 Mode.  
The ALT LED is ON.
- Step 2.** Press **2** (PRLY) to display the current Remote Control Port Relay operating state setting. Pressing **5** repeatedly displays available settings (1, 2, 3, 4, 5, 6, 7, 8 or OFF). Settings 1 to 8 enable the selected port pin, and OFF disables all Remote Control Port pins. The default setting is OFF.
- Step 3.** When the desired setting is displayed, press YES to save (STORE) the setting.  
The front panel display flashes OFF and ON several times to confirm the new setting.

Repeat the above action to change the Remote Control Port Relay operating state. The Remote Control Port Relay operating state can be displayed or changed from any channel. This option is only available at the front panel.

## RF/SWIF input

The RF/SWIF setting determines if RF or SWIF input is used by the receiver for tuning the received digital signal. The selected signal input must match the input of the received digital signal. The RF/SWIF input setting can also be set via the Menu interface.

To display or change the SWIF signal input setting...

- Step 1.** Press **ALT** to change from normal operation to Alt 1 Mode. The ALT LED flashes OFF and ON, continuously.
- Step 2.** Press **0** (SWIF) to display the current SWIF signal input setting. Pressing **0** repeatedly displays available settings (ON or OFF). The default setting is OFF.
- Step 3.** When the desired setting is displayed, press YES to save (STORE) the setting. The front panel display flashes OFF and ON several times to confirm the new setting.

Repeat the above action to change the RF/SWIF input setting. When set to ON, the input signal from the SWIF IN rear panel connector is used. When set to OFF, the input signal from the RF IN rear panel connector is used. When SWIF input is set, this signal can also be used for connecting two or more receivers together in a network for signal monitoring. For more information about interconnecting receivers using SWIF signal output, see Chapter 2 (see also “MPEG Output”). This option is also available at the R39-Installer Menu.

## Signal Level

**Display only:** The Signal Level option is an Alt 1 Mode function. The displayed Signal Level (any number from 0 to 99) is associated with the Symbol Rate and signal input level.

To display the Signal Level...

- Step 1.** Press **ALT** to change from normal operation to Alt 1 Mode. The ALT LED flashes OFF and ON, continuously.
  - Step 2.** Press **6** (SIG) to display the Signal Level.
- The Signal Level can be displayed from any channel (see also “Signal Polarization”). This option is also available at the R39-Installer Menu, and at the R10-Receiver Status menu.

## Signal Polarization

The Signal Polarization option is an Alt 1 Mode function. The selected Signal Polarization must match the polarization of the received digital signal.

To display or change the Signal Polarization...

Perform the first step if you are changing the Signal Polarization.

- Step 1.** If required, press **0** to display the Installer Channel.

- Step 2.** Press **ALT** to change from normal operation to Alt 1 Mode. The ALT LED flashes OFF and ON, continuously.
- Step 3.** Press **8 (POL)** to display available settings (H [Horizontal] or V [Vertical]). The default setting is H (Horizontal).
- Step 4.** When the desired setting is displayed, press **YES** to save (**STORE**) the setting. The front panel display flashes OFF and ON several times to confirm the new setting.

Repeat the above action to change the Signal Polarization. The Signal Polarization can be displayed from any channel, but can only be changed from the Installer Channel. When Horizontal polarization is set, a 19V DC signal is output from the receiver rear panel SATELLITE connector. When Vertical polarization is set, a 13V DC signal is output from this connector. Observe the effect of the Polarization change by checking the displayed relative Signal Level value (see "Signal Level"). Higher (Signal Level) numbers are better. This option is also available at the R39-Installer Menu.

## Signal Quality (BER)

**Display only:** The BER display option is an Alt 1 Mode function. The displayed value (any number from 0 to 9) is related to the Bit Error Rate (higher numbers are better).

To display the Signal Quality...

- Step 1.** Press **ALT** to change from normal operation to Alt 1 Mode. The ALT LED flashes OFF and ON, continuously.
- Step 2.** Press **3 (BER)** to display the Signal Quality (Bit Error Rate).

The Signal Quality (BER) can be displayed from any channel. This option is also available at the R39-Installer Menu, and at the R10-Receiver Status menu.

## Signal Search

The Signal Search option is an Alt 2 Mode function. The selected setting enables or disables automatic Signal Search for the receiver (see "...About Signal Searches").

To display or change the Signal Search setting...

- Step 1.** Press **ALT** twice to change from normal operation to Alt 2 Mode. The ALT LED is ON.
- Step 2.** Press **USER (SRCH)** to display the current Signal Search setting. Pressing **USER** repeatedly displays available settings (SRCH or OFF). The default setting is OFF.
- Step 3.** When the desired setting is displayed, press **YES** to save (**STORE**) the setting. The front panel display flashes OFF and ON several times to confirm the new setting.

Repeat the above action to change (i.e., enable or disable) the Signal Search setting. A signal Search can be executed from any channel. This option is also available at the R39-Installer Menu.

## Store (Save)

The STORE option is a front panel/Alt Mode function (i.e., available with menu, Alt 1 or Alt 2 Mode operation), and is used to save changes made to the current receiver setup.

To store (save) changes...

- Step 1.** When the desired setting is displayed, press YES to save (STORE) the setting. The front panel display flashes OFF and ON several times to confirm the new setting.
- Step 2.** Pressing YES replaces the previous setting with the setting displayed at the front panel. Not pressing YES (i.e., pressing any other key) after making a change to the current receiver setup discards the change and restores the previously-saved setting.

Repeat the above action to save each new change made to the current setup. The YES button operates only after a change is made to the current receiver setup (see also “On-screen menu operation”). This option is also provided for saving changes made in menus.

## Symbol Rate

The Symbol Rate option is an Alt 1 Mode function. The selected Symbol Rate must match the Symbol Rate associated with the received digital signal.

To display or change the Symbol Rate...

Perform the first step if you are changing the Symbol Rate.

- Step 1.** If required, press **0** to display the Installer Channel.
- Step 2.** Press **ALT** to change from normal operation to Alt 1 Mode. The ALT LED flashes OFF and ON, continuously.
- Step 3.** Press **5** (SYM) to display the current Symbol Rate setting. Pressing **5** repeatedly displays higher Symbol Rates (Symbol Rates are displayed from 3 MS/s to 30.8000 MS/s in 10 KS/s steps). You can also press and hold the **5** button down to rapidly increase the Symbol Rate. The default setting is 28.3465 MS/s.
- Step 4.** When the desired setting is displayed on-screen, press YES to save (STORE) the setting. The front panel display flashes OFF and ON several times to confirm the new setting.

Repeat the above action to change to another Symbol Rate. The Symbol Rate can be displayed from any channel, but can only be changed from the Installer Channel. This option is also available at the R39-Installer Menu.



**IMPORTANT!** Certain (critical) receiver settings can only be changed from the Installer Channel (i.e., channel 0). Before making changes, verify that channel 0 is the current channel, if required. Changes made to the current setup in menus are not saved (stored) automatically (see also “Store (Save)” and “...About saving changes”).

## User

The USER option is a front panel/Alt Mode function (i.e., available with menu, Alt 1 or Alt 2 Mode operation), and is provided for displaying R39-Installer Menu Pages 1, 2 or 3, or for setting the Signal Search option (see "...About Signal Searches").

### To display the R39-Installer Menu...

- Step 1.** Press **MENU** to display the R10-Receiver Status menu.
- Step 2.** Press **2** to enable R39-Installer Menu options (instructions are displayed on-screen), and then press **9** to display the R39-Installer Menu (page 1 displays automatically).
- Step 3.** Press **USER** to display page 2. Pressing USER repeatedly displays pages 1, 2 and 3 of the R39-Installer Menu.

Repeat the above action to display page 1, page 2 or page 3 of the R39-Installer Menu. The USER button operates when menus are displayed, or when Alt 2 Mode is used to operate the receiver (see "Signal Search").

## Video Standard

The Video Standard option is an Alt 2 Mode function. The selected Video Standard must match the Video Standard associated with the received digital signal (see "...About changing the Video Standard").



**IMPORTANT!** The current Video Standard setting is used by the receiver for correct display of the video (picture) only. The satellite receiver does not convert from one Video Standard to another, such as from NTSC (525-line) to PAL-B (625-line) formats. When receiving a 525-line signal, the default Video Standard can be set to NTSC, or PAL-M. Similarly, when receiving a 625-line signal, the default Video Standard can be set to PAL-B, or PAL-N (Argentina).

### To display or change the Video Standard...

- Step 1.** Press **ALT** to change from normal operation to Alt 2 Mode. The ALT LED is on.
- Step 2.** Press **7 (VID)** to display the current Video Standard setting. Pressing **7** repeatedly displays available<sup>1</sup> settings (see Table 3-9). The default setting is 525A: NTSC->PAL/B (i.e., automatic switching from 525-line NTSC to 625-line PAL/B).
- Step 3.** When the desired setting is displayed on-screen, press **YES** to save (STORE) the setting. The front panel display flashes OFF and ON several times to confirm the new setting.

Repeat the above action to change the Video Standard. The Video Standard can be displayed or changed from any channel. This option is also available at the R39-Installer Menu.

---

<sup>1</sup> Additional Video Standard settings are available via the menu interface

Table 3-9. Available Video Standards (Alt Mode only)

Option	Description
525	NTSC 525-line
625	PAL/B 625-line
525A	Auto-switching from NTSC to 625-line PAL/B
625A	Auto-switching from PAL/B to 525-line NTSC

## Video Bit Rate

**Display only:** The Video Bit Rate display option is an Alt 1 Mode function. The displayed Video Bit Rate (any number from 1 to 15 Mb/s [Megabits/second]) is the maximum speed at which video information can be transmitted from the uplink.

To display the Video Bit Rate...

**Step 1.** Press **ALT** to change from normal operation to Alt 2 Mode.  
The ALT LED is ON.

**Step 2.** Press **9** (VBR) to display the Video Bit Rate.

The Video Bit Rate can be displayed from any channel. This option is only available at the front panel.

## View

The View option is an Alt Mode function (i.e., Alt 1 or Alt 2 Mode), and is provided for exiting from Alt Mode to video (current channel).

To exit from Alt Mode to video...


**Step 1.** Press **VIEW** to exit from Alt Mode to video (i.e., return to normal receiver operation).

You can also exit from Alt Mode to the current channel by pressing the ALT button until the ALT LED is OFF). The VIEW button operates only if menus are displayed.



## On-screen menu operation

Setting up your Professional Receiver via the menu interface requires setup of frequency-related and other options. These settings are used by the receiver for tuning the received digital signal, and for optimizing receiver performance. Not all Alt Mode interface functions are available via the menu interface.



### ...About on-screen menu operation

While viewing any channel, you can display on-screen menus for viewing or changing the current receiver setup. While in menus, you can change the current receiver settings, and/or display other menus. Some menus contain setup information which is available for viewing only, and cannot be changed. Numbered menu options are used to display other menus. Access to menus and changeable menu options is controlled by system Lock Levels. For more information about Lock Levels, see “Setting up the receiver”.



**IMPORTANT!** The functions of certain front panel buttons are changed when on-screen menus are used to operate the Professional Receiver.

On-screen menus available for display are...

- ☐ R10-Receiver Status menu
- ☐ R20-Services Menu
- ☐ R22-Sub-Menu
- ☐ R23-Tuning Mode Menu
- ☐ R28-Configuration Menu
- ☐ R35-Session Word Menu
- ☐ R39-Installer Menu (pages 1, 2 and 3)

To display on-screen menus and view the current receiver setup...

- Step 1.** Press the **MENU** button on the receiver front panel.  
The R10-Receiver Status menu is displayed.

You can only change the current receiver setup if you have changed to the Installer Channel (i.e., channel 0) before pressing the MENU button. Otherwise, you will only be able to view the current receiver settings.

- Step 2.** Move to the desired setting by pressing the NEXT button, or follow the on-screen instructions to display other menus.

Complete information about how to operate each of the on-screen menus is found on the pages that follow (see also "...About saving changes").

**To disable receiver lockout (if Lock Level 3 set)...**

If the receiver is locked out (i.e., Lock Level 3 is set), you can display setup information at the front panel only, and menus cannot be displayed.

Perform the following actions to change the receiver Lock Level setting from 3 to 0 to disable lockout. When receiver lockout is disabled, you can display menus and/or make any changes to the current setup using front panel buttons.


- Step 1.** Press **ALT** to change from normal operation to Alt 2 Mode.  
The ALT LED is ON.
- Step 2.** Press **3 (LOCK)** once to display the current Lock Level (i.e., Loc 3). Pressing **3** again displays Loc 0.
- Step 3.** Press **YES** to save (STORE) the setting.  
The front panel display flashes OFF and ON several times to confirm the new setting.

For more information about Lock Levels, see "...About Lock Levels".



**IMPORTANT!** Certain (critical) receiver settings can only be changed from the Installer Channel (i.e., channel 0). Before making changes, verify that channel 0 is the current channel, if required. Changes made to the current setup in menus are not saved (stored) automatically (see also "Store (Save)" and "...About saving changes").

## Menus at a glance



## R10-Receiver Status menu

Setting up your Professional Receiver for normal operation requires setup of frequency-related and other options. Certain information about the current receiver setup can be displayed and/or changed via the R10-Receiver Status menu, and from other menus. These settings are used by the receiver for tuning the received digital signal, and for optimizing receiver performance. Navigation to all menus is available only via the R10-Receiver Status menu.

```

Professional Receiver Status

Decoder Address      000-214-6370-9
Decoder Versions     2.60/1.05(2)
SmartCard            Not Installed
SmartCard Version    N/A
Additional Versions  2.12/1.02
ADP enc.             0 of 0 rec'd
ADP non-enc.         0 of 0 rec'd

Bit Error Rate:      0.0E-6      LOCKED
Signal Level:        62
AFC Level:           0

Press 0 to Display Services
Press 1 to clear ADP
Press 2 for Other Sub-Menus
Press VIEW to watch TV

```

To display the R10-Receiver Status menu...

**Step 1.** Press the **MENU** button at the receiver front panel.


You can view information about the current setup. Press VIEW to return to video (i.e., the current channel).

**Available options:** Press 0 to display the R20-Services Menu. Press 1 to clear the ADP count. Press 2 to display the R22-Sub-Menu. Press VIEW to return to video (current channel).

The following R10-Receiver Status information is displayed on-screen.

- Decoder Address
- Decoder Versions
- Smart Card
- Smart Card Versions
- Additional Versions
- ADP (enc)
- ADP (non-enc)
- Bit Error Rate
- Signal Level
- AFC Level

The current Bit Error Rate, Signal Level and AFC Level are also displayed at the R39-Installer Menu (see “R39-Installer Menu”).



### ...About the ADP count

The encrypted and non-encrypted Address Data Packet (or ADP) count is continuously monitored by the receiver. The information displayed on-screen for each packet type indicates how much of the transmitted packet information is being accurately received and processed by the ISE (Inboard Security Element). Under ideal conditions, both of the displayed figures are identical. To assist with monitoring your receiver's performance, you can clear or reset the ADP count to zero (0) at any time using the Reset ADP option. The ADP count is also reset each time the receiver is switched ON.

To reset the ADP count...

**Step 1.** Press 1 to clear the ADP count.  
The ADP count is reset to zero (0).

Repeat the above action to reset the ADP count. The ADP count can be reset from any channel.

### ...About Signal Level and Signal Quality

Your Professional Receiver actively monitors and updates the strength (level) and quality characteristics of the incoming signal as it is decoded, and displays this information on-screen at the R10-Receiver Status menu (and R39-Installer Menu). The Signal Level (displayed on a scale from 0 to 99) is associated with the Symbol Rate and signal input level. The displayed Bit Error Rate (i.e., corrected errors) is a measure of how much of the original signal information is being received, and is an indication of relative Signal Quality.

Certain receiver settings can cause signal loss or degradation which can compromise video or audio information. The effect of any changes you make to your satellite LNB antenna installation is immediately displayed. Signal Level and Signal Quality can also be affected by changes at the signal source, and/or by adverse environmental or terrestrial conditions. Taken in combination, certain receiver settings and signal conditions can cause the Signal Level and Signal Quality (or BER) values to increase or decrease accordingly.

Temporary, solar-related electromagnetic disturbances occur every year during the spring and autumn months. These disturbances usually persist for several minutes a day for approximately one week during these time periods. Your service provider can advise you about when authorized broadcast services may be adversely affected. For troubleshooting information, see Appendix C.

To verify your satellite LNB antenna installation or improve antenna reception, refer to your antenna equipment installation manual, or contact your dealer or service provider.

### **Decoder Address**

The displayed Decoder Address is an 11-digit number used for equipment identification.

### **Decoder Versions**

Displayed decoder version information identifies the versions of installed DCP and ISE decoder devices plus the network-specific algorithm code number (in brackets).

### **Smart Card**

Displayed information indicates that a Smart Card is installed or not installed as part of the decoder. If installed, the smart card IDentification number is displayed similar to the Decoder Address.

### **Smart Card Version**

Displayed information identifies the Smart Card version number only if a Smart Card is installed.

### **Additional Versions**

Displayed version information identifies the versions of installed KBD<sup>1</sup> and CCP<sup>2</sup> devices.

### **ADP enc. and ADP non-enc.**

Displayed information for each packet type indicates how much of the transmitted ADP (Address Data Packet) information is being accurately received and processed. Under ideal conditions, both of the displayed figures are identical (see "...About the ADP count").

### **Bit Error Rate**

**Display only:** Displayed information identifies the BER or Bit Error Rate for the received digital signal plus the signal status. The displayed Bit Error Rate BER is related to signal quality, and tends to increase when atmospheric conditions that cause signal fade exist. The BER is displayed in scientific notation. BER values ranges from 0.0E-6 under ideal conditions to 6.5E-2 under worst case conditions. The normal range for BER values is typically from 1.0E-5 to 1.0E-3 (see also Appendix F). This option is also available at the front panel.

---

<sup>1</sup> Keyboard Microcontroller

<sup>2</sup> Compression Control Processor

When the receiver is locked onto the RF input signal, the signal status message “LOCKED” is displayed beside the BER value. If RF carrier signal synchronization is temporarily interrupted or lost, the message “SEARCH” is displayed while the receiver searches for this signal (see “...About Signal Searches”).

### Signal Level

**Display only:** Displayed Signal Level and signal status information indicate the relative level or strength of the received digital signal plus the current signal state. The Signal Level is useful for antenna setup (i.e., peaking). Signal Level values range from 0 (lowest) to 99 (highest). The normal Signal Level range is typically from 30 to 50 which corresponds to an input signal level of -40 and -60 dBm. Poor picture quality can be expected when the Signal Level is near 0 or 99. When the Signal Level is extremely low, the message “NO SIGNAL” displays which may indicate that the input signal cable is faulty. This option is also available at the front panel.

### AFC Level

**Display only:** The Displayed AFC Level indicates the relative amount of LNB drift present in the received digital signal. AFC Level values range from -50 (lowest) to +50 (highest). The normal AFC Level range is typically from -10 to +10. This option is also available at the front panel.

## R20-Services Menu

Information about available satellite broadcast services and the current setup is available from the R20-Services Menu. Broadcast virtual channel services are authorized via PCC control system software to your dealer/reseller or local service provider. The current setup is also affected by your LNB antenna (dish) installation.

```

Service Info
Program : 255, Scr, ENCon, NOT AUTH
Name : MDR Live Service Five
Provider : DEFAULT PROVIDER
TxID : 100, PMT PID: 5255
L-Band : 1760.00 MHz, PCR PID: 2160
Filter : Unfiltered
Video : ON (2160)
Audio1 : ON (2120) MPEG
Audio2 : ON (2121) MPEG
Audio3 : OFF ( 0)
Audio4 : OFF ( 0)
Utility : ON (2063)
HS Data : ON (2062)
VBI : OFF ( 0)
Dnld: DCP: OFF ( 0)
CCP: OFF ( 0)
Press VIEW to watch TV
Press MENU for Main Menu
Press USER to turn on/off transparency

```

To display the R20-Services Menu...

**Step 1.** Press the MENU button at the receiver front panel to display the R10-Receiver Status menu.

**Step 2.** Press 0 to display the R20-Services Menu.

You can view information about the current setup.



**IMPORTANT!** Authorized uplink services (i.e., video, audio and data) available via receiver operating software and installed factory options are enabled via PCC (PowerVu *Plus*™ Command Center) control system software. Each of these services are associated with a unique PID number, and can be enabled or disabled separately.

**Available options:** Press VIEW to return to video (i.e., the current channel). Press MENU to display the R10-Receiver Status menu (i.e., main menu). You can also press the CHAN.▲ and CHAN.▼ buttons (front panel) to advance up or down to the available (virtual) channels. Displayed R20-Services Menu information is unique for each virtual channel.

The following available satellite broadcast services information is displayed on-screen for the current virtual channel.

- ☐ Program number/ Services status
- ☐ Program name
- ☐ Provider name
- ☐ Transport ID
- ☐ L-Band frequency
- ☐ Transport filter mode



- ☐ Video and PID<sup>1</sup> status
- ☐ Audio 1 status and PID
- ☐ Audio 2 status and PID
- ☐ Audio 3 status and PID
- ☐ Audio 4 status and PID
- ☐ Utility data status and PID
- ☐ High Speed data status and PID
- ☐ VBI status and PID
- ☐ Download DCP status and PID
- ☐ Download CCP status and PID
- ☐ PMT PID
- ☐ PCR PID

Unauthorized uplink services and/or individual services which are OFF or disabled are not available and cannot be decoded by the receiver.

The topics that follow describe each of the services available for virtual channels.

### Program number / Services status

Program number and services status information indicate the channel number and the current status of the received uplink services. Services are identified in three (3) status fields which can contain the following messages.

- ☐ **Field 1:** Scr (Scrambled services) or No Scr (Non-Scrambled services) for the current channel
- ☐ **Field 2:** ENCon (encryption of Entitlement Control Messages [ECM] is enabled) or EN-Coff (ECM encryption is disabled) or NoECM (no ECMs are being transmitted) for the current channel
- ☐ **Field 3:** AUTH (receiver is authorized) or NOT AUTH (receiver is not authorized) for the current channel

### Transport ID

Displayed Transport ID information is the Transport stream ID number for uplink services.

#### ID #

Authorized virtual channel uplink services are controlled via PCC control system software, and are associated with a Transport ID number. A unique Transport stream ID is associated with each network.

### Video status and PID

Displayed Video status and PID (Packet IDentification) information indicates the current status of the received uplink video services.

#### ON/OFF (PID #)

---

<sup>1</sup> Packet IDentification

ON (PID #) indicates that video is available for the current channel. However, video packets associated with the displayed PID # must be present in the bitstream in order for video to display. OFF (PID # 0) indicates that uplink Video service is not authorized or is unavailable for the current virtual channel.

### **Audio status and PID**

Displayed Audio status and PID information indicates the current status of the received uplink Audio 1, Audio 2, Audio 3 and Audio 4 services.

#### **ON/OFF (PID #)**

ON (PID #) indicates that Audio service is available for the current channel. However, audio packets associated with the displayed PID # must be present in the bitstream in order for audio to be present. OFF (PID # 0) indicates that uplink Audio services are not authorized or are unavailable for the current virtual channel.

Two-channel audio is provided as a standard feature. Four-channel audio is optional.

### **Utility data status and PID**

Displayed Utility (low speed) data status and PID information indicates the current status of the uplink utility data service.

#### **ON/OFF (PID #)**

ON (PID #) indicates that utility data service is available for the current channel. However, utility data packets associated with the displayed PID # must be present in the bitstream in order for utility data to be present. OFF (PID # 0) indicates that uplink utility data service is not authorized or is unavailable for the current virtual channel.

Utility data rates range from 600 to 38,400 baud, inclusive.

### **High Speed data status and PID**

Displayed high speed (RS-422 synchronous) data status and PID information indicates the current status of the uplink High Speed data service.

#### **ON/OFF (PID #)**

ON (PID #) indicates that High Speed data service is available for the current channel. However, High Speed data packets associated with the displayed PID # must be present in the bitstream in order for High Speed data to be present. OFF (PID # 0) indicates that uplink High Speed data service is not authorized or is unavailable for the current virtual channel.

### **VBI status and PID**

Displayed VBI (Vertical Blanking Interval) status and PID information indicates the current status of the uplink VBI service.

#### **ON/OFF (PID #)**

ON (PID #) indicates VBI service is available for the current channel. However, VBI packets associated with the displayed PID # must be present in the bitstream in order for VBI data to be present. OFF (PID # 0) indicates that uplink VBI service is not authorized or is unavailable for the current virtual channel.

**Download DCP/CCP status and PID**

Displayed Download (Dnld) DCP and CCP status and PID information indicates the current status of the uplink DCP/CCP software download service.

**T/ON/OFF (PID #)**

ON (PID #) indicates that Download (DCP and/or CCP) service is available for the current channel. However, Download packets associated with the displayed PID # must be present in the bitstream in order for Download data to be present. OFF (PID # 0) indicates that uplink Download service is not authorized or is unavailable for the current virtual channel. "T" indicates that a remote software download is currently in progress.

**PMT PID**

Displayed PMT (Program Map Table) information is the PMT PID number for uplink services.

**PID #**

A unique PMT PID number can be associated with each virtual channel. If used, the PMT PID identifies which packet ID contains the Program Map information.

**PCR PID**

Displayed PCR (Program Clock Reference) information is the PCR PID number for uplink services PCR synchronization.


**PID #**

A unique PCR PID number is associated with each network, and identifies which packets are being used to update the decoder local clock to the PCR (program) clock.

---

## R22-Sub-Menu

Use this menu to select either the R35-Session Word Menu or the R39-Installer Menu.



## R23-Tuning Mode Menu

Under average user circumstances, the Professional Receiver Model D9224 can be used in the PowerVu tuning mode setting, which is the factory-set default setting. To most users the mode setting is transparent. However, there are some users who require one of the other two tuning mode settings.

```

Program: 0  PID Entry Menu

1)  Video    4096
2)  Audio1   4097
3)  Audio2    0
4)  Audio3    0
5)  Audio4    0
6)  Utility   0
7)  HS Data   0
8)  PCR      4097
9)  VBI       0

USER) Tune mode: Non PowerVu

Press a # to select field
Press 0 to restore saved data
Press YES to save program
PID #'s are in decimal
Press VIEW to watch TV

```

To display the menu:

**Step 1.** Display the Professional Receiver Status menu.

**Step 2.** Sequentially press the following front panel keys : USER, NEXT, YES

The tuner mode selection menu is displayed.

**Step 3.** Press the USER key until the setting you want is displayed in the USER) field.  
The choices have the following meanings:

Tune Mode	Description
PowerVu (default)	The tuning information is taken from the NIT. If the NIT does not exist, the receiver ceases operation.
Non PowerVu	The NIT is ignored. Tuning information is taken from the R39-Installer Menu.
Fixed PID	Lets you specify PIDs to decode directly. To enter a PID value: 1. Be sure the USER) field is set to Fixed PID. 2. Enter the number (1 to 9) of the PID you want to change. 3. Key in the PID value.

## R28-Configuration Menu

Information about installed receiver startup, download operating software and factory-installed options is available from the R28-Configuration Menu. Broadcast virtual channel services are authorized via PCC control system software to your dealer/reseller or local service provider.



To display the R28-Configuration Menu...

**Step 1.** Press the MENU button at the receiver front panel to display the R10-Receiver Status menu.

**Step 2.** Press 8 to display the R28-Configuration Menu.

You can view information about receiver operating software and factory-installed options.

**Available options:** Press MENU to display the R10-Receiver Status menu (i.e., Main Menu). Press VIEW to return to video (current channel).

The following receiver operating software and factory-installed options information is displayed on-screen.

- ☐ CCP Boot Version/CRC
- ☐ DCP Boot Version/CRC
- ☐ Front End status
- ☐ High Speed Utility status
- ☐ Digital Option status
- ☐ SWIF Option status
- ☐ DVB Scrambling Option status
- ☐ L-Band option status

Authorized uplink services are enabled via PCC control system software. Unauthorized uplink services and/or individual services which are OFF or disabled are not available and cannot be decoded by the receiver.

## CCP Boot Version

Displayed CCP (Compression Control Processor) Boot Version/CRC status information indicates the current version of CCP Boot (startup) software plus the CRC (checksum), respectively. Software CRC information is not currently supported.

### CCP Boot Version/CRC

The installed CCP Boot Version software provides initialization and startup for the Compression Control Processor software. CCP software operates together with DCP (Decoder Control Processor) software (see “DCP Boot Version”).

## DCP Boot Version

Displayed DCP (Decoder Control Processor) Boot Version/CRC status information indicates the current version of DCP Boot (startup) software plus the CRC (checksum), respectively. Software CRC information is not currently supported.

### DCP Boot Version/CRC

The installed DCP Boot Version software provides initialization and startup for the Decoder Control Processor software. DCP software operates together with CCP (Compression Control Processor) software (see “CCP Boot Version”).

## Decoder front end

Displayed Front End status information identifies the installed LSI FEC (Forward Error Correction) decoder hardware and decoder type. Variable rate or fixed rate decoding capability is also indicated. All current Model D9224 Professional Receiver models support variable rate decoding.

**LSIXXXXXX (VARIABLE RATE)**

## High Speed data

Displayed High Speed data status indicates if the High Speed data decoder hardware is installed. Note that Utility (low speed) data is a separately authorized service (see “R20-Services Menu”).

### NOT Installed/Installed

If installed, authorized High Speed (RS-422 synchronous) data service can be extracted/decoded by the receiver. If not installed, no High Speed data service can be decoded. If the High Speed data option is installed and High Speed data service is authorized at the uplink (i.e., associated with one or more virtual channels), a High Speed data service PID # displayed at the R20-Services Menu.

## Digital Option

Displayed Digital data (D1 and AES3 output) status indicates if the digital hardware option is installed.

**NOT Installed/Installed**

If installed, a D1 digital video output signal (via D1 BNC connector) and AES digital audio output signals (via CH 1/CH 2 XLR3 connectors) can be supplied to other/external equipment (i.e., for signal monitoring or retransmission). No digital output signals are available if the digital option is not installed.

### **SWIF Option**

Displayed SWIF option status indicates if the SWIF IN factory option is installed (all Model D9224 Professional Receivers are equipped with a SWIF OUT connector).

#### **NOT Installed/Installed**

If installed, a SWIF (Single Wire InterFace) input signal (via a SWIF signal cable connector) can be supplied to other/external equipment (i.e., for signal monitoring or retransmission). No SWIF IN signal connection can be made if the SWIF option is not installed.

### **DVB Common Scrambling**

Displayed DVB Scrambling option status indicates if the DVB Common Scrambling decoding (hardware and software) option is installed.

#### **NOT Installed/Installed**

If installed, authorized DVB Common Scrambling services provided for video, audio and data can be decoded by the receiver. No DVB Common Scrambling services can be decoded if the DVB Scrambling option is not installed.

### **Multiple L-Band**

Displayed multiple L-Band status indicates if the multiple LNB inputs are installed.

#### **NOT Installed/Installed**

If installed, satellite signals can be received from either the LNB 1, LNB 2, LNB 3, or LNB 4 input allowing up to four satellite dishes to be connected to the receiver at the same time. If not installed, only one satellite dish can be connected to the receiver and the signal is received through the RF IN input.



---

## R35-Session Word Menu

This menu lets you enter a session word, also known as BISS (Basic Interoperable Scrambling System), from which the session key can be derived. A session key is used for descrambling a secured transmission.


BISS offers interoperability between the equipment of different Digital Satellite News Gathering (DSNG) vendors. The model requires the direct entry of a session word at the transmitter and receiver to control access to the transmission. The sender and receiver(s) of the transmission share the session word so that only the intended parties will receive the transmission. The session word should be agreed upon and communicated prior to the actual transmission. Depending on the requirement, the sender and receiver(s) might decide to change the session word from time to time.

## R39-Installer Menu

Setting up your Professional Receiver for normal operation requires setup of frequency-related and other options available from the R39-Installer Menu, and from other menus. R39-Installer Menu screens contain most of the functions needed for receiver setup. Each of the menu screens is displayed separately using receiver front panel buttons. The following figure shows all pages (i.e., page 1, page 2 and page 3) of the R39-Installer Menu. Note that some receiver settings (i.e., the current Bit Error Rate, Signal Level and AFC Level) displayed at the R39-Installer Menu are also displayed at the R10-Receiver Status menu.



**IMPORTANT!** Certain (critical) receiver settings can only be changed from the Installer Channel (i.e., channel 0). Before making changes, verify that channel 0 is the current channel. Changes made to the current setup in menus are not saved (stored) automatically (see also “Store (Save)” and “...About saving changes”).



To display the R39-Installer Menu...


- Step 1.** Press MENU to display the R10-Receiver Status menu.
- Step 2.** Press 2 to display the R22-Sub-Menu.
- Step 3.** Press 9 to display the R39-Installer Menu. (Page 1 displays automatically.)
- Step 4.** Press USER to display page 2 (pressing USER repeatedly displays R39-Installer Menu pages 1, 2 and 3, in order).

You can view or change the current setup. Press VIEW to return to video (i.e., the current channel).

**Available options:** Press the CHAN. ▲/CHAN.▼ button (front panel) to display available settings. Press NEXT to move to the next menu option. Press YES (STORE) to save the new settings. Press USER to display R39-Installer Menu Pages. Press VIEW to return to video (current channel).

## R39-Installer Menu (page 1)

Information about how to use page 1 of the R39-Installer Menu for receiver setup follows. For R39-Installer Menu display instructions, see above.



## Band Select

The Band Select setting determines the Installer Channel operating frequency band used by the receiver (see also "...About the current channel"). This option is also available at the front panel.

To change the operating band...

- Step 1.** Press USER to display page 1 of the R39-Installer Menu, if required.
- Step 2.** Move to **Band** by pressing the NEXT button.

**Step 3.** Press the CHAN. ▲/CHAN. ▼ button (front panel) to display available settings (C/L-Band Freq., C/Downlink Freq., Low Ku/L-Band Freq., High Ku/L-Band Freq., Single Ku/Downlink Freq. or Dual Ku/Downlink Freq.). The default setting is C/L-Band Freq.

**Step 4.** When the desired setting is displayed on-screen, press YES to save (STORE) the setting.

A save message displays on-screen to confirm the new setting(s).

Repeat the above action to change the operating (frequency) band. The accompanying table lists the frequency spectrum for C and Ku-Bands.

**Table 3-10. C/Ku-Band frequency ranges**

Band	Frequency Range
C-Band	3.70000 GHz to 4.20000 GHz
Ku-Band (North America)	11.70000 GHz to 12.20000 GHz
Low Ku-Band (EU)	10.70000 GHz to 11.70000 GHz
High Ku-Band (EU)	11.70000 GHz to 12.75000 GHz

## Frequency

The Frequency setting determines the current L-Band or Downlink frequency used by the receiver for tuning the received digital signal. This option is also available at the front panel.

To display or change the operating Frequency...

**Step 1.** Press USER to display page 1 of the R39-Installer Menu, if required.

**Step 2.** Move to **L-Band/Downlink Freq.** by pressing the NEXT button.

**Step 3.** Enter a valid frequency using front panel buttons. You can also press the CHAN.▲/CHAN.▼ button (front panel) to display available settings (frequencies are displayed from 950 MHz to 2050 MHz [L-Band] and from 0 GHz to 15 GHz [Downlink] in 1 MHz steps). You can also press and hold down the CHAN.▲/CHAN.▼ buttons to rapidly increase/decrease the Frequency. The default setting is 950 MHz.

**Step 4.** When the desired setting is displayed, press YES to save (STORE) the setting. A save message displays on-screen to confirm the new setting(s).

Repeat the above action to display or change the operating (Downlink/L-Band) Frequency (see also “Band Select”). A valid operating Frequency is always required.

## FEC Rate

The FEC Rate setting determines the FEC (Forward Error Correction) Rate used by the receiver for tuning the received digital signal. The FEC Rate set must match the FEC Rate associated with the received digital signal. This option is also available at the front panel.

### To display or change the FEC rate...

- Step 1.** Press USER to display page 1 of the R39-Installer Menu, if required.
- Step 2.** Move to **FEC Rate** by pressing the NEXT button.
- Step 3.** Press the CHAN.▲/CHAN.▼ button (front panel) to display available settings (1/2, 2/3, 3/4, 5/6, or 7/8). The default setting is 7/8.
- Step 4.** When the desired setting is displayed, press YES to save (STORE) the setting. A save message displays on-screen to confirm the new setting(s).

Repeat the above action to change the FEC Rate.

## Symbol Rate

The Symbol Rate setting determines the Symbol Rate used by the receiver for tuning the received digital signal. The Symbol Rate set must match the Symbol Rate associated with the received digital signal. This option is also available at the front panel.

### To display or change the Symbol Rate...

- Step 1.** Press USER to display page 1 of the R39-Installer Menu, if required.
- Step 2.** Move to **Symbol Rate** by pressing the NEXT button.
- Step 3.** Enter a valid Symbol Rate using front panel buttons. You can also press the CHAN.▲/CHAN.▼ button (front panel) to display available settings (Symbol Rates are displayed from 3 MS/s to 30.8000 MS/s in 10 KS/s steps). You can also press and hold down the CHAN.▲/CHAN.▼ buttons to rapidly increase/decrease the Symbol Rate. The default setting is 28.3465 MS/s.
- Step 4.** When the desired setting is displayed on-screen, press YES to save (STORE) the setting. A save message displays on-screen to confirm the new setting(s).

Repeat the above action to display or change to another Symbol Rate.

## Signal Polarization

The signal Polarization setting determines the signal polarization used by the receiver for tuning the received digital signal. The selected signal Polarization must match the polarization of the received digital signal. This option is also available at the front panel.

### To display or change the Signal Polarization...

- Step 1.** Press USER to display page 1 of the R39-Installer Menu, if required.
- Step 2.** Move to **Polarization** by pressing the NEXT button.
- Step 3.** Press the CHAN.▲/CHAN.▼ button (front panel) to display available settings (H [Horizontal] or V [Vertical]). The default setting is Horizontal.

**Step 4.** When the desired setting is displayed on-screen, press YES to save (STORE) the setting.

A save message displays on-screen to confirm the new setting(s).

Repeat the above action to change the signal Polarization. When a Horizontal polarization is set, a 19 volt DC signal is output via the receiver rear panel RF IN connector. When a Vertical polarization is set, a 13 volt DC signals output via this connector. Observe the effect of the Polarization change by checking the displayed relative Signal Level value (see "Signal Level"). Higher Signal Level numbers are better.

## RF/SWIF input

The Input Select setting determines if RF or SWIF input is used by the receiver for decoding the received digital signal. The selected signal input type must match the input signal connection made at the receiver rear panel (i.e., RF IN or SWIF IN). This option is also available at the front panel.

### To display or change the RF/SWIF input setting...

**Step 1.** Press USER to display page 1 of the R39-Installer Menu, if required.

**Step 2.** Move to **Input Select** by pressing the NEXT button.

**Step 3.** Press the CHAN.▲/CHAN.▼ button (front panel) to display available settings (RF or SWIF). The default setting is RF.

**Step 4.** When the desired setting is displayed on-screen, press YES to save (STORE) the setting.

A save message displays on-screen to confirm the new setting(s).

Repeat the above action to change the RF/SWIF input setting. When set to ON, the input signal from the SWIF IN rear panel connector is used. When set to OFF, the input signal from the RF IN rear panel connector is used. SWIF signal output (i.e., from the SWIF OUT connector) can be used for connecting two or more receivers together in a network for signal monitoring purposes. For more information about interconnecting receivers using SWIF signal output, see Chapter 2 (see also "MPEG Output").

## Find

The Find setting determines if the automatic Find feature is used by the receiver for finding a digital signal (see also "...About the Find option"). This option is also available at the front panel.

### To Find a signal...

**Step 1.** Press USER to display page 1 of the R39-Installer Menu, if required.

**Step 2.** Move to **Find** by pressing the NEXT button.

**Step 3.** Press the CHAN.▲/CHAN.▼ button (front panel) to Find a signal (set to ON). The default setting is OFF.

**Step 4.** When the desired signal is found (i.e., "LOCKED" status displayed on-screen), press YES to save (STORE) the setting.

A save message displays on-screen to confirm the new setting(s).

Repeat the above action to Find another signal. When a signal is found, the Find option is automatically set to OFF. You can also terminate the search manually by setting the Find option to OFF.

### Bit Error Rate (Signal Quality)

**Display only:** The displayed Bit Error Rate identifies the relative Signal Quality for the received digital signal, and is a measure of how much of the original signal information is being received (see "...About Signal Level and Signal Quality"). The Bit Error Rate can also be displayed via the Alt Mode interface. The Bit Error Rate is continuously monitored and updated by the receiver (see also "...About Signal Searches"). This display option is also available at the front panel.

#### To display the Bit Error Rate...

**Step 1.** Press USER to display page 1 of the R39-Installer Menu, if required.

The Bit Error Rate tends to increase when atmospheric conditions that cause signal fade exist. The BER (displayed in scientific notation) ranges from 0.0E-6 in ideal conditions to 6.5E-2 for worst case conditions. The normal range for BER values is typically from 1.0E-5 to 1.0E-3.

When the receiver is locked onto the RF input signal, the signal status message "LOCKED" is displayed beside the BER value. If RF carrier signal synchronization is temporarily interrupted or lost, the message "SEARCH" is displayed while the receiver searches for this signal (see "...About Signal Searches").

### Signal Level

**Display only:** The displayed Signal Level indicates the relative level or strength of the received digital signal. The Signal Level can also be displayed via the Alt Mode interface. The Signal Level is continuously monitored and updated by the receiver. This display option is also available at the front panel.

#### To display the Signal Level...

**Step 1.** Press USER to display page 1 of the R39-Installer Menu, if required.

The Signal Level is useful for antenna setup (i.e., peaking), and ranges from 0 (lowest) to 80 (highest). The normal Signal Level range is typically from 30 to 60 which corresponds to an input signal level of -40 and -60 dBm. Poor picture quality can be expected when the current Signal Level is near zero. When the Signal Level is extremely low, the message "NO SIGNAL" displays which may indicate that the input signal cable is faulty.

### AFC Level

**Display only:** The displayed AFC Level indicates the relative amount of LNB drift present in the received digital signal. The AFC Level is continuously monitored and updated by the receiver. This display option is also available at the front panel.


#### To display the AFC Level...

**Step 1.** Press USER to display page 1 of the R39-Installer Menu, if required.

The AFC Level ranges from -30 (lowest) to +30 (highest). The normal AFC Level range is typically from -10 to +10 (corresponding to  $\pm 1.0$  MHz).

## R39-Installer Menu (page 2)

Information about how to use page 2 of the R39-Installer Menu for receiver setup follows. For R39-Installer Menu display instructions, see the beginning of this section. Page 2 of the R39-Installer Menu can only be displayed from page 1.



### Seconds to NO SIGNAL

The “Seconds to NO SIGNAL” setting determines the preset time-out period (in seconds) following a loss of signal to the receiver after which the “NO SIGNAL” message is displayed (see also “Signal Level”).

#### To display or change the NO SIGNAL time-out...

- Step 1.** Press USER to display page 2 of the R39-Installer Menu, if required.
- Step 2.** Enter a valid time-out value using front panel buttons. You can also press the CHAN.▲/CHAN.▼ button (front panel) to display available settings (settings are displayed from 0 to 30 seconds). The default setting is 5 seconds. You can also press and hold down the CHAN.▲/CHAN.▼ buttons to rapidly increase/decrease the settings. The default setting is 5 seconds.
- Step 3.** When the desired setting is displayed on-screen, press YES to save (STORE) the setting.  
A save message displays on-screen to confirm the new setting(s).

Repeat the above action to display or change the “Seconds to NO SIGNAL” time-out.

### Network ID

The Network ID setting determines the Network ID used by the receiver for tuning the received digital signal. The Network ID set must match the Network ID associated with the received digital signal (see also “...About the Network ID”).



### To display or change the Network ID...

- Step 1.** Press USER to display page 2 of the R39-Installer Menu, if required.
- Step 2.** Move to **Network ID** by pressing the NEXT button.
- Step 3.** Enter a valid Network ID using front panel buttons. You can also press the CHAN.▲/CHAN.▼ button (front panel) to display available settings (Network ID values are displayed from 0 to 65535). You can also press and hold down the CHAN.▲/CHAN.▼ buttons to rapidly increase/decrease the settings. The default setting is 1.



**IMPORTANT!** Although the Network ID is preset at the factory to a default of 1, contact your service provider to find out what your network ID is and enter that number in the Network ID field.

- Step 4.** When the desired setting is displayed on-screen, press YES to save (STORE) the setting.  
A save message displays on-screen to confirm the new setting(s).

Repeat the above action to display or change to another Network ID. A valid Network ID is required for operating the Professional Receiver in a DVB network.

### Bouquet ID

The Bouquet ID setting determines the Bouquet ID used by the receiver for tuning the received digital signal, if existing. The Bouquet ID set must match the Bouquet ID associated with the received digital signal, if required (see also "...About the Network ID").

### To display or change the Bouquet ID...

- Step 1.** Press USER to display page 2 of the R39-Installer Menu, if required.
- Step 2.** Move to **Bouquet ID** by pressing the NEXT button.
- Step 3.** Enter a valid Bouquet ID using front panel buttons. You can also press the CHAN.▲/CHAN.▼ button (front panel) to display available settings (Bouquet ID values are displayed from 0 to 65535). You can also press and hold down the CHAN.▲/CHAN.▼ buttons to rapidly increase/decrease the settings. The default setting is 1.
- Step 4.** When the desired setting is displayed on-screen, press YES to save (STORE) the setting.  
A save message displays on-screen to confirm the new setting(s).

Repeat the above action to display or change to another Bouquet ID. A valid Bouquet ID may be required for operating the Professional Receiver in a DVB sub/network.

## Video Standard

The Video Standard setting determines the Video Standard used by the receiver for decoding the received digital signal. The Video Standard set must match the Video Standard associated with the received digital signal (see also "...About changing the Video Standard"). This option is also available at the front panel.



**IMPORTANT!** The current Video Standard setting is used by the receiver for correct display of the video (picture) only. The satellite receiver does not convert from one Video Standard to another, such as from NTSC (525-line) to PAL-B (625-line) formats. When receiving a 525-line signal, the default Video Standard can be set to NTSC, or PAL-M. Similarly, when receiving a 625-line signal, the default Video Standard can be set to PAL-B, or PAL-N (Argentina).

To display or change the Video Standard...

- Step 1.** Press USER to display page 2 of the R39-Installer Menu, if required.
- Step 2.** Move to **Video Standard** by pressing the NEXT button.
- Step 3.** Press the CHAN.▲/CHAN.▼ button (front panel) to display available settings (see Table 3-11). The default setting is 525A:NTSC>PAL/B.
- Step 4.** When the desired setting is displayed on-screen, press YES to save (STORE) the setting.  
A save message displays on-screen to confirm the new setting(s).

Repeat the above action to change the Video Standard. Table 3-11 lists available Video Standard options.

**Table 3-11. Available Video Standards**

Option	Description
525:NTSC	NTSC 525-line Video Standard
525:PAL/M	PAL/M 525-line Video Standard
625:PAL/B	PAL/B 625-line Video Standard
625:PAL/N	PAL/N 625-line Video Standard
625:PAL(N)	PAL/(N) 625-line Video Standard
525A:NTSC>PAL/B	Auto-switching from NTSC to 625-line PAL/B
525A:NTSC>PAL/N	Auto-switching from NTSC to 625-line PAL/N
525A:NTSC>PAL/(N)	Auto-switching from NTSC to 625-line PAL/N
525A:PAL/M>PAL/B	Auto-switching from PAL/M to 625-line PAL/B
525A:PAL/M>PAL/N	Auto-switching from PAL/M to 625-line PAL/N
525A:PAL/M>PAL/(N)	Auto-switching from PAL/M to 625-line PAL/(N)
625A:PAL/B>NTSC	Auto-switching from PAL/B to 525-line NTSC
625A:PAL/B>PAL/M	Auto-switching from PAL/B to 525-line PAL/M

Option	Description
625A:PAL/N>NTSC	Auto-switching from PAL/N to 525-line NTSC
625A:PAL/N>PAL/M	Auto-switching from PAL/N to 525-line PAL/M
625A:PAL/N>NTSC	Auto-switching from PAL/N to 525-line NTSC
625A:PAL/(N)>PAL/M	Auto-switching from PAL/(N) to 625-line PAL/M

### ...About I-Q signal inversion

The I-Q Select function provides automatic or manual tracking and selection of inverted and non-inverted digital QPSK signals. When set to Automatic, the I-Q Select function tracks the received digital signal and inverts the signal automatically for correct selection, as required. When set to Inverted, the received digital signal is always inverted. Conversely, when set to Non-Inverted, the received digital signal is never inverted. The I-Q Select function is normally set to Automatic/ Auto Switch. The I-Q Select Inverted and Non-Inverted settings can be used to automatically reject or filter out unwanted QPSK signals.

To display or change the I-Q Select option...

- Step 1.** Press USER to display page 2 of the R39-Installer Menu, if required.
- Step 2.** Move to **I-Q Select** by pressing the NEXT button.
- Step 3.** Press the CHAN.▲/CHAN.▼ button (front panel) to display available settings (Automatic/ Auto Switch<sup>1</sup>, Inverted or Non-Inverted). The default setting is OFF.
- Step 4.** When the desired setting is displayed on-screen, press YES to save (STORE) the setting.  
A save message displays on-screen to confirm the new setting(s).

Repeat the above action to change the Signal Search setting. Unless otherwise recommended, I-Q Select should normally be set to Automatic (default). For information about default receiver settings, see "Default receiver settings".

### MPEG Output

The MPEG Output setting determines if the signal appearing at the SWIF OUT and the DVB/ASI OUT connector contains the complete incoming MPEG-2 transport stream (i.e., all authorized virtual channel services), or a filtered transport stream (i.e., current channel virtual services only).

To display or change the MPEG Output filter setting...

- Step 1.** Press USER to display page 2 of the R39-Installer Menu, if required.
- Step 2.** Move to **MPEG Output** by pressing the NEXT button.

---

<sup>1</sup> Some versions not equipped with Auto Switch fixed delay and variable delay (2-60 second)

**Step 3.** Press the CHAN.▲/CHAN.▼ button (front panel) to display available settings (Filtered or Unfiltered). The default setting is Unfiltered.

**Step 4.** When the desired setting is displayed on-screen, press YES to save (STORE) the setting.  
A save message displays on-screen to confirm the new setting(s).

Repeat the above action to change the MPEG Output setting. When set to Unfiltered, all service PID (Packet IDentifier) and PSI (Program-Specific Information) received as part of the encoded digital signal appears at the SWIF OUT connector. If set to Filtered, service PID information associated with the current virtual channel only appears at the SWIF OUT and the DVB/ASI OUT connectors. The MPEG Output setting does not affect receiver operation even if the SWIF signal output is not used, regardless of whether a RF or SWIF input signal is used to operate the receiver.

### C-Band LO frequency

The C-Band Local Oscillator frequency setting determines the Local Oscillator frequency used by the receiver for tuning the received digital signal only when C-Band operation (i.e., C/L-Band Freq. or C/Downlink Freq.) is set (see also “

Band Select”).

To display or change the C-Band Local Oscillator frequency...

**Step 1.** Press USER to display page 2 of the R39-Installer Menu, if required.

**Step 2.** Move to **C-Band LO** by pressing the NEXT button.

**Step 3.** Enter a valid frequency using front panel buttons. You can also press the CHAN.▲/CHAN.▼ button (front panel) to display available settings (frequencies are displayed from 0 GHz to 15 GHz in 1 MHz steps). You can also press and hold down the CHAN.▲/CHAN.▼ buttons to rapidly increase/decrease the frequency. The default setting is 5.150 GHz.

**Step 4.** When the desired setting is displayed on-screen, press YES to save (STORE) the setting.  
A save message displays on-screen to confirm the new setting(s).

Repeat the above action to change the C-Band Local Oscillator frequency.

### Ku-Band Low/Single LO frequency

The Ku Low/Single LO frequency setting determines the Local Oscillator frequency used by the receiver for tuning the received digital signal only when Low Ku/L-Band Freq. or Single Ku/L-Band Freq. operation is set for use with a single LNB system (see also “

Band Select”).

To display or change the Ku-Band Low/Single LO frequency...

**Step 1.** Press USER to display page 2 of the R39-Installer Menu, if required.

- Step 2.** Move to **Ku Low/Single LO** by pressing the NEXT button.
- Step 3.** Enter a valid frequency using front panel buttons. You can also press the CHAN.▲/CHAN.▼ button (front panel) to display available settings (frequencies are displayed from 0 GHz to 15 GHz in 1 MHz steps). You can also press and hold down the CHAN.▲/CHAN.▼ buttons to rapidly increase/decrease the frequency. The default setting is 9.750 GHz.
- Step 4.** When the desired setting is displayed on-screen, press YES to save (STORE) the setting.  
A save message displays on-screen to confirm the new setting(s).

Repeat the above action to change the Ku Low/Single LO frequency.

### Ku High Band LO frequency

The Ku High Band LO frequency setting determines the Local Oscillator frequency used by the receiver for tuning the received digital signal only when High Ku/L-Band Freq. or Single Ku/L-Band Freq. operation is set (see also “

Band Select”).

To display or change the Ku High Band LO frequency ...

- Step 1.** Press USER to display page 2 of the R39-Installer Menu, if required.
- Step 2.** Move to **Ku High Band LO** by pressing the NEXT button.
- Step 3.** Enter a valid frequency using front panel buttons. You can also press the CHAN.▲/CHAN.▼ button (front panel) to display available settings (frequencies are displayed from 0 GHz to 15 GHz in 1 MHz steps). You can also press and hold down the CHAN.▲/CHAN.▼ buttons to rapidly increase/decrease the frequency. The default setting is 10.600 GHz.
- Step 4.** When the desired setting is displayed on-screen, press YES to save (STORE) the setting.  
A save message displays on-screen to confirm the new setting(s).

Repeat the above action to change the Ku High Band LO frequency.

### Ku Band Switch LO Crossover frequency

The Ku Band Switch frequency setting determines the Local Oscillator crossover frequency used by the receiver for tuning the received digital signal only when Dual Ku/L-Band Freq. is set for dual-LNB system operation (see also “

Band Select”). Dual-LNB system operation also requires correct setup of the Ku Low/Single LO plus the Ku High Band LO frequencies.

To display or change the Ku Band LO Crossover frequency...

- Step 1.** Press USER to display page 2 of the R39-Installer Menu, if required.
- Step 2.** Move to **Ku High Switch** by pressing the NEXT button.

- Step 3.** Enter a valid frequency using front panel buttons. You can also press the CHAN.▲/CHAN.▼ button (front panel) to display available settings (frequencies are displayed from 0 GHz to 15 GHz in 1 MHz steps). You can also press and hold down the CHAN.▲/CHAN.▼ buttons to rapidly increase/decrease the frequency. The default setting is 11.700 GHz.
- Step 4.** When the desired setting is displayed on-screen, press YES to save (STORE) the setting.  
A save message displays on-screen to confirm the new setting(s).

Repeat the above action to change the Ku Band Switch LO crossover frequency.

### L-Band Input selection

The L-Band Input selection indicates which of the four L-Band inputs is currently being used as the signal source (on the rear panel of the receiver, L-Band Input 1 refers to LNB 1 input, L-Band Input 2 refers to LNB 2 input, L-Band Input 3 refers to LNB 3 input, and L-Band Input 4 refers to LNB 4 input). Be sure that all settings on each of the three R39-Installer Menu pages are appropriate for the current L-Band Input selection.



**IMPORTANT!** This field is displayed only if your receiver is equipped with the four LNB rear panel inputs that are part of the four L-Band Input option.

To display or change the L- Band Input selection...


- Step 1.** Press USER to display page 2 of the R39-Installer Menu, if required.
- Step 2.** Move to **L-Band Input** by pressing the NEXT button.
- Step 3.** Press the CHAN.▲/CHAN.▼ button (front panel) to change between inputs 1 to 4.
- Step 4.** When the desired setting is displayed, press YES to save (STORE) the setting.  
A save message displays on-screen to confirm the new setting(s).



**IMPORTANT!** The L-Band inputs will not function unless the RF loopback is installed correctly on the rear panel of the receiver. Refer to the equipment installation section of this manual to be sure the RF loopback is installed properly.

## R39-Installer Menu (page 3)

Information about how to use page 3 of the R39-Installer Menu for receiver setup follows. For R39-Installer Menu display instructions, see the beginning of this section. Page 3 of the R39-Installer Menu can only be displayed from page 2.



### ...About other Search Setup options

Signal searches are constrained or limited by the current Search Type and the boundary settings for the Lower and Upper Search Limit frequency (range). When searching for a signal, the receiver uses the Search Type as the primary search criteria. For example, if Frequency Only is set as the Search Type, only signals that match the current FEC Rate (set at the R39-Installer Menu, page 1) within the current Lower/Upper Search Limit frequency boundaries are examined for a possible match. Signals associated with all other FEC Rates are ignored (see also "...About I-Q signal inversion").

### Signal Search

The Search setting determines if automatic Signal Search is used by the receiver for recovering the digital carrier signal if signal loss occurs (see also "...About Signal Searches"). This option is also available at the front panel.

#### To display or change the Signal Search setting...

- Step 1.** Press USER to display page 3 of the R39-Installer Menu, if required.
- Step 2.** Move to **Search** by pressing the NEXT button.
- Step 3.** Press the CHAN.▲/CHAN.▼ button (front panel) to display available settings (ON or OFF). The default setting is OFF.
- Step 4.** When the desired setting is displayed on-screen, press YES to save (STORE) the setting.  
A save message displays on-screen to confirm the new setting(s).

Repeat the above action to change the Signal Search setting.

## Search Type

The Search Type setting determines the primary search criteria used with automatic Signal Search for recovering the digital carrier signal if signal loss occurs (see also "...About Signal Searches").

### To display or change the Search Type...

- Step 1.** Press USER to display page 3 of the R39-Installer Menu, if required.
- Step 2.** Move to **Search Type** by pressing the NEXT button.
- Step 3.** Press the CHAN.▲/CHAN.▼ button (front panel) to display available settings (FEC Rate Only, Frequency & FEC or Frequency Only). The default setting is Frequency Only (see Table 3-12).
- Step 4.** When the desired setting is displayed on-screen, press YES to save (STORE) the setting.  
A save message displays on-screen to confirm the new setting(s).

Repeat the above action to change the Search Type. Setting the Search Mode to ON enables the signal search for automatic activation. You can disable the signal search option by setting the Search Mode to OFF.

**Table 3-12. Available Search Type options**

Option	Description
FEC Rate Only	Search by FEC Rate
Frequency & FEC	Search by Frequency and FEC
Frequency Only	Search by Frequency

## Upper Search Limit

The Upper Search Limit setting determines the highest frequency in the range used with automatic Signal Search for recovering the digital carrier signal if signal loss occurs (see also "...About Signal Searches").

### To display or change the Upper Search Limit (frequency)...

- Step 1.** Press USER to display page 3 of the R39-Installer Menu, if required.
- Step 2.** Move to **Upper Search Limit** by pressing the NEXT button.
- Step 3.** Enter a valid frequency using front panel buttons only (the CHAN.▲ or CHAN.▼ [front panel] button cannot be used to display available settings). Frequencies from 0 GHz to 15 GHz can be set. The default setting is 1450.00 MHz.
- Step 4.** When the desired setting is displayed, press YES to save (STORE) the setting.  
A save message displays on-screen to confirm the new setting(s).

Repeat the above action to change the Upper Search Limit frequency.



## Lower Search Limit

The Lower Search Limit setting determines the lowest frequency in the range used with automatic Signal Search for recovering the digital carrier signal if signal loss occurs (see also "...About Signal Searches").

To display or change the Lower Search Limit (frequency)...

- Step 1.** Press USER to display page 3 of the R39-Installer Menu, if required.
- Step 2.** Move to **Lower Search Limit** by pressing the NEXT button.
- Step 3.** Enter a valid frequency using front panel buttons only (the CHAN.▲ or CHAN.▼ [front panel] buttons cannot be used to display available settings). Frequencies from 0 GHz to 15 GHz can be set. The default setting is 950.00 MHz.
- Step 4.** When the desired setting is displayed, press YES to save (STORE) the setting. A save message displays on-screen to confirm the new setting(s).

Repeat the above action to change the Lower Search Limit frequency.



---

# Chapter 4 Maintenance

Normal operation of the PowerVu *Plus*™ Model D9224 Professional Receiver requires periodic maintenance.

## About this chapter

This chapter provides complete operating instructions for maintaining the Model D9224 Professional Receiver. It contains the following topics.

## Contents

**Maintenance.....4-2**

**Preventative maintenance .....4-2**

# Maintenance

The Model D9224 Professional Receiver chassis has no internal, user-serviceable parts. Refer servicing of this product to qualified personnel only.

---

## Preventative maintenance

The Model D9224 Professional Receiver can operate unattended for extended periods of time. However, periodic visual inspection is recommended to ensure continued and safe operation. Perform a quarterly visual inspection as per Table 4-1.

Table 4-1. Preventative maintenance

Inspect...	To ensure that...
Chassis	<ul style="list-style-type: none"><li>• Mechanical damage or evidence of overheating is not present</li><li>• All chassis air vents are unobstructed and free of dust and debris (clean<sup>1</sup>/dust or vacuum when necessary)</li><li>• Receiver is not operated in environments where air flow is restricted, or where ambient temperatures are outside the specified range</li></ul>
External cables and connections	<ul style="list-style-type: none"><li>• All cables are properly mated, and that all connectors and retainers are correctly installed and tightened</li><li>• Cables and connectors are not stressed or subjected to abrasion or contact with sharp surfaces</li></ul>

---

<sup>1</sup> Do not permit any liquids to penetrate the chassis interior (use non-corrosive liquid cleaners only)

---

# Appendix A Customer Support Information

## About this Appendix

This Appendix provides important information about your PowerVu *Plus* Model D9224 Professional Receiver. Refer to this section for:

- ❑ Product support and contact information
- ❑ Product warranty/return details

## Contents

<b>Customer support information .....</b>	<b>A-2</b>
<b>Product support .....</b>	<b>A-2</b>
Hotline technical support.....	A-3
Training support .....	A-3
Warranty and post-warranty support.....	A-3
Customer responsibility .....	A-3
In case of a fault.....	A-3
<b>Product return .....</b>	<b>A-4</b>

## Customer support information

This Appendix provides important information about your PowerVu *Plus* Model D9224 Professional Receiver. Refer to this section for:

- ☐ Product support and contact information
- ☐ Product warranty/return details

---

### Product support

Scientific-Atlanta provides customers with 24-hour hotline support from anywhere in the world. If you require technical assistance or product training support, or if you have any questions concerning your Scientific-Atlanta product, contact the appropriate Customer Support Center from those listed below.

If you call from...	Support Location	Regular Hours	After Hours	Fax
USA or Canada	<ul style="list-style-type: none"> <li>• Atlanta, Georgia, USA</li> <li>• Toronto, Ontario, Canada</li> </ul>	<b>Toll-free: 1-888-949-4786</b>	<b>Toll-free: 1-888-949-4786</b>	<b>1-770-903-5567</b>
South America	Buenos Aires, Argentina	<b>+54-1-342-0321</b>	<b>1-770-903-4786</b>	<b>+54-1-325-5900</b>
Europe, Middle East or Africa	London, England	<b>Toll-free (within Europe): 1-800-220-145</b>  <b>Direct:</b> <b>Material return/tracking: +44-1923-271460</b>  <b>Decoder support: +44-1923-271467</b>  <b>Uplink/software support: +44-1923-271420</b>	<b>1-770-903-4786</b>	<b>+44-1923-269018</b>
Asia or Australia	Sydney, Australia	<b>Toll-free: 1-800-500-518</b> or <b>Direct: +61-2-9975-3678</b>	<b>1-770-903-4786</b>	<b>+61-2-9451-4432</b>

Media Networks customers who call a Customer Support Center are asked specific questions in order to identify their needs. In this way, each call can be directed to the customer support representative most experienced with your Scientific-Atlanta product. Customer Support Centers also provide the following pre- and post-sales support services for Scientific-Atlanta products.

## Hotline technical support

24-hour hotline technical support services are available to answer technical questions about the operation, maintenance and repair of Scientific-Atlanta products.

## Training support

On and off-site training plus technical support services are available for both equipment operators and system administrators.

## Warranty and post-warranty support

Warranty and post-warranty support services are available to assist customers returning Scientific-Atlanta products for service or repair. For complete product warranty information, see the beginning pages of this guide.

## Customer responsibility

When returning equipment, the customer is solely responsible for equipment packaging and transportation costs both to and from the factory.

At the customer's request, Scientific-Atlanta will make reasonable efforts to provide warranty service at the customer's premises, provided that the customer pays current field service rates plus direct travel and accommodation expenses.

## In case of a fault

If an equipment fault develops, perform following steps. For complete information, see "Product return".

1.	<ul style="list-style-type: none"> <li>• Notify Scientific-Atlanta of the problem immediately, providing the model number and serial number of the equipment plus details of the problem. On receipt of this information, service information and shipping instructions will be provided.</li> </ul>
2.	<ul style="list-style-type: none"> <li>• On receipt of instructions, return the product by prepaid freight.</li> <li>• If the product or fault is not covered under warranty, Scientific-Atlanta will provide an estimate of repair charges in advance of any work performed.</li> </ul>

## Product return

To return any Scientific-Atlanta product for repair or replacement, follow the steps below. To be eligible for credit, a Material Return Authorization (RMA) number must accompany each product returned to Scientific-Atlanta. This number can only be obtained from your local Scientific-Atlanta Customer Support Center in advance of product return. Be sure to include this number in all correspondence.

1.	Telephone your regional Customer Support Center or call <b>1-416-299-6888</b> , or fax Scientific-Atlanta and request a Material Return Authorization for product return.
2.	Tag or label the product with the following information. <ul style="list-style-type: none"> <li>• Your name and full return address</li> <li>• Telephone contact number</li> <li>• RMA number</li> <li>• Sales order (if available)</li> <li>• Purchase order (if available)</li> <li>• Date the product was received</li> <li>• Brief description of problems</li> </ul>
3.	Repackage the product using the original carton and packing materials, if possible. If the original packaging is not available, repackage the product using a suitable corrugated carton (or similar shipping container). Be sure to wrap the product in sufficient protective packaging to prevent damage to the equipment during shipment.
4.	Print or attach the following information on the outside of the carton or shipping container. <ul style="list-style-type: none"> <li>• The full shipping address</li> <li>• Your name, your business name and full return address</li> <li>• Contact telephone number</li> <li>• RMA number</li> </ul>
5.	Ship the product prepaid and insured to the Scientific-Atlanta Customer Support Center (or other repair location) as directed. If you are unsure about where to ship the product, contact your local Scientific-Atlanta Customer Support Center, Scientific-Atlanta dealer or distributor. <b>Note:</b> Scientific-Atlanta does not accept freight collect. Be sure to prepay all return shipments.



---

# Appendix B Technical Information

## About this Appendix

This Appendix provides important information about your PowerVu *Plus* Professional Receiver. Scientific-Atlanta product specifications are subject to change without notice. Refer to this section for:

- ☐ Specifications
- ☐ Standard features and available options

## Contents

Technical Information ..... B-2

## Technical Information

Table B-1 lists standard features, available options and product specifications information for the PowerVu Plus Model D9224 Professional Receiver.

Table B-1. Product specifications

System	Description
System:	MPEG-2/DVB Compatible
Modulation:	QPSK
Inner FEC:	Variable (1/2, 2/3, 3/4, 5/6 or 7/8)
Outer) FEC:	Reed Solomon, T=8
Transport:	MPEG-2
Tuner	Description
Inputs	4 Switched
Tuner Input Level:	-30 dBm through -65 dBm per carrier
Frequency Range:	950 MHz through 2050 MHz
Tuning Stepsize:	250 kHz
Symbol Rate Range:	3.0 to 30.8 Msymbols/s
Stepsize:	100 symbols/s
Carrier Capture Range:	$\pm 1.5$ MHz
Carrier Acquisition Time:	< 2 seconds
Satellites:	C Band and Ku Band
Impedance:	75 $\Omega$
Video Output	Description
Video Decompression Type:	MPEG-2 4:2:2/4:2:0
Video Output Level:	100 IRE $\pm 5\%$ (NTSC) and 1.0 V p-p $\pm 5\%$
Frequency Response:	-2 dB @ 5.0 MHz, 720 X 480/576 sample density, and -2 dB @ 3.0 MHz, 544 X 480/576 sample density
Maximum Video Resolution :	720 x 576
Chroma-Luma Delay:	$\pm 26$ ns
Field Time Distortion:	$\leq 3$ IRE (NTSC), and $\leq 2\%$ (PAL)
Line Time Distortion:	$\leq 1\%$ max.
Short Time Distortion:	$\leq 2\%$
Luminance Non-Linearity:	$\leq 5\%$
Differential Gain:	$\leq 4$ IRE (NTSC), and $\leq 4\%$ (PAL)
Differential Phase:	2•
Signal-To-Noise-Ratio:	$\geq 56$ dB
VBI Line Insertion	Lines 10-22 (NTSC) fields 1 and 2 or PAL lines 7-22

Audio Outputs	Description
Number of Channels:	Two (2) stereo pairs, or four (4) monaural channels
Balanced Audio Output:	2 Balanced (adjustable) audio outputs are factory set for unity gain (0 dBm out for 0 dBm in). Range is adjustable from -10 to +2 dB, providing a maximum output of up to +18 dBm into 600 $\Omega$ .
Frequency Response:	$\pm 2$ dB (20 Hz to 20 kHz)
Total Harmonic Distortion:	$\leq 0.3\%$ @ 1 kHz
Dynamic Range:	75 dB (CCIR/Arm weighting)
Crosstalk:	60 dB
Expansion Port	Description
Utility Data:	RS-232 asynchronous data at rates up to 38400 b/s (settings of 300, 1200, 2400, 4800, 9600, 19200, and 38400)
Outputs:	Eight open-collector for control of external devices
Serial Remote Control : and monitoring outputs	RS-232 data at rates of 600, 1200, 2400, 4800 and 9600 b/s
Transport Input/Output	Description
MPEG-2 Input:	Scientific-Atlanta SWIF link, MPEG-2 transport format with multiplexed video, audio and data
Digital Video Output	(D1, serial interface SMPTE 259M)
Digital Audio Output	(CH 1/CH 2, serial interface AES/EBU format)
MPEG-2 Output:	Scientific-Atlanta SWIF link, MPEG-2 and DVB-ASI transport format with multiplexed video, audio and data
Environmental	Description
Operating Temperature:	0 • C to 50 • C (32 • F to 122 • F)
Storage Temperature:	-40 • C to 60 • C (-40 • F to 140 • F)
Relative Humidity:	5% to 95% (non-condensing)
Physical	Description
Dimensions:	3.5 inches H X 19.0 inches W X 13.3 inches D (8.9 cm H X 48.3 cm W X 33.8 cm D)
Chassis:	2U height for EIA standard (19-inch wide rack) mounting
Weight:	10 lbs. (4.5 kg) approx.
Power Requirements	Description
Voltage Range:	100 VAC to 240 VAC $\pm 10\%$ nominal
Line Frequency:	47 Hz to 63 Hz
Power Consumption:	63W max.
LNB Drive Voltage: (three-position slide switch)	Position 1 (19 VDC @ 450 mA max.) Position 2 (OFF) Position 3 (+13 VDC/+19 VDC @ 450 mA max.), H/V controlled output for dual mode applications

Connectors and Controls	Description
SATELLITE (input):	F type (4 inputs with one active at a time)
VIDEO (output):	BNC type
AUDIO, L & R, balanced (output):	L (Left +/-), R (Right +/-), and G (Gnd) detachable terminal block
EXPANSION PORT (I/O):	25-pin D, female (Utility Data)
LNB PWR drive voltage (output): 19V OFF 3/19V	3-position slide switch
Level Control (output): L & R balanced	Trimmer potentiometers

---

# Appendix C Troubleshooting

## About this Appendix

This Appendix provides important information about your PowerVu *Plus* Model D9224 Professional Receiver. Refer to this section for:

❑ Troubleshooting Guide

Product troubleshooting information is provided in this Appendix to help resolve operating problems with the PowerVu *Plus* Model D9224 Professional Receiver. Servicing of installed equipment should only be performed by qualified technical personnel. For complete operating instructions and other important information about your receiver, refer to this Installation and Operation Guide. For additional application and troubleshooting information, see Appendix F. For additional reference information, see Appendix G.

## Contents

**Troubleshooting Guide..... C-2**

## Troubleshooting Guide

The information in this troubleshooting guide is provided to help you resolve operating problems with the PowerVu *Plus* Model D9224 Professional Receiver. If you have any questions about this product, contact your local Customer Support Center. For information about how to contact Scientific-Atlanta for customer service or technical assistance, see Appendix A Customer Information. For product warranty information, see the beginning pages of this manual.



**IMPORTANT!** Note that temporary, solar-related electromagnetic disturbances occur every year during the spring and autumn months. These disturbances usually persist for several minutes a day for approximately one week during these periods. Your service provider can advise you about when authorized services may be adversely affected. If you are unable to resolve your problem after consulting this Troubleshooting guide, contact your dealer/reseller or local service provider for assistance, or contact your local Scientific-Atlanta Customer Support Center.

Table C-1. Troubleshooting Checklist

Symptom	Possible Causes	Remedies
Front panel display is off	Receiver is unplugged or AC power is interrupted	<ul style="list-style-type: none"> <li>Check the AC power cord and electrical outlet</li> </ul>
Front panel displays "●" only	Receiver is OFF (on stand-by)	<ul style="list-style-type: none"> <li>Press the STANDBY button on the front panel to activate the receiver</li> </ul>
No signal Signal Level <20	No DC power supplied to LNB  Faulty LNB or cable connection	<ul style="list-style-type: none"> <li>Check external LNB DC power source (if external power supply used), or verify that the LNB power switch (receiver rear panel) is set to ON (if internal power supply used)</li> <li>Check cable, and measure LNB power output voltage (normally 13V or 19V DC <math>\pm 10\%</math>) (see also Appendix B)</li> <li>Check that LNB cable does not exceed maximum length, and/or that signal splitters do not have missing terminations which can cause excessive signal loss</li> </ul>
No signal Signal Level >20	Incorrect receiver settings  Incorrect LNB polarity  Incorrect antenna orientation  Line-of-Sight obstruction	<ul style="list-style-type: none"> <li>Check RF frequency and other front panel/menu setup options</li> <li>Verify/Connect proper LNB polarity (H or V)</li> <li>Contact your dealer/reseller or local service provider for assistance</li> <li>Aim antenna for peak reception according to manufacturer's instructions (you can use a standard analog receiver tuned to a NTSC or PAL signal to confirm correct antenna position)</li> <li>Relocate antenna or remove obstruction</li> </ul>
Signal with high BER Signal Level >20	Signal weak and/or error rate very high (receiver synchronized to a valid digital signal)	<ul style="list-style-type: none"> <li>Aim antenna for peak reception according to manufacturer's instructions (peak for lowest possible BER)</li> <li>Check that LNB cable does not exceed maximum length, and/or that signal splitters do not have missing terminations which can cause excessive signal loss (see also Appendix G)</li> </ul>
Signal with high BER Signal Level >50	Signal too strong due to block converter and/or line amplifiers installed after LNA/LNB	<ul style="list-style-type: none"> <li>Remove extra amplifier(s) and/or add signal attenuator pads (see also Appendix F and G)</li> </ul>
No video or audio SIGNAL LED flashing regularly	Receiver not authorized to receive the signal (receiver synchronized to a valid digital signal)	<ul style="list-style-type: none"> <li>Contact your dealer/reseller or local service provider for assistance</li> </ul>
No response when front panel buttons are pressed	Front panel operation is disabled by Lock Level setting	<ul style="list-style-type: none"> <li>Receiver Lock Level set to Loc3 or Loc4 (if Lock Level 3, change setting, as required)</li> </ul>





# Appendix D Serial Remote Control Command Set

## About this Appendix

This Appendix provides important information about your PowerVu *Plus* Professional Receiver. Refer to this section for:

❑ **Serial Remote Control commands information**

Complete information required for operating your PowerVu *Plus* Model D9224 Professional Receiver via Serial Remote Control commands is provided in this Appendix. Remote operation of the receiver is performed via the rear panel Expansion Port RS-232 link.

Use the information provided in this Appendix to familiarize yourself with Remote Control command operation, and for quick reference when needed. For complete operating instructions and other important information about your receiver, refer to this Installation and Operation Guide. Reading all of this guide is recommended before you begin using the Serial Remote Control commands.

## Contents

<b>Expansion Port interface .....</b>	<b>D-3</b>
...About the Expansion Port interface.....	D-3
...About networking.....	D-4
<b>Expansion Port operation .....</b>	<b>D-5</b>
...About the Authorization Relay .....	D-5
...About the Port Control Relay .....	D-5
...About the Port Control pins .....	D-5
<b>Serial Remote Control commands.....</b>	<b>D-7</b>
<b>Command protocol.....</b>	<b>D-7</b>
<b>Command/Response messaging .....</b>	<b>D-8</b>
<b>Error responses .....</b>	<b>D-8</b>
Authorization Relay.....	D-9
Automatic Frequency Control.....	D-9
Bit Error Rate .....	D-9
Channel.....	D-10
Corrected Errors.....	D-10
Installer.....	D-10
Lock level .....	D-12
Port Control .....	D-12
Port Control Relay.....	D-13
Power .....	D-13
Product version .....	D-13
Reset.....	D-13
Signal State.....	D-14
Uncorrected Errors.....	D-14
<b>Receiver microprocessor versions .....</b>	<b>D-15</b>
Compression Control Processor version.....	D-15

Decoder Control Processor version.....D-15

Inboard Security Element version.....D-15

Keyboard Control Processor version .....D-16

Outboard Security Element version.....D-16

## Expansion Port interface

The Expansion Port interface is used by the receiver to carry remote control command data to and from the Model D9224 Professional Receiver and the host computer.




Figure D-1. Daisy-Chain receiver network configuration

### ...About the Expansion Port interface

The Model D9224 Professional Receiver can be operated and monitored remotely via the Expansion Port (DB-25 female connector) when connected to a host computer (i.e., PC workstation or data terminal). The Expansion Port interface operates at standard RS-232 interface signal levels (data lines only), and uses non-standard pin connections to permit internal signal sharing. Pins marked NC (No Connection) or Reserved must not be connected for normal operation. No support is provided for external protocols (e.g., XON/XOFF). The default data format used for port operation is ASCII, 8 bits, no parity, 1 start bit and 1 stop bit. Both receive and transmit baud rates are equal. The default Baud Rate (9600) can be changed using receiver front panel buttons.

Remote receiver operation via the Expansion Port requires installation of a PC/data communications program. Note that certain program settings may vary, depending on the type of workstation/terminal equipment being used. Data interface cables connected between the Professional Receiver and some customer equipment may require a unique pin-out for proper operation. For Expansion Port pin-out information, see Table D-1.

Table D-1. Expansion Port pin-out

Pin	Function	Pin	
#1	Ground (RS-232)	#14	Reserved
#2	Utility Data Output	#15	Reserved
#3	NC (RS-232 RxD)	#16	RC-8
#4	NC (RS-232 RTS)	#17	RC-7
#5	NC (RS-232 CTS)	#18	RC-6
#6	NC (RS-232 DSR)	#19	RC-5
#7	Ground (RS-232)	#20	+5 VDC control output via 1K $\Omega$ pull-up resistor
#8	Download input	#21	+5 VDC control output via 47 $\Omega$ pull-up resistor
#9	Reserved	#22	RC-4
#10	Auth Flag	#23	RC-3
#11	Reserved	#24	RC-2
#12	Serial Remote (RxD)	#25	RC-1
#13	Serial Remote (TxD)		

## ...About networking

When connected to a host computer (i.e., PC workstation or data terminal), the Model D9224 Professional Receiver can be operated as part of a multiple-receiver network. This is accomplished by interconnecting each of the receivers with the host computer in a daisy-chain configuration (see Figure D-1). In a daisy-chain network, command information (data) transmitted from the host computer is received by the first receiver in the loop, which in turn, retransmits the data to the second receiver in the loop, and so on. This action continues until the last receiver completes the loop by re-transmitting the data back to the host computer. With daisy-chain networks, the network address assigned to each receiver is not used. Instead, the logical address of each receiver is determined by its position in the chain.

When operating the receiver as part of a daisy-chain network, note the following limitations and operating constraints.

- ❑ **Response time:** The time required to receive a response from a remote control command issued from the host computer increases with each receiver added to the network.
- ❑ **Performance:** Since every character transmitted across the network must be received and retransmitted by every receiver in the chain, the increased response time can affect remote configuration and monitoring the performance, especially when low baud rates are used in a large daisy-chain network.
- ❑ **Software downloading not networkable:** Because the downloading of receiver operating software requires a S-A proprietary protocol, the receiver must first be removed (disconnected) from the network before a software download can be performed.

---

## Expansion Port operation

Remote control and monitoring of the Model D9224 Professional Receiver via the rear panel Expansion Port is performed using Serial Remote Control commands. The commands are used to control the following Expansion Port (and other) subsystem components.

- ☐ Authorization Relay
- ☐ Port Control Relay
- ☐ Expansion Port Remote Control pins

### ...About the Authorization Relay

The Authorization Relay (together with the Authorization Flag) is used to control the receiver authorization state. This relay can be controlled externally using the remote ARLY command. When the receiver is authorized, the operating state of the Authorization Flag (pin #10) is low, which energizes the relay. When the receiver is deauthorized, the operating state of the Authorization Flag is high (open-collector), which de-energizes the relay. For complete information about this command, see “Authorization Relay”.

### ...About the Port Control Relay

The Port Control Relay is used to operate external appliances/devices connected to the receiver by energizing the relay independently, or via port control pins. The PRLY command is used to energize the relay, or to set one of the designated port control pins (i.e., RC-1 to RC-8) to operate the relay (see also “...About the Port Control pins”). For complete information about this command, see the next topic.

### ...About the Port Control pins

The Expansion Port is externally controlled via one of the designated Remote Control pins (i.e., RC-1 to RC-8) using the PCTL command. Each Remote Control pin can be set to operate under remote (uplink encoder) control, or under local (PCTL command) control. A separate command is required for controlling or changing the operating state of each Remote Control pin. For complete information about this command, see the next topic.

Figure D-2 following shows how the Authorization Relay (ARLY), Port Control Relay (PRLY) and Port Control (PCTL) commands are used to control and operate the Professional Receiver Expansion Port.




Figure D-2. Expansion Port operation and control

## Serial Remote Control commands

Your Model D9224 Professional Receiver is equipped for remote control using Serial Remote Control commands via a host computer (i.e., PC/workstation or data terminal) connection. This optional connection can be made at the receiver rear panel serial data port labeled EXPANSION PORT. Serial Remote Control commands can be used in place of the user interface (front panel buttons) for remote receiver control and monitoring.

General information about how Serial Remote Control commands are used is followed by detailed information about each command, including syntax and command options.

---

### Command protocol

Each of the Serial Remote Control commands are executed using a unique protocol or rules. These rules control command syntax (i.e., how a command must be sent to the receiver) and how the receiver responds. Commands can only be interpreted by the receiver if upper case characters are used. When sending commands, observe the following.

- ❑ Use only upper case ASCII characters
- ❑ All Serial Remote Control commands begin with the characters "SA1"
- ❑ A command is executed only after a carriage return character is sent (i.e., the Enter or Return key is pressed)

The following conventions are used for identifying the command options found in this Appendix.

- ❑ Left and right parenthesis characters "{" }" and the forward slash character "/" are used to separate the command option(s) from the main command characters, and must not be entered
- ❑ The forward slash character "/" used to separate command options indicates that one of the available options must be specified, and must not be entered

The following example shows correct command usage.

#### **SAIVER<CR>**

In the above example, the VER command causes the receiver model number to display only after the Enter key is pressed (i.e., carriage return [<CR>]). The command is valid only if the characters "VER" are used (i.e., "ver" is not a valid command, even though the characters are the same). If command or syntax is invalid, the receiver responds with "?". If an internal overflow condition exists when executing a command, the receiver responds with "V". Note that all Serial Remote Control commands begin with the characters "SA1".

## Command/Response messaging

A specific protocol is used for constructing and processing all Serial Remote Control commands and resulting response messages. Table D-2 shows Professional Receiver command frame and response frame information.

Table D-2. Remote control command and response frames

Command frame			
Byte	Length	Data	Description
1	1	"S"	Start character #1
2	1	"A"	Start character #2
3	1	"1-9" ".,"	Unit Number (in chain) <sup>1</sup> Next ASCII character if more than 9 units in chain
4	n		Command code and parameters
4 + n	1	<CR> <sup>2</sup>	End of message
Response frame			
1	1	<LF> <sup>3</sup>	Line Feed
2	n		Command Response
2 + n	1	<CR>	Carriage Return
3 + n	1	<LF>	Line Feed
4 + n	1	">"	Ready for next message

All transmitted command characters must be upper case ASCII. All characters are echoed by the receiver, except for the Unit Number (i.e., byte #3) which is decremented if greater than zero (0).

## Error responses

Table D-3 shows receiver command error and overrun error response frame information.

Table D-3. Command/Overrun errors

Command error frame			
Byte	Length	Data	Description
2	1	"?"	Command error response
Overrun error Frame			
2	1	"&"	Overrun error response

<sup>1</sup> Receiver is addressed when first unit (1) received

<sup>2</sup> Carriage Return

<sup>3</sup> Line Feed



The command error message (?) may display if the receiver cannot recognize the command, or if an internal microprocessor operating error or error condition exists.

The overrun error message (&) may display if the receiver cannot process the command completely, and/or if the command becomes corrupted during transmission.

## Authorization Relay

The ARLY command is available for polling the receiver to display the current operating state of the Authorization Relay, and for enabling or disabling external control over the relay state. Consider the following syntax: **SA1ARLY={ON/OFF}**

**ARLY** polls the receiver for the current operating state. **ARLY=ON** enables external control over receiver authorization via the Authorization Relay. **ARLY=OFF** disables external control over receiver authorization by energizing the relay. The receiver responds by displaying: **ARLY=ON/OFF**.

When set to ON, Authorization Relay contacts are closed (energized) when the receiver is authorized and active, and are open (de-energized) if the receiver becomes de-authorized. When set to OFF, the receiver is always authorized.

## Automatic Frequency Control

The AFC command is available for polling the receiver to display the current relative offset from the set center frequency of the decoded digital signal. Consider the following syntax: **SA1AFC**.

**AFC** polls the receiver for the current relative offset from the set center frequency (decoded digital signal), where ## can be any number from -50 to +50. The receiver responds by displaying: **AFC={+/-}##**.

The receiver automatically compensates for a +/- 2.5 MHz frequency offset which is equivalent to an AFC value of approximately +/- 12.

## Bit Error Rate

The BER command is available for polling the receiver to display the current Bit Error Rate of the decoded digital signal (errors per second). Consider the following syntax: **SA1BER**.

**BER** polls the receiver for the current Bit Error Rate (digital signal). The receiver responds by displaying: **BER=#.#E-#**

#.#E-# is the Bit Error Rate expressed in scientific notation.

## Channel

The Channel command is available for polling the receiver to display the current channel, or for changing the channel. Consider the following syntax: **SA1CH=###**.

CH polls the receiver for the current channel. CH=### changes the current channel. The receiver responds by displaying: CH=###.

### can be any virtual channel number from 0 to 500.

## Corrected Errors

The CE command is available for polling the receiver to display the current Corrected Error count, and for clearing or resetting the current error count. Consider the following syntax: **SA1CE=0**.

CE polls the receiver for the current Corrected Error count. CE=0 clears or resets the current error count. The receiver responds by displaying: **CE=###**.

### can be any number from 0 to 65536, and is the number of Corrected Viterbi Errors counted since the last reset. The corrected error count depends on the Signal Quality, and is automatically reset each time the receiver is restarted. This command is available only with DCP (Decoder Control Processor) software v 1.22 or greater (see also “Decoder Control Processor version”).

## Installer

The INST command is available for displaying current receiver settings, or for changing the receiver settings. Consider the following syntax:

$$\text{SA1INST} = \# , \{ \# \# . \# \# \# \# \# / \# \# \# \# . \# \# \} , \# , \# \# . \# \# \# \# , \# \# . \# \# \# , \# \# . \# \# \# , \# \# . \# \# \# , \# \# . \# \# \# , \# , \# , \# \# \# \# \# , \# \# \# \# \# , \{ \# , \# \} .$$

The receiver responds by displaying:

$$\text{INST} = \# \{ \# \# . \# \# \# \# \# / \# \# \# \# . \# \# \}, \# , \# \# . \# \# \# \# , \# \# . \# \# \# , \# \# . \# \# \# , \# \# . \# \# \# , \# \# . \# \# \# , \# , \# , \# \# \# \# , \# \# \# \# \# \# , \{ \# , \# \}$$

Table D-4 identifies each of the command parameters as displayed (from left to right), in order.

### Table D-4. INST command options

	Parameter	Options
1.	# (Band Select)	0 (C/L-Band 1), 1 (C/Downlink), 2 (Low-Ku/L-Band), 3 (High-Ku/L-Band), 4 (Single-Ku/Downlink) or 5 (Dual-Ku/Downlink)
2.	###.##### (Downlink Frequency) or ####.## (L-Band frequency)	Range (0-15 GHz)  Range (950-2050 MHz, with 250 kHz resolution)
3.	# (FEC Rate)	1 (1/2), 2 (2/3), 3 (3/4), 4 (5/6) or 5 (7/8)

	Parameter	Options
4.	##.#### (Symbol Rate)	Range (3-30 Ms/s [variable-rate receivers only]) ignored in fixed-rate receivers
5.	##.### (C-Band Local Oscillator frequency)	Range (0-15 GHz)
6.	##.### (Low Ku-Band Local Oscillator frequency)	Range (0-15 GHz)
7.	##.### (High Ku-Band Local Oscillator frequency)	Range (0-15 GHz)
8.	##.### (Crossover frequency)	Range (0-15 GHz) for Dual-Ku/Downlink Mode only)
9.	# (Polarization)	H (Horizontal) or V (Vertical)
10.	# (Input Select)	0 (RF) or 1 (SWIF)
11.	##### (Network ID, DVB)	Range (0-65535)
12.	##### (Bouquet ID, DVB)	Range (0-65535)
13.	# (MPEG Output Select) OPTIONAL PARAMETER	0 (Unfiltered) or 1 (Filtered)
14.	# (Tuner Gain) OPTIONAL PARAMETER	0 (Low Gain Mode) or 1 (High Gain Mode)

When using the **INST** command, a valid Downlink frequency or L-Band frequency must be specified. Also, if the MPEG Output Select or the Tuner Gain command option (parameter) is required, both must be specified.

The **INST** command is valid only if Channel 0 is the current channel. No parameters may be omitted when using this command. This command is available only with DCP (Decoder Control Processor) software v 1.22 or greater (see also “Decoder Control Processor version”).

The **INST2** command displays current status of L-Band inputs. Consider the following syntax: **SA1INST2=#**.

# can be 1, 2, 3 or 4. If 1, then L-band input 1 will be selected, and so on (i.e., 1 for 1, 2 for 2, etc.).

The receiver responds by displaying: **INST2=#**.

If the receiver returns a 1, then L-Band input 1 has been selected, and so on (i.e., 1 for 1, 2 for 2, etc.). If the receiver returns a 0, the multiple L-Band module is not installed on the receiver

The **INST2** command is valid only if Channel 0 is the current channel. This command is available only with DCP (Decoder Control Processor) software v 2.11 or greater (see also “Decoder Control Processor version”).

## Lock level

The LOCK command is available for polling the receiver to display the current Lock Level setting, and for changing the Lock Level setting. Consider the following syntax: **SA1LOCK=#**.

**LOCK** polls the receiver for the current Lock Level. **LOCK=#** changes the receiver Lock Level.

The receiver responds by displaying: **LOCK=#**.

# can be 0, 1, 2, 3 or 4. When set to 0, receiver lockout is disabled (all options are available). When set to 1, menus and current receiver settings are displayed, and all options are available except Factory Reset. When set to 2, menus and current receiver settings are displayed, and all receiver functions are locked out or disabled except Authorization Relay, Baud Rate, Lock Level, and Port Control Relay settings. When set to 3, menus are not displayed and all user interface receiver functions are locked out or disabled except for the Lock Level setting. When set to 4, no menus are displayed and all receiver functions are locked out or disabled, and menus cannot be displayed (i.e., accessible via remote terminal or PCC uplink signal).

The Lock Level setting does not affect external remote command operation in any way.

## Port Control

The PCTL command is available for polling the receiver to display the current operating state of Expansion Port control pins, and for enabling or disabling external control over Expansion Port control pins. Consider the following syntax: **SA1PCTL,#={H/L/R/T}**.

**PCTL,#** polls the receiver for the current state of (specific) Expansion Port control pins.

**PCTL,#=H** forces the specified port pin HIGH (open collector).

**PCTL,#=L** forces the specified port pin LOW (grounded).

**PCTL,#=R** sets the specified port pin for remote (uplink) control over the HIGH and LOW states.

**PCTL,#=T** sets the specified port pin to the state of the corresponding bit in the transmitted Cue Trigger byte.

The receiver responds by displaying: **PCTL,#={H/L/R/T}**.

# can be any pin (number) from 1 to 8.

## Port Control Relay

The PRLY command is available for polling the receiver to display the current operating state of the port control relay, and for enabling or disabling external control over the relay state. Consider the following syntax: **SA1PRLY={#/OFF}**.

**PRLY** polls the receiver for the current relay operating state. **PRLY=#** sets a specific port pin to control the Authorization Relay. **PRLY=OFF** energizes the Authorization Relay contacts. The receiver responds by displaying: **PRLY=#/OFF**.

# can be any pin (number) from 1 to 8. When set to a valid port pin, Authorization Relay contacts are closed (energized) when the pin set goes HIGH and the receiver is authorized and active. Relay contacts are open (de-energized) if the pin set goes LOW, or if the receiver becomes deauthorized. When set to OFF, the port control relay is always energized.

## Power

The PW command is available for polling the receiver to display the current operating (power) state, or for powering the receiver on and off. Consider the following syntax: **SA1PW={ON/OFF}**.

**PW** polls the receiver for the current operating state. **PW=ON** powers the receiver on, and **PW=OFF** powers the receiver off. The receiver responds by displaying: **PW=ON/OFF**.

The receiver is in standby mode when powered OFF.

## Product version

The Version command is available for polling the receiver to display the product model identification number. Consider the following syntax: **SA1VER**.

**VER** polls the receiver for the model number. The receiver responds by displaying: **VER=#### CDSR**.

## Reset

The RESET command is available for resetting the receiver hardware (i.e., main microprocessor). Consider the following syntax: **SA1RESET=YES**.

**RESET=YES** resets the receiver (i.e., warm boot only). The receiver responds by displaying: **RESET=RECV**.

Note that the RESET command *does not* reset the receiver operating software, or reset the receiver to factory default settings.

## Signal State

The STATE command is available for polling the receiver for the current receiver operating/Signal State. Consider the following syntax: **SAISTATE**.

**STATE** polls the receiver for the current operating/ Signal State. The receiver responds by displaying: **STATE=#**.

# can be (see Table D-5). Returned status codes represent all possible operating states. Note that each command response (instance) reflects the instantaneous operating state of the receiver which may indicate a response which is erroneous or unexpected. If an unexpected response is received, the steady or normalized operating state of the receiver can best be determined if this command is executed repeatedly.

**Table D-5. Possible signal status codes and descriptions**

State Code	Response
0	No lock
10	Search Mode Active
20	Loss of Signal Time-out
30	Channel Change in Progress
40	Digital Lock, No Signal
50	Digital Lock, and Signal
60	Unauthorized Program Active
70	Authorized Program Active

## Uncorrected Errors

The UE command is available for polling the receiver to display the current Uncorrected Error count, and for clearing or resetting the current error count. Consider the following syntax: **SAIUE=0**.

**UE** polls the receiver for the current Uncorrected Error count. **UE=0** clears or resets the current error count. The receiver responds by displaying: **UE=###**.

### can be any number from 0 to 65536, and is the number of uncorrected Viterbi errors counted since the last reset. The uncorrected error count depends on the Signal Quality, and is automatically reset each time the receiver is restarted. This command is available only with DCP (Decoder Control Processor) software v 1.22 or greater (see also “Decoder Control Processor version”).

## Receiver microprocessor versions

Serial Remote Control commands can be used to display current version information for receiver subsystem control microprocessors. These subsystems are:

- ❑ Compression Control Processor (CCP)
- ❑ Decoder Control Processor (DCP)
- ❑ Inboard Security Element (ISE)
- ❑ Keyboard (KBD)
- ❑ Outboard Security Element (OSE)

### Compression Control Processor version

The CCP command is available for polling the receiver to display the installed software version for the CCP (Compression Control Processor) microprocessor. Consider the following syntax: **SA1CCP**.

CCP polls the receiver for installed software version information (CCP microprocessor). The receiver responds by displaying: **CCP=V#.#**.

V#.# is the installed software version

### Decoder Control Processor version

The DCP command is available for polling the receiver to display the installed software version for the DCP (Decoder Control Processor) microprocessor. Consider the following syntax: **SA1DCP**.

DCP polls the receiver for installed software version information (DCP microprocessor). The receiver responds by displaying: **DCP=V#.#**.

V#.# is the software version number. Note that some command options may differ slightly, depending on the installed receiver DCP software version.

### Inboard Security Element version

The ISE command is available for polling the receiver to display the network address plus the installed software version for the Internal Security Element microprocessor, including algorithm information. Consider the following syntax: **SA1ISE**.

ISE polls the receiver for network address and installed software version information (Inboard Security Element microprocessor and algorithm). The receiver responds by displaying: **ISE=###-###-####-#, V#.#(#)** -

###-###-####-# is the network address, V#.# is the software version and (#) is the decryption algorithm type, and "-" is displayed only if the ISE is not installed.

## Keyboard Control Processor version

The KBD command is available for polling the receiver to display the installed software version for the (front panel) Keyboard microprocessor. Consider the following syntax: **SA1KBD**.

**KBD** polls the receiver for installed software version information (Keyboard control microprocessor). The receiver responds by displaying: **KBD=V#.#**.

V#.# is the software version number.

## Outboard Security Element version

The OSE command is available for polling the receiver to display the network address plus the installed software version for the Outboard Security Element (Smart Card) microprocessor, including algorithm information. Consider the following syntax: **SA10SE**.

**OSE** polls the receiver for network address and installed software version information (Outboard Security Element and algorithm [Smart Card]). The receiver responds by displaying: **OSE=###-###-####-#,V#.#(#)** -.

###-###-####-# is the network address, V#.# is the software version, (#) is the decryption algorithm type, and "-" is displayed only if the Smart Card is not installed.



---

# Appendix E Product Identification

## About this Appendix

This Appendix provides important information about your PowerVu *Plus* Professional Receiver. Refer to this section for:

- Product identification information

The label affixed to the receiver rear panel contains a 16-digit product identification code number that identifies your receiver, including factory options. Use this information to help identify your receiver. For more information about product ordering, contact your local Scientific-Atlanta Customer Support Center, Scientific-Atlanta dealer or distributor.

Figure E-1 shows the product identification code with available factory options.




Figure E-1. Example product identification code showing options




Figure E-2. 803-356 Rear panel

# Appendix F   Application Notes

## About this Appendix

This Appendix provides important information about your PowerVu Plus Professional Receiver. Refer to this section for:

- ❑ Comparison of compressed digital vs. analog FM satellite signal delivery
- ❑ Application Brief

Additional application and troubleshooting information is provided in this Appendix for optimizing your PowerVu Model D9224 Professional Receiver equipment installation. Servicing of installed equipment should only be performed by qualified technical personnel. For complete operating instructions and other important information about your receiver, refer to this Installation and Operation Guide. For additional troubleshooting information, see Appendix C.

## Contents

<b>Digital vs. analog FM satellite signal delivery .....</b>	<b>F-2</b>
Industrial/Microwave equipment interference .....	F-2
Adjacent-Band radar altimeter interference .....	F-2
Ignition noise interference .....	F-3
<b>Application brief .....</b>	<b>F-4</b>
<b>Minimizing signal interference .....</b>	<b>F-4</b>
Maintain an adequate signal level .....	F-4
Avoid signal saturation .....	F-4
Local Oscillator stability .....	F-5
Using line amplifiers, isolators and filters .....	F-5
Terrestrial in-band and out-of-band interference .....	F-5
High Bit Error Rates .....	F-6
High BER caused by a high signal level .....	F-7

## Digital vs. analog FM satellite signal delivery

The PowerVu Plus Model D9224 Professional Receiver tunes digital video, audio and data signals transmitted over C and Ku-Band satellites. It differs from traditional FM Video receivers in that it receives this information as a compressed, Quadrature Phase Shift Keyed (QPSK) digital signal. This signal compression technique permits the transmission and reception of high-quality, video channels and associated audio per transponder. In comparison, traditional analog FM modulation permits only one video signal (plus associated audio and data) to be transmitted by each transponder.

Because of the increased capacity achieved using digital compression and transmission, special error protection is used to correct errors and provide error concealment when the error rate exceeds the capability of the decoder to provide complete error correction. To detect and correct errors caused by thermal noise, an encoding technique called soft decision convolutional encoding is used. The Model D9224 Professional Receiver and associated up-link equipment use a convolutional encoder to provide error correction to decrease the error rate. To protect against burst noise interference, special data interleave and Reed-Solomon block decoders are used.

Because there may be instances when the error rate is high enough so that not all errors can be corrected, the receiver contains sophisticated software algorithms that provide image concealment for small, uncorrected errors, and freeze frame or black-frame substitution for larger, uncorrected errors.

The FM Analog equivalent to digital errors is the well-known "sparkle" that appears on the TV screen when the received signal level drops below the FM Threshold of about 10 dB C/N. Unlike analog transmission where the "sparkles" are superimposed on the video, uncorrected digital errors can create a loss of digital synchronization resulting in signal outages that can last longer than the actual duration of the interference. It is during these instances that image concealment is most important. Typically, instead of a single sparkle, a digital error can result in generation of artifacts ranging from "no perceptible error" to "multiple block errors" that appear similar to FM threshold sparkles to "freeze frames or black screens" for greater, more significant errors.

Scientific-Atlanta supplies digital satellite receivers in existing C-Band TVRO systems ranging from Broadcast Affiliate systems to Hotel/Motel SMATV systems. Experience has shown that the C-Band environment is susceptible to local in-band and out-of-band interference, whereas the Ku-Band environment is not.

### Industrial/Microwave equipment interference

This form of microwave interference typically originates from industrial microwave ovens operated in factories and commercial sites, and interferes primarily with transponder #24. Microwave signal levels produced by these sources can be high enough to saturate the LNB and/or receiver. Generally, replacement of the offending Magnetron RF output tube will solve this problem.

### Adjacent-Band radar altimeter interference

Aircraft radar altimeters do not operate in the 3.7 to 4.2 GHz band, but are close enough in frequency that they can produce interference strong enough to saturate the LNB and/or receiver.

Radar altimeter interference can be eliminated by installing an off-the-shelf microwave filter designed specifically for out-of-band signals. These microwave filters are installed between the feed assembly of the antenna and the LNB or LNA.

## **Ignition noise interference**

Ignition noise interference is typically broadband in nature and can interfere with the received signal. Ignition noise can be generated by faulty combustion engine ignition systems, hand-held electric dryers/blowers, or other electromagnetic equipment operated near the receive antenna. In most cases, the noise energy within the received channel can be tolerated provided that receive/line amplifiers do not become saturated.

A signal input level of approximately -50 dBm is recommended for normal receiver operation. This allows sufficient receiver headroom so that any interference that takes place within the 3.7-4.2 GHz band (as well as adjacent bands) does not cause the receiver to become saturated. If other parts of the receive system become saturated, steps should be taken to eliminate the unwanted interference.

Ignition noise can be reduced or eliminated by restricting the use of combustion engines, hand-held electric dryers/blowers, or other electromagnetic equipment near the receive antenna.

## Application brief

This application brief is provided to assist users with the installation, setup and maintenance of the PowerVu Plus Model D9224 Professional Receiver.

Digital compression signals react differently to problems caused by saturation and/or terrestrial interference (TI) in the downlink path as compared with analog signals. Where terrestrial interference can cause random sparkles, black and white lines or hum and picture noise in analog satellite receivers, the same interference in the digital domain can cause digital artifacts such as "blocking", "freeze frame" and/or a "black screen" depending upon the magnitude and duration of the interfering signal.

Specific actions you can take to minimize the effects of local terrestrial interference are discussed in the pages that follow.

---

### Minimizing signal interference

Types of terrestrial interference known to cause problems with digital compression signals are out-of-band interference such as aircraft radar altimeters, commercial microwave ovens, and/or in-band interference from hand-held electrical or combustion engine equipment operated near the receive antenna.

### Maintain an adequate signal level

The input signal level as provided to the receiver from the satellite LNB should be maintained between the values of 20 to 50 as displayed on-screen at the Installer menu.

### Avoid signal saturation

If signal saturation is a problem, a Low-Noise Amplifier (LNA) followed by a blockconverter may require a C-Band attenuator installed before the blockconverter. Signal attenuation between approximately 6 to 20 dB can effectively reduce or eliminate the effects of signal saturation.

Signal levels should range from 20 to 40 for the lower power type carriers (<10 Msymbols/s), and from 30 to 50 for larger, high power carriers; especially those which occupy a full transponder. Low signal levels accompanied by a high Bit Error Rate usually indicate excessive signal loss between the receiver and the satellite antenna. High signal levels accompanied by a high Bit Error Rate usually indicate signal overloading at the receiver and/or line amplifier RF input.

To test for a low signal BER problem, perform the following actions.

**Step 1.** Connect the receiver before any splitters, if existing.

**Step 2.** Connect the decoder as close to the LNB output as possible.

**Step 3.** Connect a line amplifier between the LNB and the receiver.

Connect and compare the performance of a second receiver, if possible.

## Local Oscillator stability

To minimize the time required for synchronizing to a target carrier frequency, PowerVu Plus variable rate satellite receivers are optimized for operation with LNBs having the following LO frequency stability (see Table F-1).

**Table F-1. LNB Local Oscillator stability vs. carrier Symbol Rate**

Symbol Rate	LNB LO Stability
> 3 MS/s and $\leq$ 6 MS/s	$\pm 1.0$ MHz
> 6 MS/s	$\pm 1.5$ MHz

## Using line amplifiers, isolators and filters

If you are using line amplifiers as part of your equipment installation, avoid saturating the line amplifier or overloading the receiver by locating the line amplifier at the appropriate distance from the LNA/LNB. Line amplifiers typically offer a gain of 20 dB, and should only be installed if the signal input cable length is approximately 50 to 100 Meters.

The line amplifier used must be able to amplify the composite power of all the satellite transponders without distortion. An output 1 dB compression point of 0 to 10 dBm is usually sufficient in most cases. If installed, line amplifiers with noise figures under 7 dB provide the best Signal-to-Noise ratio.

Antenna cross-polarization isolation should always be checked at the downlink. A misaligned LNB can introduce interference from other satellite signals.

If you are experiencing interference causing LNB overload from a Radar signal existing outside the normal 3.7 to 4.2 GHz C-Band, a C-Band "block filter" can be installed before the LNA/LNB input. If installed, this type of filter can effectively reduce out-of-band interference and the effects of downlink path compression, and should not exceed 0.3 dB signal loss.

Be sure to terminate all splitter outputs, power dividers and unused connectors, where necessary. Signal cables used should be low loss RG-6, with L-Band or equivalent rating.

## Terrestrial in-band and out-of-band interference

The received signal level can be weakened and degraded due to local Terrestrial Interference (TI) originating from earth-based, C-Band signal sources. Higher frequency Ku-Band signals are not affected by this type of interference. Both in-band and out-of-band local TI can adversely affect receiver operation.

Local, in-band interference that affects certain channels only is often caused by the satellite antenna (dish) being located in or adjacent to the path of a microwave telecommunication signal tower. This source of interference can usually be identified with spectrum analyzer equipment. C-Band radar scatter originating from airport control towers can intermittently overload the satellite LNB, and can be difficult to detect. The most common form of in-band interference is caused by noise spikes from electrical power or ignition systems which are amplified by active components in the LNB and receiver (tuner). For this and other reasons, over-amplification of the LNB output signal can adversely affect the received digital

signal. If local, in-band interference is present, installing 10 dB C-Band attenuator pad at the input of the LNA/blockconverter will prevent signal saturation and compression.

It should be noted that some types of two-way radios or walkie-talkies can destructively interfere with a receiver due to use of identical bands within the receiver IF frequency. Use of walkie-talkies should be restricted in the vicinity of the receiver.

Out-of-band interference can originate from a variety of sources. Aircraft radar altimeters are a common problem near airports. Commercial microwave ovens operating adjacent to earth station antennas have been known to interfere with digital compression signals. Purchase of a C-Band bandpass filter to be installed at the antenna prior to the LNA or LNB is recommended where there are known out-of-band interfering sources.

## High Bit Error Rates

The Bit Error Rate (BER) associated with the received digital signal is extremely important, as it indicates how much of the received signal information contains errors that must be corrected due to electrical noise/interference. The BER is displayed in scientific notation (e.g., a received signal BER of 1E-5 [or  $1.0 \times 10^{-5}$ ] is less than a signal BER of 2E-3 [or  $2.0 \times 10^{-3}$ ]). The BER threshold for the Model D9224 Professional Receiver ranges from 5E-3 to 2E-2, depending on the FEC Rate setting used. For example, the BER threshold for a FEC Rate of 1/2 is 2E-2, 1E-2 for 3/4, and 5E-3 for 7/8. For safe operation, the BER associated with the received signal should be at least 1/10 of the threshold (i.e., for a FEC Rate of 3/4, a BER of from 1E-3 to 1E-5 is considered ideal).

The received signal level can be weakened and degraded due to precipitation (i.e., rain, ice and snow), and from snow accumulation on the satellite antenna (dish). Using the BER display is the best method for accurate antenna peaking. For information about operating the receiver front panel to display current BER information, see Chapter 3 of this guide.

Common problems associated with a high Bit Error Rate are:

- ☐ Unterminated splitter port
- ☐ Poor cabling or impedance mismatch
- ☐ Marginal RF downlink signal level
- ☐ Cross polarization
- ☐ Improperly pointed satellite antenna (dish)

If no improvement in the BER is obtained after investigating the above, faulty antenna or LNB equipment may be responsible for the problem. BER problems caused by low signal levels can be effectively improved by performing one or more of the following actions:

- ☐ Using higher-quality cable and connectors
- ☐ Reducing the number of signal splitters and/or line amplifiers
- ☐ Replacing the low gain LNA/LNB, if found to be faulty
- ☐ Installation of a line amplifier after a long cable run



## High BER caused by a high signal level

A 10 dB attenuator pad installed before the receiver RF input (external LNB power switch set to OFF) can determine if the high BER is being caused by an unusually high signal level. Also, powering the LNB from a separate receiver/decoder using a splitter connection can assist in determining if the BER problem is being caused by the input signal level. If, after taking the above steps there is no marked improvement in BER, the problem is likely the satellite antenna (dish) or LNB. A LNB operating with an unstable or noisy local oscillator can adversely affect receiver performance (see also "Using line amplifiers, isolators and filters").



---

# Appendix G Reference

## About this Appendix

This Appendix provides important information about your PowerVu *Plus* Model D9224 Professional Receiver. Refer to this section for:

- Operating performance graphs and product application (reference) information
- Additional (reference) information is provided in this Appendix about the Model D9224 Professional Receiver pertaining to equipment performance. For complete operating instructions and other important information about this receiver, refer to this Installation and Operation Guide.

## Contents

<b>Receiver performance.....</b>	<b>G-2</b>
Bit Error Rate (Signal Quality).....	G-2
Signal Level.....	G-3
AGC Level.....	G-4


# Receiver performance

Operation and performance of the PowerVu *Plus* Model D9224 Professional Receiver is directly affected by the overall quality and input level of the received digital signal. The receiver provides a continuously updated display of the following key operating parameters.

- ❑ Bit Error Rate (Signal Quality)
- ❑ Signal Level
- ❑ AFC Level

The following is a brief discussion of how each of these operating parameters can be used as performance indicators.

## Bit Error Rate (Signal Quality)



**Figure G-1. BER vs. Information Rate (typical)**

Figure G-1 shows typical Signal Quality (BER) values obtained for various FEC rates as displayed on-screen at the Installer menu.

The Eb/No (Information Rate) is normalized as the energy-per-bit for a 1 Hz noise bandwidth, and applies to any data rate. The Information Rate is the useful data rate following Forward Error Correction (FEC) as defined by the DVB standard. The threshold for Eb/No depends on the Viterbi FEC rate associated with the uplink signal.

Table G-1 lists the threshold  $E_b/N_0$  for each of the available FEC Rates.

Table G-1. FEC Rate and corresponding threshold  $E_b/N_0$

FEC	Threshold $E_b/N_0$ (based on information rate)
1/2	4.5 dB
2/3	5.0 dB
3/4	5.5 dB
5/6	6.0 dB
7/8	6.4 dB

For example, if the receiver is operating at 3/4 FEC, reference the middle curve (see Figure G-1). If the displayed BER is near  $1.0E-2$ , this corresponds to a  $E_b/N_0$  of 5.5 dB (threshold). Below this threshold the video display is likely to break up, or signal synchronization can be lost. If the displayed BER is  $1E-4$ , the receiver is operating at a  $E_b/N_0$  of 10.5 dB, which is approximately 5 dB over the threshold. If the received downlink signal is Ku (i.e., clear sky conditions), the displayed BER may be approximately  $1E-4$ . With heavy precipitation the BER is likely to increase to  $1E-2$ , corresponding to a loss of 5 dB. The 1/2 FEC Rate threshold corresponds to a BER of  $3.0E-2$ , and the 7/8 FEC threshold to a BER of  $3.0E-3$ .

The BER threshold for the Model D9224 Professional Receiver ranges from  $5E-3$  to  $2E-2$ , depending on the FEC Rate used. For safe operation, the BER for the received signal should be at least 1/10 of the threshold (i.e., for a FEC Rate of 3/4, a BER of from  $1E-3$  to  $1E-5$  is considered ideal).

## Signal Level




Figure G-2. Signal Level vs. RF signal input (typical)

Figure G-2 shows typical Signal Level values obtained for Symbol Rates above and below 20 MSymbols/s as displayed on-screen at the Installer menu. Note that displayed Signal Level values appear slightly higher for Symbol Rates below 20 MSymbols/s than for Symbol Rates above 20 MSymbols/s.


To reduce the possibility of tuner overload and the signal quality degradation that would result, the maximum RF signal input to the receiver is limited to -30 dBm for a full transponder RF carrier. A RF carrier of 3 MSymbols/s is a narrower bandwidth and will carry approximately 10 dB less power than a full transponder RF carrier of 30 MSymbols/s.

For a Symbol Rate of 3.0 MSymbols/s, the maximum RF input to the tuner should be -40 dBm assuming that other full transponder (-30 dBm) signals may also be present at the tuner input. If sufficient cable/distribution loss exists between the LNB and the receiver, then the RF signal level will be significantly reduced, and the overall signal quality will be further degraded by the receiver tuner noise figure.

**Example 1:** If the displayed Symbol rate is 30 MSymbols/s, a Signal Level of 50 corresponds to approximately -30 dBm maximum RF input for this carrier. Similarly, a Signal Level of 25 corresponds to approximately -65 dBm RF input. Normally, the receiver would be operated somewhere between these two extremes.


**Example 2:** If the displayed Symbol rate is 3.0 MSymbols/s, a Signal Level of 60 is too high, and a Signal Level of 50 corresponds to approximately -40 dBm maximum RF input for this carrier. Similarly, a Signal Level of 30 corresponds to approximately -65 dBm for a minimum RF input level. Normally, the receiver would be operated somewhere between these two extremes.

## AGC Level



**Figure G-3. AGC voltage vs. RF signal input (typical)**

Figure G-2 shows typical AGC voltage output available at the receiver rear panel AGC (RCA) connector. AGC voltage output corresponds approximately to 10% of the Signal Level on-screen display at the Receiver Status menu. The AGC output signal (>10K $\Omega$  high impedance load) can be used for operating antenna tracking devices, for offset inclined satellites that drift with time, and for antenna peaking.



# Scientific Atlanta

## Declaration of Conformity

### CE MARKING

<b>The Product</b>	<u>PowerVu Professional Satellite Receiver</u> (Type, Description)
<b>Reference Number</b>	<u>Model D9224</u> (Model or Catalogue designation)
<b>Rating</b>	<u>100-230 Vac, 1.4 A, 50/60 Hz</u> <u>or 100-240 Vac, 1.4 A, 50 Hz</u>

has been designed and manufactured in accordance with the following  
Harmonised standards

EN 60065: 1993 - Safety requirements for mains operated electronic  
and related apparatus for household and similar  
general use

EN 55022: 1998 - Limits and methods of measurement of radio  
interference characteristics of information  
technology equipment, Class A

EN 55024: 1998 - Information technology equipment - Immunity  
characteristics - Limits and methods of  
measurement

(Number, Title of Standard and Date of issue)

according to the provisions of the Low Voltage Directive 73/23/EEC  
and the Electromagnetic Compatibility Directive 89/336/EEC,  
amended per Directive 93/68/EEC

Toronto, Canada, June 1999

(Issue place and date)

Scientific-Atlanta Canada Inc. (Satellite Television Networks)

(Company name)

120 Middlefield Road, Scarborough, Ontario, Canada M1S 4M6

(Company address)

For the manufacturer: Gina Zivkovic, Qualifications Engineer  
(Signature, Name and Title)





---

## FCC notices

This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules. These limits exist to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with this instruction manual may cause harmful interference in which case the user at his own expense must take whatever measures may be required to correct the interference.

Shielded cables should be used to interconnect this unit with any peripheral equipment (i.e., data sources, terminals, monitors, etc.) to ensure compliance with Class A limits. Failure to do so may result in radio or TV interference.

---

## Industry Canada notice

This digital apparatus does not exceed the limits for Class A radio noise emissions from digital apparatus as set out in the radio interference regulations of the Canadian Department of Communications.

Le présent appareil numérique n'émet pas de bruits radioélectriques qui dépassent les limites applicables aux appareils numériques de Class A prescrites dans le règlement sur le brouillage radioélectrique édicté par le Ministre des Communications du Canada.

---

## Unauthorized modifications

The manufacturer is not responsible for any radio or TV interference resulting from unauthorized modifications made to this equipment. It is the responsibility of the user to correct such interference at his own expense.



**United States:** 4317-B Park Drive, Norcross, GA 30093; Tel: 1-888-949-4786; Fax: 1-770-903-5567

**Canada:** 120 Middlefield Road, Scarborough, Ontario, M1S 4M6, Canada; Tel.: 1-416-299-6888; Fax: 1-416-299-7145

**United Kingdom:** Home Park Estate, Kings Langley, Herts WD4 8LZ, United Kingdom; Tel: +44-1923-266133; Fax: +44-1923-269018

**Australia:** Unit 2, 2 Aquatic Drive, French's Forest, PO Box 292, NSW 2086, Australia; Tel: +61-2-9-452-3388; Fax: +61-2-9-451-4432

**Germany:** Westerbachstrasse 28-32, 61476 Kronberg, Germany; Tel: +49 (0)6173-9280; Fax: +49 (0)6173-9281-50

**Italy:** Via Fosso Centroni 4, Angolo Via Anagnina, 00040 Roma, Italy; Tel: 39-67-984-0030; Fax: 39-67-984-0034

**Argentina:** Argentina, S.A., 1149 Piso 11, Capital Federal 1011, Argentina; Tel: 54-11-4325-2800; Fax: 54-11-4325-5900

**Singapore:** Scientific-Atlanta Pte. Ltd., 1 Claymore Drive, #08-11 Orchard Towers, Singapore 229594; Tel: 65-733-4314; Fax: 65-733-2706

**Beijing:** Lucky Tower, Block B, Suite 1110-1112, 1116-1117, No. 3 Dong San Huan Bei Lu, Beijing, China 100027; Tel: 8610-6461-5761; Fax: 8610-6461-5754

© 1996-2000 Scientific-Atlanta, Inc.

All rights reserved.

Printed in Canada.

Part Number 707-145 Rev. 3

August 2000