

Warning and Attention Symbols

You must be aware of safety when you install and use this system. This *User Guide* provides various procedures. If you do some of these procedures carelessly, you could injure or kill yourself or damage equipment or property. Some other procedures require special attention.



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated “dangerous voltage” within the product’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the apparatus.

For Your Safety



Do not try to open the case. There is risk of electrical shock, which may cause damage to the apparatus and/or personal injury or death to you. There are no user-serviceable parts inside. Opening the case or making unauthorized changes will void the warranty.



Warning: To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

Important Software Notice

As with all software controlled products, unexpected behavior could arise if the user tries to perform operations in a non-routine manner. This product, like almost any other high tech product, is subject to bugs and hence DISH Network CANNOT AND DOES NOT GUARANTEE OR WARRANT THAT ALL FEATURES, SUCH AS PARENTAL CONTROL, WILL WORK AS INTENDED UNDER ALL CIRCUMSTANCES. In compliance with the terms of the GNU Public License (GPL), DISH Network is making some source code available to the public to download from www.dishnetwork.com.

Equipment and Software Covered by this Guide

This *User Guide* covers the DTVPal DVR Digital Television Receiver/DVR. This *Guide* may cover other devices, not listed here. The information in this *User Guide* may change without notice. We may issue revisions to tell you about such changes.

Copyright Notice

Part Number: 158912 Copyright © 2008 EchoStar Technologies L.L.C., Englewood, CO 80112. All rights reserved.

The software embedded in this product includes code that is copyright © 2005 the FreeType Project (www.freetype.org) and which is licensed under the FreeType Project Licence of January 27, 2006.

Manufactured under license from Dolby Laboratories. “Dolby” and the double-D symbol are trademarks of Dolby Laboratories.

DOWNLOADED FROM SATELLITEGUYS.US

NOTE: POSSIBLE ROUGH DRAFT

SPECS & INSTRUCTIONS SUBJECT TO CHANGE
WITHOUT NOTICE

SAFETY

IMPORTANT SAFETY INSTRUCTIONS

PROPER CARE OF YOUR EQUIPMENT

SAFETY

IMPORTANT SAFETY INSTRUCTIONS

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with a dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Use only attachments/accessories specified by the manufacturer.
12. Unplug this apparatus during lightning storms or when unused for long periods of time.
13. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as the power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.



Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.

IMPORTANT SAFETY INSTRUCTIONS


- Locate the DTVPal DVR in an open, well-ventilated area. Do not place the DTVPal DVR in an enclosure (such as a cabinet) without proper ventilation.
- Do not impede ventilation by covering the ventilation slots (such as with magazines, curtains, tablecloth, etc.), or the DTVPal DVR will overheat.
- Do not stack the DTVPal DVR on top of or below other electronic devices as this can cause heat build-up and vibration.
- Do not install the DTVPal DVR in any area where the temperature can be less than 40°F or more than 113°F, and do not cover it.
- Connect the power plug to an outlet having a safety ground connection. The power plug must be readily accessible so that the equipment can be easily disconnected from the AC power.
- Operate the DTVPal DVR using only the type of power source indicated on the marking label. Unplug the DTVPal DVR power cord by gripping the power plug, not the cord.
- Do not overload wall outlets or extension cords — this can result in a risk of fire or electrical shock.
- Never insert objects of any kind through openings into the DTVPal DVR, as the objects may touch dangerous voltage points or short out parts. This could cause fire or electrical shock.
- Do not attempt to service the DTVPal DVR yourself, as opening or removing covers may expose you to dangerous voltage, and will void the Limited Warranty. Refer all servicing to authorized service personnel.
- Unplug the DTVPal DVR from the AC power outlet before cleaning. The DTVPal DVR is still connected to the AC power whenever it is plugged in to a live power outlet, even if the DTVPal DVR is turned off using the remote control.

SAFETY

IMPORTANT SAFETY INSTRUCTIONS (continued)

- Do not place naked flame sources such as lighted candles on or near the DTVPal DVR.
- Do not expose the remote control batteries to excessive heat or fire.

Note to Installer: This reminder is provided to call the installer's attention to Article 810 section II of the *National Electrical Code (NEC)* that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building as close to the point of cable entry as practical.



Do not locate the antenna near overhead light or power circuits, or where it can fall into such power lines or circuits. When installing the antenna, take extreme care to avoid touching such power lines or circuits, as contact with them can be fatal.

PROPER CARE OF YOUR EQUIPMENT

- Always handle the DTVPal DVR carefully. Excessive shock and vibration can damage the hard drive.
- Always turn the DTVPal DVR off, unplug it, and then let it sit idle for at least 30 seconds before moving it.
- If the DTVPal DVR is cold to the touch, do not plug it in immediately. Let it sit unplugged at room temperature for at least 45 minutes before plugging it in.
- The use of accessories or attachments not recommended by the DTVPal DVR manufacturer will void the Limited Warranty.
- Use an outlet that contains surge suppression or ground fault protection. During an electrical storm or when the DTVPal DVR is left unattended and unused for long periods of time, unplug the power cord from the wall outlet, and disconnect the lines between the DTVPal DVR and the antenna. This will provide additional protection against damage caused by lightning or power line surges.
- In some TVs, the presence of fixed images for extended periods of time may cause permanent imprints on the screen. Consult your TV's manufacturer and user manual to determine if this is an issue for your TV.

SAFETY



Watching TV

- GETTING STARTED
- USING THE REMOTE CONTROL BUTTONS
- OPTIONS FOR VIEWING TV
- SETUP MENU
- DVR MENU
- PREFERENCES MENU
- TIMERS MENU
- CONTROLLING LIVE TV
- RECORDING MY PROGRAMS
- USING DOLBY® DIGITAL SURROUND SOUND

Getting Started

GETTING STARTED

Welcome! Your new high-definition, digital video recording, over-the-air receiver is a powerful, yet easy-to-use device you'll enjoy!



Connecting DTVPal DVR to Your TV

IMPORTANT SAFETY NOTE: Do not connect your TV or your DTVPal DVR to a power supply until after you have properly connected all of the cables using the following instructions.

To connect your DTVPal DVR, start with the antenna:

1. On the back of your TV, locate the **ANTENNA IN** connection, which connects your TV to your over-the-air antenna. This connection may be labeled **OVER-THE-AIR ANTENNA IN**, **CABLE IN**, **COAX IN** or another name. Refer to your TV's user guide for help locating this connection.
2. Disconnect the coaxial cable from your TV's **ANTENNA IN** connection.



Note: If your TV uses twin-lead (300 ohm) connections, you will need to obtain and install a 75 ohm to 300 ohm converter on your TV. This converter can be found at most consumer electronics stores.

3. Look at the back of your DTVPal DVR, and locate the **OVER-THE-AIR ANTENNA IN** connection. Connect the coaxial cable from step 2 to the **OVER-THE-AIR ANTENNA IN** connection on the DTVPal DVR.



Important: *Do not use a wrench to tighten this connection.*

Determine the connection type you'll use to connect your DTVPal DVR to your TV. If your TV has:

- a HDMI connection, you can use a HDMI cable to provide both high-definition video and stereo audio to your TV's compatible input (go to step 4).
- component connectors (Y/Pb/Pr) for video, you can use a set of component cables for video and either a Dolby Digital optical audio cable, or a pair of RCA-type audio cables (one right and one left), to connect to your TV's corresponding audio input (go to step 5).


DOWNLOADED FROM SATELLITEGUYS.US

NOTE: POSSIBLE ROUGH DRAFT

SPECS & INSTRUCTIONS SUBJECT TO CHANGE
WITHOUT NOTICE

Getting Started

- RCA connectors for both stereo audio and video, you can use RCA cables to connect from the **R-AUDIO-L-VIDEO** connection (RCA-type) on your DTVPal DVR to your TV's video input (go to step 6).
- an **ANTENNA IN** connection that uses a coaxial cable, you can connect it to the **TV SET OUT** connection on the DTVPal DVR, and it will provide both standard video and mono audio on RF channel 3 or channel 4 (go to step 7).



- To connect your DTVPal DVR to your TV using a HDMI cable:
 - Connect a HDMI cable between the **HDMI** connection on the DTVPal DVR and the HDMI connection on your HDTV or monitor.
 - Plug the power cord of the DTVPal DVR into an electrical outlet. Make sure your TV is also plugged in to power and turned on.
 - The DTVPal DVR first displays a startup screen.
 - Confirm that you are getting a picture from the DTVPal DVR. Consult your HDTV user's guide if you need to change your HDTV's settings to display from the HDMI input.




Note: In most cases, connecting the HDMI cable provides plug-and-play control of the monitor's display resolution and other settings. However, your HDTV may require selecting a different format to display video from the DTVPal DVR during system setup.

DOWNLOADED FROM SATELLITEGUYS.US
 NOTE: POSSIBLE ROUGH DRAFT
 SPECS & INSTRUCTIONS SUBJECT TO CHANGE
 WITHOUT NOTICE

Getting Started



- Follow the instructions for *Using the Setup Wizard* on page 6 to complete the initial setup of your DTVPal DVR. Tune to live TV.
- Turn up the volume on your HDTV and confirm you have sound. OPTIONAL: If you don't have sound, your system may require you to connect a pair of RCA-type audio cables (one red and one white) between the DTVPal DVR's audio outputs and your TV's audio input connections.



5. To connect your DTVPal DVR to your TV using component cables (red, blue, and green connections):
 - Connect a set of component cables from the DTVPal DVR's **YPrPb** (Red, Blue, and Green) component connections to your TV.
 - Connect audio (red and white) RCA-type cables between the DTVPal DVR's audio outputs and the audio input connections that go with the **YPrPb** video connectors on your HDTV. You can also use the optional optical connection if you use a device to decode Dolby Digital audio, for example for 5.1-channel surround sound.
 - Plug the power cord of the DTVPal DVR into an electrical outlet. Make sure your TV also is plugged in to power and turned on.
 - The DTVPal DVR first displays a startup screen.
 - Confirm that you are getting a picture from the DTVPal DVR. Consult your HDTV user's guide if you need to change your HDTV's settings to display from the component video input.
 - Follow the instructions for *Using the Setup Wizard* on page 6 to complete the initial setup of your DTVPal DVR. Tune to live TV.

DOWNLOADED FROM SATELLITEGUYS.US

NOTE: POSSIBLE ROUGH DRAFT


SPECS & INSTRUCTIONS SUBJECT TO CHANGE
WITHOUT NOTICE

Getting Started

- Turn up the volume on your HDTV and confirm you have sound. If you don't have sound, verify the connections for both left and right RCA-type audio cables on the back of your DTVPal DVR and TV.



- To connect your DTVPal DVR to your TV using composite A/V cables (red, white, and yellow RCA-type):
 - Connect a set of composite cables to your TV's RCA-type composite inputs.
 - Connect the other ends of the cables to the **R-AUDIO-L--VIDEO** (RCA-type Audio/Video) connections on your DTVPal DVR.
 - Plug the power cord of the DTVPal DVR into an electrical outlet. Make sure your TV also is plugged in to power and turned on.
 - The DTVPal DVR first displays a startup screen.
 - Confirm that you are getting a picture from the DTVPal DVR. Consult your TV user's guide if you need to change your settings to display from the correct video input.
 - Follow the instructions for *Using the Setup Wizard* on page 6 to complete the initial setup of your DTVPal DVR. Tune to live TV.
 - Turn up the volume on your TV and confirm you have sound. If you don't have stereo sound, verify the connections for both left and right RCA-type audio cables on the back of your DTVPal DVR and TV.



7. To connect your DTVPal DVR to your TV using a coaxial cable:
 - Connect one end of coax to the TV's **ANTENNA IN** (or **CABLE IN**, **COAX IN** or another name) connection.
 - Connect the other end of the coax cable to the **TV SET OUT** connection on your DTVPal DVR.
 - Plug the power cord of the DTVPal DVR into an electrical outlet. Make sure your TV also is plugged in to power and turned on.
 - The DTVPal DVR first displays a startup screen.
 - Confirm that you are getting a picture from the DTVPal DVR. You may need to select a different channel or input source on your TV. If you do not see the DTVPal DVR screen on the default output channel, channel 3, try tuning your TV to channel 4. You can change this default for DTVPal DVR in Setup Wizard, on page 8.
 - Follow the instructions for *Using the Setup Wizard* on page 6 to complete the initial setup of your DTVPal DVR. Tune to live TV.
 - Turn up the volume on your TV and confirm you have sound. If you do not have sound, check both ends of your coax connection.

Using the Setup Wizard

To finish installing your DTVPal DVR:

1. If you have not already done so, turn on your TV and change to the correct channel or input to view your DTVPal DVR.

DOWNLOADED FROM SATELLITEGUYS.US

NOTE: POSSIBLE ROUGH DRAFT

SPECS & INSTRUCTIONS SUBJECT TO CHANGE
WITHOUT NOTICE

- If your TV is connected to your DTVPal DVR using the coaxial connection (step 7), set the TV to channel 3, which is the default output channel for the DTVPal DVR.



Note: If you have a local channel that broadcasts on channel 3, you can change the modulator output setting for your DTVPal DVR to channel 4 during this Setup Wizard, described below.

- If your TV is connected to your DTVPal DVR using any other type of connection (steps 4-6), you will need to set the TV to the correct video input or source. Most TV remote controls have an INPUT, SOURCE, or TV/VIDEO button that you can use to change the TV's video input or source. Refer to your TV's user guide for additional help changing the TV's input or source for the DTVPal DVR.
2. Ensure that your over-the-air antenna is connected to your DTVPal DVR and the antenna is positioned where it can receive local digital broadcasts. If you need help choosing or installing an over-the-air antenna, refer to www.antennaweb.org or your local retailer.
 3. Install the included AAA batteries in the DTVPal DVR remote control. Be sure to follow the battery installation diagram printed inside the remote control's battery compartment.
 4. The first time your DTVPal DVR turns on, a Setup Wizard screen appears and guides you through the system setup process. The wizard scans for local digital over-the-air channels, and helps you set up the settings for your local area and TV display.
 5. To navigate through the Setup Wizard, use the SELECT button on your remote control to confirm the highlighted (orange) onscreen option. To highlight other options, use the ARROW buttons.



Tip: If there is a particular digital channel you would like to use to optimize the position of your antenna, you may select it by clicking **Point Antenna** instead of **Continue** on the first screen of the Setup Wizard.

6. Select **Continue** to begin the wizard. The Setup Wizard immediately begins trying to find channels and add them to your system. (If you have previously run the wizard, then any currently stored channels will be removed.)

DOWNLOADED FROM SATELLITEGUYS.US
NOTE: POSSIBLE ROUGH DRAFT
SPECS & INSTRUCTIONS SUBJECT TO CHANGE
WITHOUT NOTICE



Getting Started



7. After the channel scan is complete, you are prompted for information; use the UP and DOWN ARROW and SELECT buttons to complete the setup of your DTVPal DVR. (Select **Next** to go to the next setting or **Back** to go to the previous setting. Select **Help** to view on-screen help for the setting.)



- Select your local time zone, and whether your area observes Daylight Savings Time (DST).
- Use the NUMBER PAD to enter your complete ZIP Code, which is required to retrieve the proper Program Guide data for your area.




IMPORTANT: *If you do not enter your ZIP code correctly, then the information in your on-screen Program Guide will be inaccurate or incomplete.*

- Choose the resolution your HDTV supports (480p, 720p, or 1080i) and its aspect ratio (traditional 4 x 3, or “widescreen” 16 x 9).
 - Choose the SD output type if you do not have a TV that supports any of the HD resolutions.
 - Set the channel 3 or 4 output setting (if you’re using the coaxial connection to your TV). If you have a local or cable channel that broadcasts on channel 3, be sure to change this setting to channel 4. If you do this, you will also need to set your TV’s channel to 4.
8. The Setup Wizard will ask you to wait until it finishes downloading Program Guide data, and then will exit to display live digital TV.
 9. Congratulations! Your DTVPal DVR is now installed and ready to use! To start watching TV, press either the UP or DOWN ARROW buttons on the remote control to change channels, or enter the channel number using the NUMBER PAD.



Note: Some broadcasters choose to send several digital channels in their broadcast range rather than just a single channel. These additional channels are referred to as sub-channels, and are identified by a dash, followed by a number (for example, channel 9-2 is a sub-channel of channel 9). On the NUMBER PAD, enter “00902” to change directly to channel 9-2, for example.




DOWNLOADED FROM SATELLITEGUYS.US

NOTE: POSSIBLE ROUGH DRAFT

SPECS & INSTRUCTIONS SUBJECT TO CHANGE
WITHOUT NOTICE

Using the Remote Control Buttons



Options for Viewing TV

Navigating the Menus

1. Press MENU to see the DTVPal DVR Main Menu. You can access most features from here. We'll show you other short cuts later.
2. Use the UP or DOWN ARROWS to move through the menu options. Or, enter the option number using the NUMBER PAD.
3. Press SELECT to choose a highlighted menu option.
4. Exit a menu by choosing **Cancel** from the on-screen options, or press CANCEL on the remote control.
5. Press VIEW LIVE TV to exit all menus and view current programming.

MENU



CANCEL



VIEW
LIVE TV



Note: In this Guide, we'll say "select" to mean move the highlight to the item and press SELECT on the remote control.

Understanding SD & HD

- Using this HDTV over-the-air receiver, you can view and record both standard-definition (SD) and high-definition (HD) digital programming.
- You can view upconverted SD and native HD over-the-air digital broadcasts on a connected HDTV.
- You can view both native SD and down-converted HD programming on a connected SDTV.

OPTIONS FOR VIEWING TV

Finding a Program: Overview

Channel Up/Down

While watching live TV, use the UP and DOWN ARROWS to change channels one at a time.

DOWNLOADED FROM SATELLITEGUYS.US
NOTE: POSSIBLE ROUGH DRAFT
SPECS & INSTRUCTIONS SUBJECT TO CHANGE
WITHOUT NOTICE

Direct Entry

Tune to a specific channel number by entering it using the NUMBER PAD. To change directly to a sub-channel number, for example 8-3, enter a zero before the number, for example "00803".

Program Guide



- Press GUIDE to open the Program Guide and view the listing of current programs and programs scheduled to air over the next seven days.

GUIDE



Note: Last-minute changes made to programming information and schedules may not always be reflected in Program Guide data.

- Highlight a program to see information, or press INFO for more details.
- Change channels by highlighting a current program and pressing SELECT.
- Set up recordings for future events by highlighting a future program and pressing SELECT or RECORD. See *Recording My Programs* on page 14 for more information.
- Press PAGE UP/PAGE DOWN to view a set of channels one page at a time.
- Move forward, then back in time through the guide by:
 - Press the SKIP FORWARD button to move ahead 24 hours; press SKIP BACK to move back 24 hours.
 - Use the NUMBER PAD to enter the number of hours to move ahead, and then press the RIGHT ARROW. Once you've moved forward, then you can use the NUMBER PAD to enter the number of hours to move back, and press the LEFT ARROW.



RECORD



PAGE



SKIP
FWD



SKIP
BACK



- Note:** You cannot move backward in the guide to the past.
- Press CANCEL or VIEW LIVE TV to view current programming.



CANCEL



VIEW
LIVE TV

DOWNLOADED FROM SATELLITEGUYS.US
NOTE: POSSIBLE ROUGH DRAFT
SPECS & INSTRUCTIONS SUBJECT TO CHANGE
WITHOUT NOTICE

Options for Viewing TV

Browse Banner

The Browse Banner allows you to watch a program while looking at program information on other channels.



- While watching a program, press the RIGHT ARROW to open the Browse Banner.
- The current program's information is displayed at the top of the screen.
- The bottom left of the Browse Banner displays information about the current program on each channel you change to. Use the UP or DOWN ARROWS to change the channel information, and the SELECT button to change channels.
- On the bottom right, move the highlight using the RIGHT ARROW to see what shows are coming on in the future on that channel.

Event Search

Event Search allows you to find programs available in the Program Guide by a keyword within the Title, the Description, or either one. While watching a program, press the LEFT ARROW to open the Event Search screen. You can also press MENU and then select Event Search from the Main Menu.

REMOTE CONTROL SHORTCUT: Press SEARCH (#) to open the Keyword search screen.

SEARCH



Searching for Specific Keywords

1. Enter a search term by using the on-screen keyboard, or entering letters using the remote control NUMBER PAD.
2. Select **Done** and then results matching your keyword are displayed.
3. If you want to use different options for this search then previous searches, select **Options** and then choose:
 - **Title** to search by program title, **Description** to search in the Program Guide descriptions, or **Title/Description** to search both.
 - **Exact Match** for a very specific search just on your keyword(s).
4. If you chose different search options, the results update automatically.

History

Choose **History** to perform new searches using keywords or other criteria you have previously used and saved on the Event Search screen. Note that you must select "Save" after a search to see that search in the History list.

DOWNLOADED FROM SATELLITEGUYS.US

NOTE: POSSIBLE ROUGH DRAFT

SPECS & INSTRUCTIONS SUBJECT TO CHANGE
WITHOUT NOTICE

SETUP MENU

Press MENU, and then select **Setup** to use the Setup Menu to:

- Set and reset password-protected locks, either based on programming ratings or on a channel-by-channel basis.
- Run the Setup Wizard again, or change any of the system settings you selected when the wizard ran previously. You can even restore the system to the factory defaults from before the wizard was run.
- Change the primary/alternate language and audio output settings.



DVR MENU

Press DVR or press MENU and select **DVR** to access many digital video recording features.

My Recordings

Displays all of the programs you have recorded on the DTVPal DVR. See *Recording My Programs* on page 14 for more details. Select **Options** to change the way the list of recordings is sorted.

REMOTE CONTROL SHORTCUT: Press DVR once to open the DVR Main Menu. Press DVR twice to open the My Recordings list.



Daily Schedule

Displays all the timers you have set, for today or the future. Select **Timers** to go **Create** a new event timer, or to **Edit** or **Delete** an existing timer. See *Setting Up Timers* on page 14 for more details.

CONTROLLING LIVE TV

You can use the DVR buttons on your remote control to control live TV. While watching live TV:

- Press PAUSE to pause a live program for up to one hour. Press PLAY to continue watching the program or press VIEW LIVE TV to catch up to real time.
- Press SKIP BACK to jump back in the program by 10 seconds.



Recording My Programs

- Press SKIP FORWARD to jump ahead by 30 seconds if you've paused or reversed the program.
- Press BACK one to four times to fast reverse, or FWD one to four times to fast forward, at one of four different speeds: 4x, 15x, 60x, or 300x. Press PLAY to continue watching the program from any point.
- Press PAUSE, then BACK or FWD for slow motion at 1/15th normal speed, and BACK or FWD a second time for 1/4th normal speed. Press BACK or FWD a third time to return to normal speed.
- Press PAUSE, then SKIP BACK or SKIP FWD to move frame-by-frame.
- At any time, you can press VIEW LIVE TV to catch up to real time in the programming.

See also *Finding and Watching Recorded Programs* on page 15 for DVR functionality with recorded events.



RECORDING MY PROGRAMS

Recording What You're Watching Now

To record a program you are currently watching, press RECORD. Select **OK** to start recording the current program now until it ends. The program will be stored on the DTVPal DVR. To stop recording a program that you are watching, press STOP, and then select **OK**.



Setting Up Timers

Use a timer when you want to view or record a future program. There are two types of timers:

- **DVR** – Records a program to your DTVPal DVR hard drive.
- **Auto Tune/Reminder** – Displays an on-screen reminder when your program is about to start. In addition, Auto Tune changes channels.



Tip: Your DTVPal DVR records programming whenever it is plugged in. The green front-panel light can be on or off when recordings are being made.

DOWNLOADED FROM SATELLITEGUYS.US
NOTE: POSSIBLE ROUGH DRAFT
SPECS & INSTRUCTIONS SUBJECT TO CHANGE
WITHOUT NOTICE



Note: HD programs require up to six times more space than SD programs, and will fill up the capacity of the DTVPal DVR faster.



Finding and Watching Recorded Programs

My Recordings List

Press DVR and select **My Recordings** to view your list of recorded programs.

REMOTE CONTROL SHORTCUT: Press DVR twice.

While watching a program from the My Recordings list:

- Press PAUSE to pause the program. Press PLAY to continue watching the program.
- Press SKIP BACK to reverse by 10 seconds.
- Press SKIP FORWARD to jump ahead by 30 seconds in the program.
- Press BACK one to four times to fast reverse, or FWD one to four times to fast forward, at one of four different speeds: 4x, 15x, 60x, or 300x. Press PLAY to continue watching the program from any point.
- Press PAUSE, then either BACK or FWD for slow motion.
- Press PAUSE, then either SKIP BACK or SKIP FWD one or more times to move frame-by-frame.

CAUTION: On some TVs, the presence of fixed images for extended periods of time may cause permanent imprints on the screen.

PREFERENCES MENU

Press MENU, and then select **Preferences** to use the Preferences Menu to change user settings for:

- How the on-screen Program Guide displays (see *Customizing the Guide and Channel Lists* on page 23)
- Showing or hiding Closed Captions for programming (see *Closed Captioning* on page 24)
- Adjusting the duration of, or disabling, Inactivity Standby (see *Inactivity Standby* on page 25).

TIMERS MENU

Press MENU, and then select **Timers** to use the Timers Menu to:

- View all existing timers for events.
- Create a new timer, or Edit or Delete an existing timer.

Timers can be either of two types:

- **DVR** – records an event automatically, even if the receiver is in standby (green front-panel light is out) at the time the event begins. Note that the receiver must be connected to a power source.
- **Auto Tune** – pops up a notice when an event is about to begin, and changes the channel to the new event unless you stop it.

Several options may be highlighted with the UP or DOWN ARROW keys, depending on whether a timer is intended for one single event, or should repeat periodically for a program.

You can select the timer to operate:

- **Once**
- **Daily**
- **Weekly**
- **Mon.–Fri.**



Note: Events that are recorded by timers that you set to repeat will be displayed in the list using the name of the first event recorded by the timer.

USING DOLBY® DIGITAL SURROUND SOUND

Press MENU and select **Setup**, then **Dolby Digital**, to access the Dolby Digital Menu. Dolby Digital gives you the capability to enjoy programs with surround sound. In order to enjoy full, 5.1-channel surround sound, you will require an external Dolby Digital decoder. Refer to the user's guide for your system's decoder device for more information.

DTVPal DVR uses a HDMI port to output digital audio and video, or an optical port to output digital audio only. The HDMI or optical connections can provide two audio data types: Dolby Digital and Linear PCM (only Dolby Digital audio through these connections can then be decoded to provide full, 5.1-channel surround sound).

DOWNLOADED FROM SATELLITEGUYS.US

NOTE: POSSIBLE ROUGH DRAFT

SPECS & INSTRUCTIONS SUBJECT TO CHANGE
WITHOUT NOTICE

Using Dolby® Digital Surround Sound

Select one of the following, depending on your audio system:

- **Dolby**—select this option if the stereo system or audio amplifier can decode only Dolby Digital and will not process Linear PCM signals. See your stereo equipment's owner's manual for more details on the amplifier or decoder.
- **PCM Only**—select this option only if the stereo system or audio amplifier cannot decode Dolby Digital signals.

You can also choose from two different sound settings on this screen:

- **Standard**. When you use this setting, the dynamic range is wider, which makes music and loud noises louder, but voices quieter. This setting is good if you don't mind turning the volume up louder to hear the speaking portions of programs.
- **Night**. When you use this setting, the dynamic range is narrower, which makes music and loud noises quieter, but voices louder. This setting is good if you need to keep the volume lower.





DOWNLOADED FROM SATELLITEGUYS.US
NOTE: POSSIBLE ROUGH DRAFT
SPECS & INSTRUCTIONS SUBJECT TO CHANGE
WITHOUT NOTICE

Customizing Receiver

- SETTING UP KEY FEATURES
- RESETTING FACTORY DEFAULTS
- PROGRAMMING YOUR REMOTE CONTROL
- SOFTWARE UPGRADE OPTIONS
- TV GUIDE




Setting Up Key Features

SETTING UP KEY FEATURES

Locks

Locks allow you to block channels or programs by requiring a password to be entered before they can be viewed.

Access the Locks menu by pressing MENU on the remote control, selecting **Setup**, then selecting **Locks**, then following the steps below. If you previously set a password, you'll need to enter the password to access the Locks menu. After you choose your Locks settings, you'll need to create a password and lock the system for the Locks to take effect.



Locks Menu

Locking specific channels

To require a password to be entered to view specific channels:

1. Select **Channel Locks** from the Locks menu.
2. Use the UP and DOWN ARROWS to find the channels you want to block. Press SELECT to include the channel in the list of locked channels. A channel is selected when it has a filled-in box next to it.
3. If you want to hide the selected channels from being displayed in the Program Guide and other channel lists, select **Yes** under Hide Locked Channels. Select **Done** to save your changes.
4. Follow the steps in *Locking your DTVPal DVR* to apply the channel locks.



Channel Settings

Locking programs based on ratings

Your DTVPal DVR supports a variety of ratings categories. These ratings depend on information about the program included by the broadcaster.

DOWNLOADED FROM SATELLITEGUYS.US

NOTE: POSSIBLE ROUGH DRAFT

SPECS & INSTRUCTIONS SUBJECT TO CHANGE
WITHOUT NOTICE


Setting Up Key Features

Broadcasters may use the Age and Content Guidelines, or the MPAA (Motion Picture Association of America) Guidelines.

- Entire Audience—Includes rating categories None, TV-G, TV-PG, TV-14, and TV-MA.
- Children—Includes rating categories TV-Y and TV-Y7.
- MPAA (Motion Picture Association of America)—Includes rating categories N/A, G, PG, PG-13, R, and NC-17.
- Extended—Includes rating categories Dialog, Language, Sex, Violence, and Fantasy Violence.

To block programs based on rating, use the following steps:

1. Select **Ratings Settings** from the Locks menu.
2. To easily select all categories for locking or unlocking, select **Block All** or **Unblock All** **All**.
3. To edit a specific category, highlight the category.
4. For that Category, press **SELECT** on the highest Rating you want to be viewed without a password. Anything with a rating higher than that will require entering your password before viewing. For example, if you select TV-G, programs with None or TV-G can be viewed without a password.
5. Select **Done** to save your changes.
6. Follow the steps in *Locking your DTVPal DVR* to apply the ratings locks that you have selected.



Ratings Settings

Locking your DTVPal DVR

After you set the channel locks and the ratings locks, you must lock the DTVPal DVR for the settings to take effect. Locking the DTVPal DVR will also protect any protected recordings from being deleted, as well as prevent anyone from formatting the hard-disk drive.

To lock your receiver, select **Lock System** on the Locks menu.

- If you already have a password, enter it using the remote's **NUMBER PAD**.

Customizing Receiver

Setting Up Key Features

- Enter a password using the NUMBER PAD on the remote control in the Password field.



- Enter the new password again when prompted. Your DTVPal DVR is now locked.

Note the following when using the Locks menu after locking your system:

- If you try to access a locked item or open the Locks menu, the DTVPal DVR displays a message asking you to enter the password. Enter the correct password to continue.
- The DTVPal DVR permits three attempts to enter the correct password. If you fail all three attempts at entering the correct password, then the DTVPal DVR does not allow you to try again for several minutes.
- If you exit a locked item or close the Locks menu, you must re-enter the password to access the item.

DOWNLOADED FROM SATELLITEGUYS.US
NOTE: POSSIBLE ROUGH DRAFT
SPECS & INSTRUCTIONS SUBJECT TO CHANGE
WITHOUT NOTICE

Customizing the Guide and Channel Lists


Changing the Order of the Channels

Press **MENU**, select **Preferences**, and then **Guide Display**. Under **Direction**, You can set up the on-screen Program Guide to list channels in descending order, with the highest channel number at the bottom of the screen, or in ascending order, with the highest channel number at the top of the screen. The default setting is to list channels in descending order.


Changing the Type of Guide Display

The DTVPal DVR comes set to display the standard-size Program Guide with descriptions for the highlighted program or event. However, you can choose the style of Guide Display that you like in the EPG Preferences menu.

- **Medium Text** - This is the default option.



- **Large Text** - Choose this option if you'd like to see larger text and fewer hours of schedule per page on the Program Guide.



Customizing Receiver

Setting Up Key Features

- **Small Text** - Choose this option if you'd like to see more channels and three hours of schedule in smaller text per page on the Program Guide.



Changing Display Formats

When viewing live TV or playing back a recording, you can press **PAGE UP** (to format the SD video outputs) or **PAGE DOWN** (for the HD outputs) or the **FORMAT/*** button (for both SD and HD outputs) to cycle through the options for screen display format: Auto (the default, based on data about the displayed content), Normal (as on **Installation** screens under **System Setup**), Stretch, Partial Zoom, and Zoom.

◀/FORMAT



Changing Languages

You may be able to change the audio language of some programs. Press **MENU**, select **Setup**, **Audio Setup**, then select to use your primary or alternative language. Also, when viewing live TV or playing back a recording, you can press the **SAP** button to hear the Secondary Audio Program for programming with SAP. Press **SAP** again to turn the feature off.



Closed Captioning

Your DTVPal DVR has many options for Closed Captioning (CC), including font size, colors, edge style, service and opacity. To enable Closed Captioning for when viewing programming with captions, press **CC**, or you can press **MENU**, select **Preferences**, and select **Closed Captions**, then **Captions On**. Select either off or on, and then **Done**. When viewing live TV or playing back a recording with closed captions turned on, you can press **CC** again to turn the feature off.



DOWNLOADED FROM SATELLITEGUYS.US
NOTE: POSSIBLE ROUGH DRAFT
SPECS & INSTRUCTIONS SUBJECT TO CHANGE
WITHOUT NOTICE

Inactivity Standby

You can set up a period of time after which, if there has been no activity (such as changing channels or using the DVR buttons), the DTVPal DVR will go into standby mode (the green front-panel light will go out). This does not affect any event timers you have set, since the DTVPal DVR saves recordings when in standby. To disable this feature or change its duration, press **MENU**, select **Preferences**, **Inactivity Standby**, make your settings and then select **Done**.

RESETTING FACTORY DEFAULTS

Press **MENU**, select **Setup**, **System Setup**, and then **Restore Factory Defaults**. A warning message will display on the screen. Select **Yes** to reset preferences and user settings for the DTVPal DVR. This will not affect any recordings you have saved, whether they are protected or not.

DIAGNOSTICS MENU

Press **MENU**, select **Setup**, **System Setup**, and then **Diagnostics**. You can use options on this menu to help diagnose and troubleshoot issues you may be having with your DTVPal DVR. The options include:

- **Video Mem** - Tests the VRAM in your DTVPal DVR for corruption.
- **HDMI** - Tests the HDMI connection to your TV, if one is present.
- **HDD** - Tests for problems with the hard-disk drive in the DTVPal DVR.
- **USB Test** - Tests the connection to a USB device, if one is present.
- **Ethernet** - Tests the DTVPal DVR's network connection, if you use one.
- **Counters** - Allows you to view and reset a number of system counters.

PROGRAMMING YOUR REMOTE CONTROL

The remote control gives you access to all the features of your DTVPal DVR. You can set up the remote to control as many as three additional devices. These devices can be your TV, VCR or DVD player, and a third device (such as a VCR or DVD player, audio receiver, tuner or amplifier, or another TV or DISH Network satellite receiver). To use your DTVPal DVR remote control to operate these other devices, you must program your remote control for these other devices. You can enter codes directly to control your devices, or you can scan the remote control's database of device codes to find the right one.

DOWNLOADED FROM SATELLITEGUYS.US

NOTE: POSSIBLE ROUGH DRAFT

SPECS & INSTRUCTIONS SUBJECT TO CHANGE
WITHOUT NOTICE



Programming Your Remote Control

Setting Up Devices by Entering Codes

You can set up the remote to control other devices using the device codes listed on page 27.

1. Turn the device on.
2. Find the brand name in the tables.
3. Press and hold the mode button for the device until all the mode buttons light up.
4. For AUX mode, press 0 for a TV, 1 for a VCR, or 2 for an audio tuner/amplifier.
5. Using the NUMBER PAD, enter one of the three-digit device codes for your brand from the table. Then press POUND (#).
6. Wait for three flashes of the mode light. If it doesn't, go back to step 3.
7. Press POWER to turn off the device. If the device does not turn off, go to step 8.
8. Turn the device back on and try some other buttons to make sure they work. If the code works for other buttons, stop here.
9. If the code doesn't work, repeat steps 3 through 7 with the next device code from the tables.
10. If you can't find a code that works, then try *Setting Up Using Device Codes Scan*.

SEARCH



POWER



Setting Up Using Device Codes Scan

1. Turn the device on.
2. Press and hold the Mode button for the device until all the Mode buttons light up.
3. Press POWER.
4. Press the UP (or DOWN ARROW, but not both) until the device turns off. Then press POUND (#).
5. Wait for three flashes of the mode light. If it doesn't flash three times, then go back to step 3.
6. Turn the device back on and test to make sure it works with other remote-control buttons, like VOLUME.



VOLUME



Programming Your Remote Control

Remote Control Device Codes

These tables contain the manufacturer codes for programming the remote to control your TV, a VCR, DVD player, or audio amplifier. Every attempt has been made to include all codes. If your equipment brand is not listed or if the codes do not work, the remote may not control your equipment. In some cases codes may operate some but not all buttons shown in this guide.

TV CODES

Programming in AUX mode: In most cases, use these codes to program in TV mode; however, if programming in AUX mode, press 0 before entering the TV code.

Abex 230
Action 662
Admiral 521 605 675
Aiko 727
Akai 570 573
Alleron 682
A-Mark 620
Amtron 657
Anam National 509 541 620 651 657 698
AOC 505 506 519 520 573 620 627 652 653 654
Apex 743 744 745 757 814 815
Archer 620
Audiovox 620 657 662
Baycraft 536
Belcor 652
Bell & Howell 590 675 683
Bradford 657
Brockwood 627 652
Broksonic 562 748 752
Candle 506 523 525 536 627 652 654
Candle/Citizen 573
Capehart 519 627
Circuit City 627
Citizen 506 516 523 524 525 526 590 652 654 657 658 680 727
Colortyme 573 627 652 654
Concerto 523 652 654
Contec Cony 662
Contec/Cony 541 655 657 726
Craig 536 541 657 662 694
Crown 526 536 657
Curtis Mathes 506 516 526 573 590 641 645 650 652 654 658 680 683 703 708
CXC 541 657 662
Cytron 903 904
Daewoo 505 524 526 529 530 531 573 630 652 653 654 658 684 698 719 727 816
Daytron 526 627 652 654 658
Dell 772 773 774
Dimensia 645 650
Dixi 566 620

Dumont 501 627 652
EchoStar 722
Electrohome 526 573 651 652 654 656 709 728
Emerson 526 534 536 541 573 590 627 636 642 648 652 654 655 657 658 662 682 683 692 696 699 720 816
Envision 506 573 652 654
Fisher 542 590 683
Fortress 573
Fujitsu 534 682 694
Funai 534 541 657 662 682 694
Futuretech 541 657 694
GE 508 509 543 544 630 645 646 650 651 652 654 676 690 691 698 701 715 716 725 728 742 779 809 859
General Electric 627
Gibraltar 501 652
Goldstar 505 523 526 545 546 566 573 652 653 654 655 656 658 693 730
Granada 627
Grand 627
Grunpy 657 682
Hallmark 627 652 654
Harmon/Kardon 561
Harvard 657
Hinari 534
Hisense 759
Hitachi 523 526 548 549 553 554 555 585 597 626 636 638 643 648 652 654 655 702 718 726 786 788 789 790 791 792 801 802
IMA 657
Infinity 566
JBL 566
JC Penney 505 506 516 525 526 543 546 631 645 646 650 652 653 654 658 676 680 690 691 701 725 726 728 730
Jensen 556 573 652 654
JVC 508 557 559 642 649 655 676 726 735 736 737 812 817
Kawasho 548 561 573 652 654
Kenwood 506 573 652 654 656
Kloss 561 610
Kloss Novabeam 657 698 723 724
KTV 526 541 573 657 658 662 696
LG 653 766
Lloyds 627
Lloytron 526
Loewe 566
Logik 675
Luxman 523 652 654
LXI 563 566 590 595 617 631 635 645 646 650 654 683 691 701 725
M. Wards 500 505 506 534 543 567 568
Magnasonic 573



Customizing Receiver

Programming Your Remote Control

Magnavox 506 520 525 536 566 567 568 573 610 652
654 656 723 724 729 762 818 887 888
Majestic 675
Marantz 506 566 573 652 654
Megatron 627 654
Memorex 590 627 653 654 675 683 720
MGA 504 505 506 542 571 573 627 652 653 654 656
728
Midland 501 646 658 676 725 730
Mitsubishi 504 505 542 570 571 572 573 597 623 627
652 653 654 656 705 728 787 799 804
Mitsui 769
Montgomery Ward 675
Motorola 521 605 651
MTC 505 506 516 523 573 627 652 653 654 680
Multitech 657
NAD 502 617 627 631 635 637 654
National 509
NEC 505 506 507 517 523 573 627 651 652 653 654
731 732
Nikkai 612
Nikko 654 727
Normandic 717
Novabeam 561
NTC 727
Nyon 701
Olevia 766 773
Onwa 541 657
Optimus 637
Optonica 521 605 607
Orion 694
Osaki 612
Panasonic 508 509 512 566 644 651 662 676 685 689
698 700 716 734 761 765 780 784 811 819 820 821
822 823 867 868 869 870 871 872 873 874 875 876
877 878 879 880 881 882 883 884 885 886 889 890
900
Philco 505 506 525 536 568 573 610 651 652 653 654
655 656 723 724 729
Philips 525 566 651 652 655 656 690 723 724 729 770
782 824 825 826 827 828 891 892 893 894
Philips Magnavox 782 826 827 828 829
Pilot 652 658
Pioneer 502 548 576 636 637 648 652 654 708
Portland 505 526 573 652 653 654 658 727
Price Club 680
Prism 676
Proscan 645 646 650 691 725 742 857
Proton 513 519 526 536 585 627 652 654 655
Pro View 902
Pulsar 501 652
Quasar 508 509 651 676 698 700 860 861 862 895 896
Radio Shack 526 541 590 607 612 645 662 683 698
Radio Shack/Realistic 590 607 650 652 654 655 657
658 683 730
RCA 503 505 548 630 633 634 636 641 645 646 648
650 651 652 653 654 656 691 698 701 708 715 716
725 742 749 763 776 805 830 831 832 863 864
Realistic 590 645 683
Runco 501
Sampo 506 519 652 654 658 698 730 746
Samsung 505 506 516 523 526 566 573 612 627 647
652 653 654 655 656 658 680 704 717 730 738 755
833 858 897
Samwon 620

Sansui 754 834
Sanyo 542 590 652 683
SBR 566
Schneider 566
Scotch 654
Scott 526 534 541 600 652 654 655 657 662 682 696
701
Sears 523 534 542 563 590 595 601 604 617 627 631
635 645 646 650 652 654 656 682 683 688 691 703
725 726
Seimitsu 627
Sharp 521 526 585 605 607 628 629 652 654 655 658
739 740 741 777 794 803 835 836 898
Shogun 652
Signature 675
Silver 573
Simpson 525
Solavox 612
Sony 500 640 690 758 781 783 795 796 797 798 806
807 808 810 837 838 839 840 841 842 843 844 845
Soundesign 525 536 541 627 652 654 657 682
Spectricon 520 620
Squareview 694
SSS 505 541 573 652 657
Starlite 657
Supra 523
SVA 901 905
Sylvania 506 525 536 566 568 569 573 600 610 652
654 656 723 724 729 733 756 764
Symphonic 632 657 662 692 694 846
Tandy 521 605
Tatung 509 651 698
Technics 508 676
Techwood 523 573 652 654 676
Teknika 504 505 512 516 523 524 525 526 534 536
541 573 644 652 653 654 655 657 658 662 675 680
682 685 726 727
Tera 513
Thomas 627
Thompson 709
TMK 523 573 627 652 654
Toshiba 516 590 617 631 635 680 683 688 750 771
785 793 847 848 849 850 851 852 853 854 855 856
865 866
Totevision 526 658
Toyomenko 627
Universal 543 690
Vector Research 506
Victor 557
Video Concepts 570
Vidtech 505 573 627 652 653 654
Viewsonic 760
Wards 536 573 607 645 650 652 653 654 656 675 682
690 715 723 724 729
White Westinghouse 816
Yamaha 505 506 573 652 653 654 656
York 627
Zenith 501 520 639 652 675 693 775 778 813 899
Zonda 620

VCR CODES

Programming in AUX mode: In most cases, use these codes to program in VCR mode; if

DOWNLOADED FROM SATISFYGUY.US

NOTE: POSSIBLE ROUGH DRAFT

SPECS & INSTRUCTIONS SUBJECT TO CHANGE
WITHOUT NOTICE

Programming Your Remote Control

programming in AUX mode, press 1 before entering the VCR code.

Adventura 588
Aiwa 588 622 623
Akai 513 515 516 517 518 568 682
American High 678
Amstrad 588
ASA 556
Asha 675
Audio Dynamics 592 600
Audiovox 676
Beaumarck 675
Bell & Howell 581
Broksonic 559
Calix 676
Candle 534 594 675 676
Canon 554 678 679
Citizen 534 591 592 594 675 676
Colortyme 592
Craig 591 675 676
Curtis Mathes 554 592 594 605 607 675 678 679
Cybernex 675
Daewoo 534 547 559 588
DBX 592 600
Dimensia 607
Dumont 549
Dynatech 588
Electrohome 512 676
Electroponic 676
Emerson 505 508 509 511 512 518 534 559 568 588
 590 618 676 678
Finlandia 549
Finlux 549 556 588
Fisher 549 581 584 588 610
Fuji 678
Funai 588
Garrard 588
GE 551 552 554 572 591 605 607 675 678 679
Go Video 557 558 620
Goldstar 592 594 676
Goodmans 585
Gradiente 588
Granada 549 581
Grundig 556
Harley Davidson 588
Harman Kardon 592
Harmon/Kardon 568 592
Headquarter 581
Hitachi 536 538 539 540 588 595 597 682
Instant Replay 678
ITT 518
JC Penney 554 581 591 592 594 595 600 675 676 678
 679
JCL 678
Jensen 595 682
JVC 561 562 563 581 592 594 600 682
Kenwood 562 581 592 594 600 682
Kodak 676 678
LG 676
Luxor 518
Lloyd's 588
LXI 676
M. Wards 512 554 585 590 591
Magnavox 527 533 554 556 678 679 797 798

Magnin 676
Marantz 554 556 581 585 592 594 600 678
Marta 676
Matsushita 678
MEI 554 678
Memorex 533 549 554 566 581 585 588 675 676 678
MGA 512 567 568
MGN Technology 675
Midland 579
Minolta 595
Mitsubishi 512 562 567 568 570 571 595
Motorola 678
MTC 544 588 675
Multitech 579 588 675
Mutitech 591
NEC 562 581 592 594 600 682
Nikko 676
Noblex 675
Olympus 678
Optimus 676
Optonica 585
Panasonic 523 554 598 614 628 633 678 679 777 780
 781 782 783 784 785 786 787 788 789 790 791 792
 793 794 795 796 799 808 809 810
Pentax 592 595
Pentax Research 594
Perdio 588
Philco 554 678 679
Philips 554 556 585 678 801 802 803 804
Pilot 676
Pioneer 562 574 575 576 600
Proscan 605 607
Pulsar 533
Quarter 581
Quartz 581
Quasar 554 678 679 770 771 772 805 806
Radio Shack 512 607 610 676
Radio Shack/Realistic 581 584 588 675 676 678 679
Radix 676
Randex 676
RCA 518 525 527 528 591 595 605 607 615 631 649
 675 678 773 774 775
Realistic 534 549 554 581 584 585 588 675 676 678
 679
Ricoh 502
Runco 533
Salora 567 581
Samsung 515 517 534 579 591 675 755 807
Sanky 533
Sansui 544 562 600 682
Sanyo 549 581 583 675
SBR 556
Scott 508 534 559 590
Sears 549 581 584 595 610 676 678
Sharp 512 585 595 607 625
Shintom 595
Shogun 675
Singer 678
Sony 500 501 502 504 768 778
STS 678
Sylvania 554 556 567 588 678 679 756
Symphonic 588 594
Tandy 581 588
Tashiko 676



DOWNLOADED FROM SATELLITEGUYS.US
 NOTE: POSSIBLE ROUGH DRAFT
 SPECS & INSTRUCTIONS SUBJECT TO CHANGE
 WITHOUT NOTICE

Programming Your Remote Control

Tatung 594 682
Teac 588 594 682
Technics 554 633 678
Teknika 554 588 676 678
TMK 675
Toshiba 534 535 567 584 590 769 776
Totevision 591 675 676
Unitech 675
Vector Research 534 592 600
Victor 561 562 600
Video Concepts 534 568 592 600
Videosonic 591 675
Wards 534 588 595 675 676 678
XR-1000 588 678
Yamaha 581 592 594 600 682
Zenith 500 501 533 779

Samsung 652 667 668 691 740 741 820 821 844 845
866 875 881 705
Sansui 725 754
Sanyo 643
Sharp 669 727 865
Sony 617 645 670 671 729 730 731 768 817 818 830
831 832 836 837 838 843 847 848 849 851 852 853
857 858 864 883 884
Sylvania 658 764 829
Teac 732
Technics 733
Techwood 664
Toshiba 616 646 672 735 736 814 815 819 825 826
827 828 834 846
Yamaha 737 739
Zenith 673 824

DVD PLAYER CODES

Programming in AUX mode: In most cases, use these codes to program in VCR mode; if programming in AUX mode, enter 1 and then the DVD Player code.

Aiwa 634 694
Alpine 653
Apex 654 655 744 757 835 839
Archos 885
BOSE 758 811
Broksonic 656 752
Clarion 696
Classic 695
CyberHome 833
Cytron 904
Daewoo 657 859
Denon 697 699 700
EchoStar 722
Emerson 658
Fisher 659
Funai 658
GE 702 703
Go Video 692 693 822
GPX 704
Hitachi 660 705 706 707 740 823 860 668
JVC 689 711 850 861 862 863
Konka 637 638 753
Koss 745
Magnavox 661
Memorex 709
Mintek 710
Mitsubishi 767 867
Norcent 711
Oritron 723
Panasonic 639 663 699 714 715 716 734 765 813 840
841 855 856 868 869 870 871 872 873 882
Philips 766 874
Pioneer 665 719 812 876 877 878 879 880
Proscan 720
Qwestar 723
RCA 666 690 749 816 842 854
Sampo 724

TUNER/AMPLIFIER CODES

Programming in AUX mode: Press 2 before entering the tuner/amplifier code.

Aiwa 636 641 656 687 718 720 724 725 726
BOSE 761 780
Carver 653
Citizen 709
Denon 647 674 759 760 762 807 809 814 835
Fisher 653
GE 711
Goldstar 677 690
Harman Kardon 640 751
Harmon/Kardon 672
Hitachi 717
JBL 640
JVC 637 683 703 725 786 827
Kenwood 676 691 726 728 774 795 828 829 830 831
832 840 842
Magnavox 654 705
Marantz 651 764
Nakamichi 671
NEC 716
Onkyo 642 660 662 678 785 788 790 791 792 796 801
Optimus 648 664
Panasonic 643 644 652 783 797 798 799 808 810 815
816 817 818 819 820 821 822 824 825 826 833 836
837 838 839
Pioneer 658 667 668 679 702 767 770 772 779 802
806 844
Proton 654 705
Quasar 652
RCA 635 638 704 727
Sharp 712 713 714 715
Sherwood 646 670
Sony 639 645 687 728 729 730 765 766 769 771 773
775 776 777 778 781 782 784 787 789 793 794 803
811 812 813
Soundmatters 763
Teac 684
Technic 652
Technics 643 644 652 768 804 805 843
Toshiba 710
Victor 703
Yamaha 663 730 731 732 733 823 834 841

DOWNLOADED FROM SATELLITEGUYS.US

NOTE: POSSIBLE ROUGH DRAFT

SPECS & INSTRUCTIONS SUBJECT TO CHANGE
WITHOUT NOTICE

Programming Your Remote Control

TV/VCR COMBO CODES

Programming for combination

equipment: Program the remote control in TV mode using the TV code and then in VCR mode using the VCR code.

	TV Code	VCR Code
Magnavox	887	797
	888	798
Philips	891	801
	892	802
	893	803
	894	804
Quasar	860	770
	861	771
	862	772
	895	805
	896	806
RCA	863	773
	864	774
Samsung	755	755
	897	807
Sylvania	756	756

TV/DVD COMBO CODES

Programming for combination

equipment: Program the remote control in TV mode using the TV code and then in VCR mode (or AUX – press 1 before entering the DVD code) using the DVD code.

	TV Code	DVD Code
Apex	757	757
Broksonic	752	752
Cytron	904	904
Panasonic	734	734
	765	765
RCA	749	749
Sansui	754	754
Sylvania	764	764
Toshiba	865	814
	866	815

TV/DVD/VCR COMBO CODES

Programming for combination

equipment: Program the remote control in TV mode using the TV code, then in VCR mode using the VCR code, and then DVD in AUX mode (press 1 before entering the DVD code) using the DVD code.

	TV	DVD	VCR
Panasonic	900	882	810

TV/VCR/TUNER COMBO CODES

Programming for combination

equipment: Program the remote control in TV mode using the TV code, then in VCR mode using the VCR code, and then tuner in AUX mode (press 2 before entering the tuner code) using the tuner code.

	TV	VCR	Tuner
Panasonic	867	796	797
	868	799	798
	869	808	799
	870	780	839
	871	781	838
	872	782	837
	873	783	836
	874	784	833
	875	785	826
	876	786	825
	877	787	824
	878	788	822
	879	789	821
	880	790	820
	881	791	819
	882	792	818
	883	793	817
	884	794	816
	885	795	815
	889	809	808

Software Upgrade Options

SOFTWARE UPGRADE OPTIONS

Software upgrades may be made available to users of the DTVPal DVR, either to add new features or fix issues with existing ones. It is possible to upgrade the software in your DTVPal DVR using the USB 2.0 or Ethernet connections on the rear panel. A software upgrade does not affect existing recordings and cannot be performed when recording is active.

Follow the on-screen instructions and never turn your DTVPal DVR off while a software download or update is taking place. This process can take as long as 5 minutes to complete, after which the DTVPal DVR will restart and refresh its Program Guide information.

Upgrading via USB

Go to www.dtvpal.com to get the latest version of DTVPal DVR software and for more details on how to use this feature.

Upgrading via Ethernet

Simply connect your DTVPal DVR to your broadband home network using an Ethernet connection and once your DTVPal DVR is in standby (the green front-panel light is out), it will automatically download the latest compatible software within an hour. An immediate download can be forced by pressing MENU, selecting **Setup**, **Broadband**, and then **Software Update**. For more information and detailed upgrade instructions, please go to www.dtvpal.com

TV GUIDE

TV Guide On Screen or Guide Plus Setup

You only need to perform the following steps if you have a TV, DVD recorder, or VCR that includes TV Guide On Screen or Guide Plus. If you do not have a TV Guide On Screen or Guide Plus device, you will be able to use the built-in Program Guide in your DTVPal DVR.

If you are currently using TV Guide On Screen or Guide Plus in your analog TV, DVD recorder, or VCR for over-the-air TV reception (not cable or satellite service), you will need to change your TV Guide On Screen/Guide Plus setup option to continue receiving your TV Guide On Screen/Guide Plus listings.

The steps provided walk you through the changes you need to make to continue receiving show listings when your DTVPal DVR is connected to your Guide-enabled product.

For more detailed instructions or updated support information, refer to www.tvgos.com/support.

Getting Started

To set up the TV Guide On Screen to communicate with your DTVPal DVR, you'll need:

- **G-LINK Cable**—this cable is required to continue receiving TV Guide On Screen/Guide Plus listings in your Guide-enabled product. The G-LINK cable was shipped with your original TV Guide On Screen/Guide Plus-enabled TV, DVD recorder, or VCR. If you no longer have the G-LINK cable, visit www.tvgos.com/support.
- **Substitute ZIP Code**—you will need the five-digit code associated with your broadcast area. During setup, you will enter the Substitute ZIP Code in place of your actual ZIP code. These codes are provided on page 38 of this User's Guide.

Setting Up Your DTVPal DVR

1. Connect your DTVPal DVR using the instructions on page 2. You should have connected the **TV SET OUT** or **AUDIO/VIDEO** output to the corresponding input on your Guide-enabled TV, DVD recorder, or VCR.

TV Guide


- Using your DTVPal DVR remote control, press MENU, select **Setup**, then **System Setup**, then **TV Guide & Guide +**.



TV Guide Setup

Connecting the G-LINK Cable

- Connect the G-LINK cable to the G-LINK jack on the back of your TV Guide-enabled TV, DVR recorder, or VCR.



- Place the G-LINK wand approximately one inch in front of the remote control sensor on your DTVPal DVR. Use tape to secure the G-LINK wand to the DTVPal DVR front panel.
Note: The remote control sensor is located in the middle of the front panel of your DTVPal DVR.



DOWNLOADED FROM SATELLITEGUYS.US

NOTE: POSSIBLE ROUGH DRAFT

SPECS & INSTRUCTIONS SUBJECT TO CHANGE
WITHOUT NOTICE

Updating TV Guide On Screen and Guide Plus Setup

After connecting your DTVPal DVR to your TV Guide On Screen or Guide Plus-enabled device, use these steps to complete the setup.

Note: The menu options on your Guide-enabled device may differ from the ones described here.

1. Using the remote control for your Guide-enabled TV, DVD recorder, or VCR, press **GUIDE** to open your Guide Listings screen.
2. On the Service Bar, select **Setup**, then **Change System Settings**.
3. If available, select **No, repeat setup**. Otherwise, follow the on-screen prompts.

Entering Your Location

The Guide uses setup information to provide TV show listings and channel lineups for your area.

1. Select **USA** as the country.
2. Use the remote control **NUMBER PAD** or the **UP** and **DOWN ARROWS** to enter the Substitute ZIP Code for your area. See page 38 for the ZIP code listing.

Set Up Your DTVPal DVR

For your Guide to communicate with your DTVPal DVR, the Guide must be set up as though the DTVPal DVR is a cable box, even though you do not have cable service. Use these steps to finish setting up your DTVPal DVR.

1. Select **Cable with a Cable Box** or **Yes I have cable**.
2. If asked, select the type of audio/video input you used to connect your DTVPal DVR to your Guide-enabled device, then follow the on-screen prompts.
3. If a connection diagram displays, verify the G-LINK cable is connected as shown.
4. For brand of cable box, select **Scientific Atlanta**.
5. Follow the on-screen instructions and verify that your DTVPal DVR changed channels.
6. When asked if the device has tuned to Channel 9, select **Yes**.
7. On the confirmation screen, select **Yes, continue/finish setup process**. If you are asked about setting up a VCR, select the appropriate answer for your installation.

DOWNLOADED FROM SATELLITEGUYS.US

NOTE: POSSIBLE ROUGH DRAFT

SPECS & INSTRUCTIONS SUBJECT TO CHANGE
WITHOUT NOTICE



TV Guide

Completing Setup

- After setup is complete, exit the Guide setup screen. To begin receiving listings, be sure to turn off the Guide-enabled device when not in use.
- Within 24 hours, you will begin receiving TV show listings. It may take up to six days to receive the full eight days of initial show listings.
- Show listings are updated several times per day. Be sure to leave your DTVPal DVR powered on to have the most updated listings information. It is normal for your DTVPal DVR to change channels while the Guide-enabled device is powered off and is setting up or receiving new data.

Note: When you receive your new Guide listings, you will notice that your channel numbers have changed. Refer to *Tuning to Your New Channel Numbers*, below, or visit www.tvgos.com/support for more details.

Tuning to Your New Channel Numbers

After connecting your Guide-enabled TV or DVD recorder to your DTVPal DVR or VCR, the channel numbers used in your Guide Listings will change.


Understanding Your New Channel Numbers

Your analog TV, DVD recorder, or VCR does not know how to tune to digital channels. The channel number assigned to your channel lineup allows your DTVPal DVR to find the correct digital channels.

Finding Channel Numbers

In any Guide version, you can identify the channel number using the Channel Editor.


1. On the Service Bar, highlight **Listings**. Press MENU on the Guide-enabled device's remote control, then select **Edit Channel**.
2. The Channel Editor displays. Note the Guide channel number for each channel.



Note: You need this channel number to go to a specific channel in the Listings screen or if you are scheduling a manual reminder or recording. Visit www.tvgos.com/support for more information.

Displaying Channel Numbers in Listings

Your Guide version may or may not have the ability to display channel numbers in the Listings grid.



To determine if you can display the new channel numbers:

1. Highlight Listings (or any channel's logo), then press MENU on the Guide-enabled device's remote control.
2. The Listings Options (or Channel Options) menu appears. If there is a Channel ID field, you can press the LEFT or RIGHT ARROW to select a channel display option:
 - **Both**—displays both the channel logo and number.
 - **Logo**—displays only the channel logo.
 - **Number**—displays only the channel number.



TV Guide

Substitute ZIP Codes

Locate the major broadcast area closest to your location. Note the substitute ZIP code associated with this area and enter it as your ZIP code during the TV Guide On Screen/Guide Plus Setup.

State	Broadcast Area	ZIP Code
AK	Anchorage	00218
AK	Fairbanks	00224
AK	Juneau	00223
AK	Sitka	00211
AL	Anniston	00195
AL	Birmingham	00050
AL	Dothan	00165
AL	Dothan	00207
AL	Huntsville-Decatur-Florence	00081
AL	Mobile-Pensacola-Ft Walt	00058
AL	Montgomery-Selma	00111
AL	Phenix City	00219
AL	Tuscaloosa	00186
AR	Ft. Smith-Fayetteville-Springdale-Rogers	00117
AR	Jonesboro	00177
AR	Little Rock-Pine Bluff	00056
AZ	Phoenix	00021
AZ	Tucson-Sierra Vista	00079
AZ	Yuma-El Centro	00178
CA	Bakersfield	00130
CA	Chico-Redding	00125
CA	El Centro	00192
CA	Eureka	00187
CA	Fresno-Visalia	00057
CA	Los Angeles	00002
CA	Palm Springs	00162
CA	Sacramento-Stockton-Modesto	00019
CA	Salinas-Monterey	00103
CA	San Diego	00024
CA	San Francisco-Oakland-San Jose	00005
CA	Santa Barbara-Santa Maria-San Luis Obispo	00112
CO	Colorado Springs-Pueblo	00097
CO	Denver	00020
CO	Grand Junction-Montrose	00188
CT	Hartford-New Haven	00025

State	Broadcast Area	ZIP Code
DC	Washington	00007
FL	Ft. Myers-Naples	00087
FL	Gainesville	00166
FL	Jacksonville	00054
FL	Miami-Fort Lauderdale	00015
FL	Orlando-Daytona Beach-Melbourne	00023
FL	Panama City	00164
FL	Tallahassee-Thomasville	00115
FL	Tampa-St. Petersburg-Sarasota	00016
FL	West Palm Beach-Ft. Pierce	00046
GA	Albany	00154
GA	Atlanta	00011
GA	Augusta	00110
GA	Columbus	00122
GA	Macon	00119
GA	Savannah	00101
HI	Honolulu	00210
IA	Cedar Rapids-Waterloo-Iowa City-Dubuque	00082
IA	Des Moines-Ames	00068
IA	Ottumwa-Kirksville	00200
IA	Sioux City	00140
ID	Boise	00132
ID	Idaho Falls-Pocatello	00158
ID	Twin Falls	00201
IL	Champaign-Springfield-Decatur	00075
IL	Chicago	00003
IL	Davenport-Rock Island-Moline	00084
IL	Marshall-Robinson	00217
IL	Peoria-Bloomington	00107
IL	Quincy-Hannibal-Keokuk	00159
IL	Rockford	00134
IN	Evansville (no DST)	00215
IN	Evansville (with DST)	00094
IN	Ft. Wayne	00102
IN	Indianapolis	00026
IN	Scottsburg-Madison	00213

DOWNLOADED FROM SATELLITEGUYS.US

NOTE: POSSIBLE ROUGH DRAFT

SPECS & INSTRUCTIONS SUBJECT TO CHANGE
WITHOUT NOTICE

State	Broadcast Area	ZIP Code
IN	South Bend-Elkhart	00083
IN	Terre Haute	00138
KS	Topeka	00139
KS	Wichita-Hutchinson	00062
KY	Bowling Green	00181
KY	Lexington	00070
KY	Louisville	00047
LA	Alexandria	00169
LA	Baton Rouge	00095
LA	Lafayette	00120
LA	Lake Charles	00174
LA	Monroe-El Dorado	00131
LA	New Orleans	00039
LA	Shreveport	00071
MA	Boston-Manchester	00006
MA	Springfield-Holyoke	00098
MD	Baltimore	00022
MD	Salisbury	00163
ME	Bangor	00155
ME	Portland-Auburn	00076
ME	Presque Isle	00205
MI	Detroit	00009
MI	Flint-Saginaw-Bay City	00060
MI	Grand Rapids-Kalamazoo-Battle Creek	00037
MI	Ironwood	00222
MI	Lansing	00105
MI	Marquette-Escanaba	00175
MI	Traverse City-Cadillac	00121
MN	Duluth-Superior	00126
MN	Minneapolis-St. Paul	00014
MN	Rochester-Mason City	00148
MO	Columbia-Jefferson City	00151
MO	Joplin-Pittsburg	00146
MO	Kansas City	00029
MO	Paducah-Cape Girardeau-Harrisonburg	00077
MO	Springfield	00080
MO	St. Joseph	00193
MO	St. Louis	00018
MS	Biloxi-Gulfport-Pascagoula	00180
MS	Columbus-Tupelo-West Point	00127
MS	Greenwood-Greenville	00179

State	Broadcast Area	ZIP Code
MS	Hattiesburg-Laurel	00167
MS	Jackson	00088
MS	Meridian	00183
MT	Billings	00171
MT	Butte-Bozeman	00189
MT	Glendive	00221
MT	Great Falls	00182
MT	Missoula	00176
NC	Charlotte	00030
NC	Greensboro-High Point-Winston Salem	00049
NC	Greenville-New Bern-Washington	00104
NC	Raleigh-Durham-Fayetteville	00032
NC	Wilmington	00143
ND	Fargo-Valley City	00109
ND	Minot-Bismarck-Dickinson-Williston	00152
NE	Lincoln-Hastings-Kearney	00099
NE	Omaha	00073
NM	Albuquerque-Santa Fe	00048
NM	Clovis	00220
NV	Las Vegas	00074
NV	Reno	00118
NY	Albany-Schenectady-Troy	00053
NY	Binghamton	00135
NY	Buffalo	00038
NY	Elmira	00172
NY	New York	00001
NY	Rochester	00069
NY	Syracuse	00067
NY	Utica	00161
NY	Watertown	00170
OH	Cincinnati	00031
OH	Cleveland-Akron-Canton	00012
OH	Columbus	00034
OH	Dayton	00052
OH	Toledo	00064
OH	Youngstown	00092
OK	Oklahoma City	00043
OK	Tulsa	00059
OR	Bend	00202
OR	Eugene	00116
OR	Medford-Klamath Falls	00145

DOWNLOADED FROM SATELLITEGUYS.US

NOTE: POSSIBLE ROUGH DRAFT

SPECS & INSTRUCTIONS SUBJECT TO CHANGE
WITHOUT NOTICE

Customizing Receiver

TV Guide



State	Broadcast Area	ZIP Code
OR	Portland	00027
PA	Erie	00142
PA	Harrisburg-Lancaster-Lebanon-York	00044
PA	Johnstown-Altoona	00089
PA	Philadelphia	00004
PA	Pittsburgh	00017
PA	Wilkes Barre-Scranton	00051
RI	Providence	00045
SC	Charleston	00106
SC	Columbia	00086
SC	Florence-Myrtle Beach	00136
SC	Greenville-Spartanburg-Asheville-Anderson	00035
SD	Rapid City	00168
SD	Sioux Falls-Mitchell	00108
TN	Chattanooga (CT)	00208
TN	Chattanooga (ET)	00085
TN	Jackson	00185
TN	Knoxville	00063
TN	Memphis	00042
TN	Nashville	00033
TN	Tri-Cities Tn-Va	00091
TX	Abilene-Sweetwater	00157
TX	Amarillo	00129
TX	Austin	00065
TX	Beaumont-Port Arthur	00137
TX	Corpus Christi	00123
TX	Dallas-Ft. Worth	00008
TX	El Paso	00100
TX	Houston	00010
TX	Laredo	00198
TX	Lubbock	00149
TX	McAllen-Harlingen-Weslaco-Brownsville	00113
TX	Odessa-Midland	00150
TX	San Antonio	00036
TX	Sherman-Ada	00156
TX	Tyler-Longview-Lufkin-Nacogdoches	00114
TX	Waco-Temple-Bryan	00096
TX	Wichita Falls	00141
UT	Salt Lake City	00041
VA	Charlottesville	00197
VA	Harrisonburg	00173

State	Broadcast Area	ZIP Code
VA	Norfolk-Portsmouth-Newport News	00040
VA	Richmond-Petersburg	00061
VA	Roanoke-Lynchburg	00066
VT	Burlington-Plattsburg	00093
WA	Seattle-Tacoma	00013
WA	Spokane	00078
WA	Yakima-Pasco-Richland-Kennewick	00124
WI	Green Bay-Appleton	00072
WI	La Crosse-Eau Claire	00128
WI	Madison	00090
WI	Milwaukee	00028
WI	Wausau-Rhinelanders	00133
WV	Bluefield-Beckley-Oak Hill	00147
WV	Charleston-Huntington	00055
WV	Clarksburg-Weston	00160
WV	Wheeling	00144
WY	Casper-Riverton	00194
WY	Cheyenne-Scottsbluf	00196

DOWNLOADED FROM SATELLITEGUYS.US

NOTE: POSSIBLE ROUGH DRAFT

SPECS & INSTRUCTIONS SUBJECT TO CHANGE
WITHOUT NOTICE

Getting Help

- FINDING MORE INFORMATION
- TROUBLESHOOTING



Finding More Information

FINDING MORE INFORMATION

How to get help:

- You can find more information on the www.dtvpal.com website.

Troubleshooting

Missing specific channels

1. Your DTVPal is only able to tune digital over-the-air channels. It is possible that some of the channels you are missing are channels that are still broadcasting in analog.
2. You can go to the website www.antennaweb.org to find out which channels in your area are currently broadcasting a digital signal. If the channel you are missing is still broadcasting in analog, you can view the channel using the TV's tuner. To view analog channels, press the ANALOG PASS-THROUGH button on the DTVPal DVR remote control, then change channels on your TV using your TV's remote control. When you want to return to watching digital channels using your DTVPal DVR, change back to the correct channel (3 or 4) or input/source, and press the ANALOG PASS-THROUGH button again.

Signal loss on all channels

1. Try a different channel. Sometimes, just one channel may be experiencing a problem, while other channels are fine. If just one channel seems have the problem, go to the next section, *Signal loss on one or some channels*. If all channels are experiencing the problem, then continue with Step 2.
2. Verify that the coax cable connecting to the **Over The Air Antenna In** connection is hand tight, and is connected to your over-the-air antenna.
3. Verify that your over-the-air antenna is still in place, and does not appear to have moved. If the antenna is moved out of proper alignment, then you may receive signal loss messages on some or all of your channels.
4. Try resetting your DTVPal DVR. Press the POWER button on the DTVPal DVR remote control to turn it off (in standby mode), then unplug the DTVPal DVR from the power outlet for 15 seconds, plug it back in, and POWER it back on.



Finding More Information

5. Check the signal strength on your over-the-air channels. Using your DTVPal DVR remote control, press MENU, select **Setup, System Setup, Channel Setup**, then **Add a New Channel**. Find a channel that is experiencing problems, and verify that it has a strong signal. Channels with an indicated signal strength below approximately 60 are likely to experience loss of video.
6. Your over-the-air antenna may need to be adjusted. Contact your local retailer for assistance. If you want to try adjusting the antenna yourself, refer to any instructions accompanying the antenna, or to www.antennaweb.org for antenna recommendations and general information on antenna alignment.

Signal loss on one or some channels

1. Try a different channel. Sometimes, just one channel may be experiencing a problem, while other channels are fine. If all channels are experiencing the problem, go to the previous section, *Signal loss on all channels*. If just one channel or a few channels seem to have a problem, then continue with Step 2.
2. Your DTVPal DVR is only able to tune in digital over-the-air channels. If you are missing some channels, it is possible that some of them are channels that are still broadcasting analog signals. See *Missing specific channels* on page 42.
3. You can refer to the website www.antennaweb.org for lists of which channels in your area are currently broadcasting digital signals. If the channel or channels you are missing is/are still in analog, you can view the channel(s) using the TV's built-in tuner. To view analog channels, press the ANALOG PASS-THROUGH button on the DTVPal DVR remote control, then change channels on your TV using your TV's remote control. When you want to return to watching digital channels using your DTVPal DVR, change back to the correct channel (3 or 4) or input (source), and press the ANALOG PASS-THROUGH button again.

Remote is not working

1. Verify the batteries are installed according to the battery diagram in the remote control.
2. Try changing the batteries in the DTVPal DVR remote control. Batteries should all be of the same type and size.
3. Make sure you are pointing the remote control directly at the front panel of the DTVPal DVR. The remote uses infrared (IR) signals to operate the DTVPal DVR (and any other equipment you have programmed in

DOWNLOADED FROM SATELLITEGUYS.US
 NOTE: POSSIBLE ROUGH DRAFT
 SPECS & INSTRUCTIONS SUBJECT TO CHANGE
 WITHOUT NOTICE



Finding More Information

the other device modes), and therefore must have line of sight to the front of the DTVPal DVR (or other equipment).

Forgot password for locks

1. Locate the Receiver ID number by pressing MENU on the DTVPal DVR remote control, selecting **Setup, System Setup**, then **System Information**. Write down the Receiver ID number (before the dash).
2. To reset your password, press MENU on the DTVPal DVR remote control, select **Setup**, then **Locks**. Enter the last four digits of your Receiver ID number (before the dash) as a temporary password, then select **Change Password** to choose a new password. When prompted for your old password, you must re-enter your temporary password before you can enter and then confirm a new password.

Program Guide issues

1. If you try to display future programs in the Program Guide or Browse Banner, but are unable to find the schedule you are looking for, you may try displaying the Program Guide again later. By that time, updates may show programs for the times you want.
2. The Program Guide and Browse Banner can display only programs that have not yet ended. They cannot display a time earlier than the present.
3. If some channels are missing when you are using the Program Guide or Browse Banner, you may have locked the DTVPal DVR to hide adult channels, or you may have applied a Favorites List other than All Chan. Unlock the DTVPal DVR (see *Locks* on page 20), or choose a different Favorites List (see *Customizing the Guide and Channel Lists* on page 23), respectively, to show the channels you are missing in the guide.
4. For the full guide to be displayed, TV Guide data must be transmitted in your area. You have access to the TV Guide data if you see the TV Guide logo in the top right corner of the program guide. If the TV Guide logo is not showing, then please check that your ZIP code has been entered correctly. Once the ZIP code is verified correct, wait until the following day to recheck the Program Guide screen. If the TV Guide logo is still not present, then unfortunately the extended guide data may not be available in your area.



Finding More Information

Timer issues

1. If a program is locked, you must enter the password to create a timer.
2. If you have set up the maximum number of event timers, the DTVPal DVR displays an error message if you try to set up another, giving you the option to delete an existing event timer.
3. If you try to set up a manual timer with invalid start or stop times (for example, an event stop time that occurs before its start time), you will see an error message.
4. If you stop or skip a timer that is repeated, the next showing of the event is not affected. To stop all occurrences, you must delete the event timer. (A timer with a frequency of Once is deleted when it has occurred.)
5. If you set a timer that misses the beginning or end of a program, you may want to use or change the Start Early or End Late options for the timer, or set a manual timer to begin and end at times you specify.

Events not recording

1. Ensure any event timers you have set that you want to record programs are set as DVR timers, and not as Auto-Tune/Reminder timers.
2. If you set up a repeating event timer, but it does not record a showing of the program, double-check that you set the correct frequency for that program (Weekly, Daily, Mon-Fri.).

Events disappearing from DVR list

1. If you run out of space on your DTVPal DVR, recordings that are not protected will begin to be erased, starting with the oldest unprotected one, as needed to make room for new recordings, as they occur.
2. If you do not want a recording to be deleted, select **Protect** on the screen for that recording.



Finding More Information



DOWNLOADED FROM SATELLITEGUYS.US
NOTE: POSSIBLE ROUGH DRAFT
SPECS & INSTRUCTIONS SUBJECT TO CHANGE
WITHOUT NOTICE

APPENDIX

LIMITED WARRANTY

FCC COMPLIANCE

Appendix

LIMITED WARRANTY



This Limited Warranty is a legal document. Keep it in a safe place. Remember to retain your Bill of Sale for warranty service! Any items returned without a copy of the Proof of Purchase will be considered out of warranty.

What the Warranty Covers

This warranty extends only to the original user of the equipment and is limited to the purchase price of each part. DISH Network Corporation and its affiliated companies ("DISH Network") warrant this system against defects in materials or workmanship as follows:

- **Labor:** For a period of 90 days from the original date of purchase, if DISH Network determines that the equipment is defective subject to the limitations of this warranty, it will be replaced at no charge for labor. DISH Network warrants any such work done against defects in materials or workmanship for the remaining portion of the original warranty period.
 - **Parts:** For a period of 90 days from the original date of purchase, DISH Network will supply, at no charge, new or re-manufactured parts in exchange for parts determined to be defective subject to the limitations of this warranty. DISH Network warrants any such replacement parts against defects in materials or workmanship for the remaining part of the original warranty period.
- Note:** "Parts" means items included in this package, which may include the TV converter and remote control. It does not include other parts purchased separately.

What the Warranty Does Not Cover

- This warranty does not cover installation of the system. If applicable, such installation will be warranted under a separate installation agreement.
- This warranty does not cover consumer instruction, physical setup or adjustment of any consumer electronic devices, remote control batteries, signal reception problems, loss of use of the system, or unused programming charges due to system malfunction.
- This warranty does not cover cosmetic damage, damage due to lightning, electrical or telephone line surges, battery leakage, fire, flood, or other acts of Nature, accident, misuse, abuse, repair or alteration by other than authorized factory service, use of accessories not recommended by the TV converter manufacturer, negligence, commercial or institutional use, or improper or neglected maintenance.
- This warranty does not cover equipment sold AS IS or WITH ALL FAULTS, shipping and handling, removal or reinstallation, shipping damage if the equipment was not packed and shipped in the manner prescribed, nor equipment purchased, serviced, or operated outside the continental United States of America.

If You Need Assistance

- 1 Call the customer support number at 1-888-667-0633 or visit our website www.DTV-Pal.com. Have the date of purchase and your receiver ID number available. Press the SYSTEM INFO button on the remote control to display the receiver ID number.
- 2 A Customer Service Representative will assist you. If the Representative determines you should return any equipment, you will be given steps and an address for which to return your equipment. Whether under warranty or not, you will be responsible for the cost of shipping back the defective equipment.

DOWNLOADED FROM SATELLITEGUYS.US

NOTE: POSSIBLE ROUGH DRAFT

SPECS & INSTRUCTIONS SUBJECT TO CHANGE
WITHOUT NOTICE

Limited Warranty

- 3 Returned equipment must be packaged properly, using either the original shipping materials or other appropriate packaging. Include a copy of the Bill of Sale. Any items returned without a copy of the Proof of Purchase will be considered out of warranty.
- 4 Follow the instructions given to you by the Customer Service Representative when returning your equipment for service.

Legal Limitations

REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS YOUR EXCLUSIVE REMEDY. DISH NETWORK SHALL NOT BE HELD LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESSED OR IMPLIED WARRANTY ON THIS SYSTEM, NOR FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF, OR INABILITY TO USE, THIS SYSTEM. UNDER NO CIRCUMSTANCES SHALL DISH NETWORK'S LIABILITY, IF ANY, EXCEED THE PURCHASE PRICE PAID FOR THIS SYSTEM. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS SYSTEM IS LIMITED IN DURATION TO THE PERIOD OF THIS WARRANTY. DISH NETWORK RESERVES THE RIGHT TO REFUSE TO HONOR THIS WARRANTY IF DISH NETWORK DETERMINES ANY OF THE ABOVE EXCEPTIONS TO HAVE CAUSED THIS SYSTEM NOT TO HAVE PERFORMED PROPERLY. THIS WARRANTY SHALL BE VOID IF ANY FACTORY-APPLIED IDENTIFICATION MARK, INCLUDING BUT NOT LIMITED TO SERIAL OR CONDITIONAL ACCESS NUMBERS, HAS BEEN ALTERED OR REMOVED. THIS WARRANTY SHALL ALSO BE VOID IF THE TV CONVERTER HAS BEEN OPENED BY AN UNAUTHORIZED PERSON.

Appendix

FCC COMPLIANCE



The following text is extracted from Federal Communications Commission (FCC) regulations, as of the publication date of this *Guide*. Contact the FCC (see following) or your library for the complete text of the regulations.

Compliance Information Statement

DISH Network Corporation, 9601 S. Meridian Blvd, Englewood, CO., (303) 723-1000, declares that: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Do not make changes or modifications to this equipment. This could void the user's authority to operate the equipment.

There are many devices that allow you to connect your antenna to your in-home distribution system such as splitters, and amplifiers. The FCC requires that the isolation between the antenna port and the network port of your system meet the following:

- 80dB from 54 MHz to 216 MHz, at least
- 60dB from 216 MHz to 550 MHz and at least
- 55dB from 550 MHz to 806 MHz

Measuring the isolation of a device requires specialized equipment. In most cases, it is easier to purchase a splitter or amplifier with the correctly specified isolation from your local television retailer. The above requirements are extracted from 47CFR15.115. For the complete text please visit WWW.FCC.GOV.

FCC DIGITAL TELEVISION TRANSITION NOTICE

February 17, 2009 marks the date when local over-the-air full-power TV broadcasts will transition from analog to digital within the United States. Consumers with analog TVs, who rely on an over-the-air antenna to receive their local broadcast TV programming, will need a digital-to-analog converter box, a digital TV with a digital tuner, or to subscribe to a pay TV service like DISH Network to display those digital broadcasts. Analog TVs that do not use one of those methods to get a digital signal will continue to work for other purposes, including watching low-power TV stations still broadcasting in analog, watching pre-recorded movies with a DVD player or VCR, or playing video games.

Great news!

Your new DTVPal DVR allows you to continue enjoying the over-the-air digital broadcasting programming available in your area. Your new DTVPal DVR also allows you to receive analog broadcasts simply by pushing the Analog Pass-Through on your remote. This is a great feature to view those low-power TV stations that do not convert to digital on 2/17/09.

Additional information regarding the digital television transition, including information about subsidized coupons for digital-to-analog converter boxes, is available at www.dtvpal.com, www.DTV.gov, www.dtv2009.gov, 1-888-DTV-2009, or 1-888-CALL-FCC.

Printed in

Appendix

A

ANTENNA IN connection 3, 6
ascending order, channel lists 23
Audio
 Night Mode 17
 Standard Mode 17
audio language 24
Audio Setup 24
Auto 24

B

BACK button 14, 15
Browse Banner 12

C

CANCEL button 10, 11
Captions Off 24
Captions On 24
Care of Your Equipment 5
Changing
 Closed Captioning 24
 Display Formats 24
 Inactivity Standby 25
 Languages 24
Channel Order 23
Closed Captioning (CC) 24
coaxial cable 3, 6
component cables 2, 4
composite (RCA-type) cables 5
Connecting DTVPal DVR to
Your TV 2
connection type
 coax 3
 component 2
 HDMI 2
 RCA (composite) 3
Controlling Live TV 13

D

descending order, channel lists
23
Description 12
Device Code Tables 27
 DVD Player Codes 30
 Tuner/Amplifier Codes 30
 TV Codes 27
 TV/DVD Combo Codes 31
 TV/DVD/VCR Combo Codes
 31
 TV/VCR Combo Codes 31
 TV/VCR/Tuner Combo
 Codes 31
 VCR Codes 28
digital channels 8
digital sub-channels 8
Direction of channel lists 23
Display format options 24
Dolby Digital audio 16
Dolby Digital Surround Sound
decoding 16
DVR Menu 13
 Daily Schedule 13
 My Recordings 13

E

EPG Preferences screen 23
Event Search 12
 History 12
 Specific keyword search 12
Exact Match 12

F

Finding a Program
 Channel Up/Down 10
 Direct Entry 11
 Overview 10

fixed images, caution 5, 15
FWD button 14, 15

G

Getting Started
 Connecting DTVPal DVR to
 Your TV 2
 Navigating the Menus 9
 Using the Setup Wizard 6
GUIDE button 11
Guide Display 23
Guide Display, Preferences for
EPG 23

H

HD 15, 16, 24
HDMI cable 2, 3
HDMI connection type 2
HDTV 10
Hide Channels 20
high-definition (HD) 10
History 12

I

Important Safety Instructions 2,
3, 4
Important Safety Note 2
Inactivity Standby 25
input, TV's video 7

K

Keyword search 12

L

Linear PCM audio 16
Live TV, Controlling 13
Locks

 Hide Locked Channels 20

M

My Recordings 13, 15

N

Normal 24

O

Options, My Recordings List 13
Options, Search 12

P

PAGE DOWN button 24
PAGE UP button 24
PAGE UP/PAGE DOWN but-
tons 11
Partial Zoom 24
PAUSE button 13, 15
PLAY button 14, 15
POUND (#) button 26
Preferences
 Channel Order 23
preferences
 resetting 25
Preferences Menu 15
 Closed Captions 24
 Guide Display 23
 Inactivity Standby 25
Program Guide 11
 Channel Order 23
Programming Your Remote
Control 25
 Setting Up Devices by Enter-
 ing Codes 26
 Setting Up Using Device
 Codes Scan 26

R

RCA cables 3

DOWNLOADED FROM SATELLITEGUYS.US

NOTE: POSSIBLE ROUGH DRAFT

SPECS & INSTRUCTIONS SUBJECT TO CHANGE
WITHOUT NOTICE

RCA connectors 3
Recording My Programs
 Finding and Watching Recorded Programs 15
 Recording What You're Watching Now 14
 Setting Up Timers 14
Remote Control Programming 25
 Device Code Tables 27
 Device Codes 26
Remote Control, buttons 32
Restore Factory Defaults 25

S

SAFETY

 Important Safety Instructions 1
 Proper Care of Your Equipment 1

SD 15, 24
SDTV 10
Search 12
SEARCH (#) button 12
Setup menu 13
SKIP BACK button 11, 13, 15
SKIP FORWARD button 11, 14, 15
Software Upgrade Options
 Upgrading via Ethernet 32
 Upgrading via USB 32
source, TV's input 7
standard-definition (SD) 10
Stretch 24
sub-channels 8

T

timer setup 14

Timers

 Create 13
 Delete 13
 Edit 13

Timers menu 16

Title 12

Title/Description 12

Troubleshooting

 Channel Setup 43

TV Guide 33

TV SET OUT connection 6

U

Using Dolby® Digital Surround Sound 16

Using the Remote Control Buttons 32

V

VIEW LIVE TV button 14

Viewing Options

 Browse Banner 12

 Event Search 12

 Finding a Program 10

 Program Guide 11

VOLUME+/VOLUME- buttons 26

Y

YPrPb connectors 4

Z

Zoom 24