

HOPPER / JOEY REMOTE CONTROL COLOR BUTTON MENU SHORTCUT LIST

Latest 27 May 2017

FROM SCREEN	BUTTON	MENU / SCREEN
Live TV	Red	TV Viewing Options
	Green	Turn On / Off Closed Captioning
	Yellow	Settings
	Blue	Apps
Menu	Yellow	Settings

If an option in a menu has a color next to it, press the matching color button. Your choice both highlights and selects the option.