


DISH Player-DVR 522 - Single Mode



Overview

"Single Mode" provides viewers the option to record two programs (even while watching a previously-recorded event), watch one live program while recording another, or use Picture-in-Picture features on any type of TV.

- In Single Mode, all 522 remote controls (both the green key and blue key remotes) will operate the viewing experience (blue key remotes only when Shared View is Enabled). For example, changing channels, operating PIP, and recording programs.
- "Dual Mode" allows viewers to independently watch or record two programs at the TV1 and TV2 viewing locations (even while watching a previously-recorded event). The receiver's default option is Dual Mode.



Changing between Single Mode & Dual Mode

- Press the MODE button on the front of the satellite receiver to change between Dual Mode and Single Mode. The MODE light toggles between Dual and Single with each press of the MODE button.
- If TV2 is on when Single Mode is chosen, a pop-up displays to let the TV1 viewer choose whether or not they want to disrupt TV2's viewing. When the TV1 viewer selects **YES**, TV2's viewing matches TV1.
 - TV2 only receives a warning message when **Shared View** is disabled (see next page for information about **Shared View**).

Record/Watch Two Programs

To watch one program while recording another:

- Ensure the receiver is in Single Mode (check the MODE light).
- Begin viewing a current program to be recorded.
- Press the RECORD button on the remote control and select **OK**, or make changes using choices from **Options**, then select **OK**.
- Afterwards, choose a new program to watch on a different channel.

To record two current programs:

- Ensure the receiver is in Single Mode (check the MODE light).
- Begin viewing a current program to be recorded.
- Press RECORD on the remote control and make recording choices from **Options** (if needed), then select **OK**.
- Find and view a second current program on a different channel, press RECORD and make recording choices from **Options** (if needed), then select **OK**.

In Single Mode, even while the viewer has two programs recording, they can watch a program that they've already recorded, by choosing a program from the **DVR Events** list.

Picture-In-Picture

The three blue buttons in the center of the 522's remotes operate the Picture-in-Picture (PIP) features when the receiver is in Single Mode. A PIP-enabled television is not needed to use this feature (nor is special hookup of the receiver to the TV required) – PIP is displayed using the 522 satellite receiver.



- To open the PIP window, press the center blue PIP button. Press it again to make it larger. Press it a third time to close the PIP window.
 - The PIP image is seen on both TV1 and TV2 (when Shared View is Enabled).
- With the PIP window open, press the POSITION button to move the small or large PIP window around to nine different locations on the TV screen.
- The SWAP button allows you to move the program in the PIP window to the large screen while moving the program in the large screen to the PIP window. Press SWAP again to switch them back. After using SWAP, you can:
 - change the channel of the program that was just in the PIP window or view a previously-recorded program.
 - use the DISH DVR features (such as Pause, Skip Back, etc.) on the program that was just in the PIP window.
 - listen to the audio of the program that was just in the PIP window.
- The SWAP button can also be used without opening a PIP window for a non-PIP swap. Each press of the SWAP button displays the program playing on the other satellite tuner.
 - You cannot swap between a live and a previously-recorded program, unless you use PIP. If you non-PIP swap while watching a recorded program, the recorded program will stop and be replaced by the last live channel viewed when the SWAP button is pressed again.

TV2 Viewer Options

When in Single Mode, TV2 viewers (the ones with the blue key at the bottom of their remote control) will watch what TV1 is watching (including PIP), if the receiver has **Enable View** selected within the **Shared View** screen.

- When **Enabled View** is selected, the TV2 viewer (using their TV2 blue key remote from the remote viewing location) can change channels, record programs, use DVR features, and use PIP just like the TV1 viewer.
- When **Disable View** is selected, the TV2 viewer will see the "Shared view is currently disabled" DISH Network logo screen. They cannot operate the satellite receiver until the TV1 viewer chooses **Enable View** in Shared View.



Shared View – Enabling/Disabling

- Ensure the receiver is in Single Mode.
- Press MENU on the remote control to see the **Main Menu** screen.
- Press #6 for the **System Setup** screen, then #2 for **Shared View**.
- Move the highlight over to choose to let the TV2 viewers watch what TV1 is watching by choosing **Enable View**. Or, turn off TV2's satellite viewing by selecting **Disable View**.