

Voice Commands

The voice control on the 50.0 and 54.0 remotes makes navigating through the Hopper system a breeze.

. See How to Use Voice Commands

Example Commands

Categories

- Actor: "Liam Neeson"
- Genre: "Movie"
- Movies: "Blades of Glory"
- Shows: "Big Bang Theory"
- Sport: "English Premier League"
- Sports Team: "Broncos"
- Year: "80s comedies"

Natural Language

- "Free movies starring Tom Cruise" (name of actor)
- "On Demand TV Shows from HBO" (name of network)
- "Show me movies I can watch now"
- "What live sports are on right now"
- (name of actor) "Johnny Depp movies from the 90's"
- "You can't handle the truth!" (other popular movie quotes)
- (name of actor) "Eddie Murphy movies rated PG-13 and below"
- (name of actor) "Movies with George Clooney and John Turturro"

Navigation

- "Tune to channel 140" (channel number)
- "Tune to Animal Planet" (name of channel)
- Launch VOD: "On Demand" (when watching a show)
- Launch Home Screen: "Home" (when watching a show)
- Launch Main Menu: "Main Menu" (when watching a show)
- Launch DVR: "DVR" (when watching a show)
- Open Guide: "Guide" (when watching a show)
- Go to Live TV: "Live TV" (from delayed play, DVR playback, Menus, etc)
- Show Program Info: "Info" (when watching a show)

Configure Settings

- Picture in Picture On/Off "Picture in Picture" or "PiP" or "Swap" or "Side-by-Side"
- Set Recordings "Record this" (when watching a show)
- Playback "Play this" (when in the DVR screen)

Other

- "Skip Forward"
- "Skip Back"
- "Fast Forward/Rewind"
- "Pause/Play/Stop"