

GEOSATpro microHD
User Data Base (.udf) Update via USB

12/05/2012

1. Save the microHD User Data Base (.udf) file to an USB drive.
2. Insert the USB drive into the microHD rear panel USB port.
3. Press Menu key then press the Down Navigation Arrow key to select and highlight the Tools Menu icon.
4. Press the List/OK key to display the Tools Menu screen.
5. Press the Up or Down Navigation Arrow key to Select Update by USB.
6. Press List/OK key to display Update by USB screen.
7. With the Save Mode line highlighted, Press the Right Navigation Arrow key to select userdb
8. Press the Down Navigation Arrow key to highlight Upgrade File.
9. Press the Right Navigation Arrow key to select the desired User Data Base (.udf) file. Example: USERDB.udf.
10. Press the Down Navigation Arrow key to highlight Start.
11. Press the List/OK Key to initiate the User Data Base file transfer to the microHD.
12. When the warning screen appears, select Yes if you wish to continue with the User Data Base loading or No to escape without updating the receiver.
13. The update is now in process and cannot be interrupted. During this process it is critical that the power is not interrupted or shut off. A power interruption may corrupt the User Data Base file transfer and cause the receiver to be inoperable.
14. Once the Update by USB is complete (status bar at 100%), the microHD power will turn off then the unit will reboot.
15. We recommend that the microHD be disconnected from power for at least 10 seconds. This will reset the unit and clear any memory buffers.
16. The User Data Base (.udf) update with the saved User receiver settings, satellite, transponder and channel list and is now complete. If the system is motorized with USALS settings, the USALS installation location's Longitude and Latitude will need to be inputted.
17. The User Data Base update is now complete and may now return to watching TV!