

S/W Update via Satellite - Manual Mode

Back-up your current firmware to USB - Save to USB (ALLCODE) .abs

Save your user data to USB - Save to USB (userdb) .udf


Highlight S/W Update via Satellite - Manual, press OK




Highlight Transponder and press the Right arrow key to select frequency 12115 V 22425

Do not change any other settings in this menu.


Verify that the Signal Quality is 50% or better




Highlight Start, press OK key



STB will collect Update File information (allow up to 30 seconds)
This file may be the same as your current version, but you may download.
Press OK key to start the download.




The download may take up to 2 minutes to complete. A status bar will show progress. If data is incomplete on the first pass, a second pass may be required to complete the file. You may stop the download by pressing OK key



When download is 100% complete, the prompt will appear "Press OK to Save Update"

Press OK key if you wish to save and continue



"Are you sure to burn the flash?" will appear. This is your last opportunity to exit the process without updating the firmware.

If you wish to continue, press the OK key. Do not interrupt or power down the STB during the part of the process.



The final step of the process is to restart or reboot the microHD. Press OK to Reboot the Receiver.

The receiver will power off then restart.

The update is now complete!