

For any dual tuner & ViP tuner (including 211 & 211k), there are five values to observe on the second screen of STBHealth Lite: Values 0, 1, 2, 4, & 7 (Value 7 only applicable on DVR 522's). If any of the five values are above the threshold, RA the receiver. (Currently, the other values are for engineering use only.)

