


16 Inbs with multiswitches and 22 khz switches



You need two cables coming from each Inb to connect to each multiswitches.

You would connect other receivers on the 3 other remaining connectors of the multiswitches.

Please note that you don't have to use multiswitches if you don't want to, you can connect directly the Inb to the 22 khz switch. In this case you don't need two cables per Inb, but you will be able to connect only 1 receiver.